OWNER'S MANUAL 2021



250 SX

Art. no. 3214210en





Congratulations on your decision to purchase a KTM motorcycle. You are now the owner of a state-of-the-art sports vehicle which, with appropriate care, will bring you pleasure for a long time to come.

We wish you good and safe riding at all times!

Enter the serial numbers of your vehicle below.

| Vehicle identification number (p. 12) | Dealer's stamp |
|--|----------------|
| | |
| | |
| Engine number (🗐 p. 12) | |
| | |
| | |

The Owner's Manual contained the latest information for this model series at the time of going to print. However, minor differences due to further developments in design cannot be ruled out completely.

All specifications contained herein are non-binding. KTM Sportmotorcycle GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. KTM accepts no liability for delivery options, deviations from figures and descriptions, misprints, and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of supply.

© 2020 KTM Sportmotorcycle GmbH, Mattighofen Austria

All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.



ISO 9001(12 100 6061)

KTM applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard. Issued by: TÜV Management Service

KTM Sportmotorcycle GmbH Stallhofnerstraße 3 5230 Mattighofen, Austria

This document is valid for the following models: 250 SX (F6301U0)



TABLE OF CONTENTS

| 1 | MEANS | S OF REPRESENTATION | . 5 | | 7.2 | Running in the engine | 20 |
|---|--------------|---------------------------------------|-----|----|--------|--|----|
| | 1.1 | Symbols used | . 5 | | 7.3 | Preparing the vehicle for difficult operating conditions | 20 |
| | 1.2 | Formats used | . 5 | | 7.4 | Preparing the vehicle for riding on | 20 |
| 2 | SAFFT | Y ADVICE | . 6 | | 7.4 | dry sand | 21 |
| _ | 2.1 | Use definition – intended use | | | 7.5 | Preparing the vehicle for riding on wet sand | 22 |
| | 2.2 | Misuse | . 6 | | 7.6 | Preparing the vehicle for riding on | |
| | 2.3 | Safety advice | | | | wet and muddy circuits | 24 |
| | 2.4 | Degrees of risk and symbols | | | 7.7 | Preparing vehicle for high | |
| | 2.5 | Tampering warning | | | 7.0 | temperatures or slow riding | 24 |
| | 2.6 | Safe operation | | | 7.8 | Preparing the vehicle for low | 25 |
| | 2.7 | Protective clothing | | | | temperatures or snow | 23 |
| | 2.8 | Work rules | | 8 | RIDING | GINSTRUCTIONS | 26 |
| | 2.9 | Environment | | | 8.1 | Checks and maintenance measures | |
| | 2.10 | Owner's Manual | . 8 | | 0.1 | when preparing for use | 26 |
| 3 | IMPOR | TANT NOTES | . 9 | | 8.2 | Starting | 26 |
| | 3.1 | Manufacturer warranty, implied | | | 8.3 | Starting off | 27 |
| | 0.2 | warranty | . 9 | | 8.4 | Shifting, riding | 27 |
| | 3.2 | Fuel, auxiliary substances | | | 8.5 | Applying the brakes | 28 |
| | 3.3 | Spare parts, accessories | . 9 | | 8.6 | Stopping, parking | |
| | 3.4 | Service | . 9 | | 8.7 | Transporting | |
| | 3.5 | Figures | . 9 | | 8.8 | Refueling | 30 |
| | 3.6 | Customer service | . 9 | 9 | SERVIC | CE SCHEDULE | 31 |
| 4 | VIEW C | F VEHICLE | 10 | | 9.1 | Additional information | 31 |
| | 4.1 | View of vehicle, front left (example) | 10 | | 9.2 | Required work | 31 |
| | 4.2 | View of vehicle, rear right | | | 9.3 | Recommended work | 32 |
| | | (example) | | 10 | TUNIN | G THE CHASSIS | 33 |
| 5 | | NUMBERS | | | 10.1 | Checking the basic chassis setting | 22 |
| | 5.1 | Vehicle identification number | | | 10.2 | with rider's weight | |
| | 5.2 | Type label | | | 10.2 | Compression damping of the shock | 55 |
| | 5.3 | Engine number | | | 10.5 | absorber | 34 |
| | 5.4 | Fork part number | | | 10.4 | Adjusting the low-speed | ٠. |
| 6 | 5.5 | Shock absorber article number | | | 10 | compression damping of the shock absorber | 34 |
| O | | | | | 10.5 | Adjusting the high-speed | ٠. |
| | 6.1 | Clutch lever | | | 10.0 | compression damping of the shock | |
| | 6.2 | Hand brake lever | | | | absorber | 35 |
| | 6.3 | Throttle grip | | | 10.6 | Adjusting the rebound damping of | |
| | 6.4 | Switch-off button | | | | the shock absorber | 35 |
| | 6.5 | Opening fuel tank filler cap | | | 10.7 | Measuring the rear wheel dimension | |
| | 6.6 | Closing the fuel tank filler cap | | | 100 | unloaded | 36 |
| | 6.7 | Fuel tap | | | 10.8 | Checking the static sag of the shock | 27 |
| | 6.8 | Choke | | | 100 | absorber | 3/ |
| | 6.9 | Shift lever | | | 10.9 | Checking the riding sag of the shock absorber | 37 |
| | 6.10 | Kick starter lever | | | 10 10 | Adjusting the spring preload of the | 57 |
| | 6.11 | Foot brake lever | | | 13.10 | shock absorber 4 | 38 |
| | 6.12 6.13 | Plug-in stand | | | 10.11 | Adjusting the riding sag 4 | |
| _ | | Service hour counter | | | | Checking the basic setting of the | |
| 7 | PREPA | RING FOR USE | 19 | | | fork | |
| | 7.1 | Advice on preparing for first use | 19 | | 10.13 | Adjusting the fork air pressure | 40 |

TABLE OF CONTENTS

| | 10.14 | Adjusting the compression damping | | | | Checking the frame 4 | |
|---|--------------|---|-----|----|--------|---|--------------|
| | | of the fork | 41 | | | Checking the link fork 4 | |
| | 10.15 | Adjusting the rebound damping of | 4.1 | | | Checking throttle cable routing | |
| | 10.16 | the fork | | | | Checking the rubber grip | 71 |
| | | Handlebar position | | | 11.42 | Adjusting the basic position of the | |
| | 10.17 | Adjusting the handlebar position 4 | 42 | | | clutch lever | 72 |
| 1 | SERVIO | CE WORK ON THE CHASSIS | 44 | | 11.43 | Checking/correcting the fluid level of the hydraulic clutch | 72 |
| | 11.1 | Raising the motorcycle with a lift stand | 44 | | 11.44 | Changing the hydraulic clutch fluid 4 | 73 |
| | 11.2 | Removing the motorcycle from the lift stand | 44 | 12 | BRAKE | SYSTEM | 75 |
| | 11.3 11.4 | Bleeding the fork legs | 44 | | 12.1 | Checking the free travel of the hand brake lever | 75 |
| | | legs | 45 | | 12.2 | Adjusting the basic position of the | |
| | 11.5 | Removing the fork legs 4 | | | | hand brake lever | 75 |
| | 11.6 | Installing the fork legs 4 | | | 12.3 | Checking the brake discs | 75 |
| | 11.7 | Removing the fork protector | | | 12.4 | Checking the front brake fluid level | |
| | 11.8 | Installing the fork protector | | | 12.5 | Adding front brake fluid 4 | |
| | 11.9 | Removing the lower triple clamp 4 | | | 12.6 | Checking the front brake linings | |
| | | Installing the lower triple clamp 4 | | | 12.7 | Changing the front brake linings 4 | |
| | | Checking steering head bearing | | | 12.8 | Checking the free travel of foot brake | |
| | | play | 50 | | | lever | 81 |
| | 11.12 | Adjusting steering head bearing play 4 | | | 12.9 | Adjusting the basic position of the foot brake lever ◀ | |
| | 11.13 | Lubricating the steering head | | | 12.10 | Checking the rear brake fluid level | 82 |
| | | bearing 4 | 51 | | | Adding rear brake fluid 4 | |
| | 11.14 | Removing the start number plate | 52 | | | Checking the brake linings of the | |
| | 11.15 | Installing the start number plate | 52 | | | rear brake | 84 |
| | 11.16 | Removing front fender | 52 | | 12.13 | Changing the rear brake linings ⁴ | 84 |
| | | Installing front fender | | 10 | | | |
| | 11.18 | Removing the shock absorber ⁴ | 53 | 13 | WHEEL | S, TIRES | 0/ |
| | 11.19 | Installing the shock absorber 4 | 54 | | 13.1 | Removing the front wheel 4 | 87 |
| | | Removing the seat | | | 13.2 | Installing the front wheel 📤 | 88 |
| | | Mounting the seat | | | 13.3 | Removing the rear wheel 4 | 88 |
| | | Removing the air filter box cover | | | 13.4 | Installing the rear wheel 4 | |
| | | Installing the air filter box cover | | | 13.5 | Checking the tire condition | |
| | | Removing the air filter - | | | 13.6 | Checking tire pressure | |
| | | Cleaning the air filter and air filter | | | 13.7 | Checking spoke tension | |
| | | box 🔏 | 59 | | | | |
| | 11.26 | Installing the air filter 4 | | 14 | COOLIN | NG SYSTEM | 93 |
| | | Preparing air filter box cover for | | | 14.1 | Cooling system | 93 |
| | | securing 4 | 60 | | 14.2 | Checking the antifreeze and coolant | |
| | 11.28 | Removing the main silencer | | | | level | 93 |
| | | Installing the main silencer | | | 14.3 | Checking the coolant level | 94 |
| | | Changing the glass fiber yarn filling | | | 14.4 | Draining the coolant 4 | |
| | | in the main silencer 4 | 61 | | 14.5 | Refilling with coolant 4 | |
| | 11.31 | Removing the fuel tank 4 | 62 | | 14.6 | Changing the coolant 4 | |
| | | Installing the fuel tank 4 | | | | | |
| | | Checking the chain for dirt | | 15 | TUNING | G THE ENGINE | 99 |
| | | Cleaning the chain | | | 15.1 | Checking throttle cable play | 99 |
| | | Checking the chain tension | | | 15.2 | Adjusting throttle cable play 4 | |
| | | Adjusting the chain tension | | | 15.3 | Carburetor tuning | |
| | | Checking the chain, rear sprocket, | | | 15.4 | Carburetor idle control | |
| | | engine sprocket, and chain guide | 67 | | | | - J <u>L</u> |

TABLE OF CONTENTS

| | 15.5 | Carburetor - adjusting the idle speed | 103 |
|-----|--------|--|-----|
| | 15.6 | Plug-in connector of ignition timing | 100 |
| | | map adjustment | 104 |
| | 15.7 | Changing the ignition timing map | 104 |
| | 15.8 | Checking the basic position of the shift lever | 104 |
| | 15.9 | Adjusting the basic position of the shift lever 4 | 104 |
| | 15.10 | Engine characteristic – auxiliary spring | 105 |
| | 15.11 | Engine characteristic – adjusting the auxiliary spring 4 | 105 |
| 16 | SERVIC | CE WORK ON THE ENGINE | 107 |
| | 16.1 | Emptying the carburetor float chamber | 107 |
| | 16.2 | Checking the gear oil level | 107 |
| | 16.3 | Changing the gear oil 4 | 108 |
| | 16.4 | Adding the gear oil 4 | 109 |
| 17 | CLEAN | ING, CARE | 111 |
| | 17.1 | Cleaning the motorcycle | 111 |
| 18 | STORA | GE | 113 |
| | 18.1 | Storage | 113 |
| | 18.2 | Preparing for use after storage | 114 |
| 19 | TROUB | LESHOOTING | 115 |
| 20 | TECHN | ICAL DATA | 117 |
| | 20.1 | Engine | 117 |
| | 20.2 | Engine tightening torques | 117 |
| | 20.3 | Carburetor | 119 |
| | 20.3.1 | Carburetor tuning | 119 |
| | 20.3.2 | Carburetor - basic setting for sandy surfaces | 120 |
| | 20.4 | Capacities | 120 |
| | 20.4.1 | | 120 |
| | 20.4.2 | Coolant | |
| | 20.4.3 | Fuel | 120 |
| | 20.5 | Chassis | 120 |
| | 20.6 | Electrical system | 121 |
| | 20.7 | Tires | 121 |
| | 20.8 | Fork | 121 |
| | 20.9 | Shock absorber | 122 |
| | 20.10 | | 122 |
| 21 | | ANCES | 124 |
| 22 | | ARY SUBSTANCES | 126 |
| 23 | | ARDS | 128 |
| 24 | | F ABBREVIATIONS | 129 |
| IND | ΞX | | 130 |

1.1 Symbols used

The meaning of specific symbols is described below.



Indicates an expected reaction (e.g. of a work step or a function).



Indicates an unexpected reaction (e.g. of a work step or a function).



All work marked with this symbol requires specialist knowledge and technical understanding. In the interest of your own safety, have these jobs performed by an authorized KTM workshop! Your motorcycle will be optimally cared for there by specially trained experts using the auxiliary tools required.



Indicates a page reference (more information is provided on the specified page).



Indicates information with more details or tips.



Indicates the result of a testing step.



Indicates a voltage measurement.



Indicates a current measurement.



Indicates the end of an activity, including potential rework.

1.2 Formats used

The typographical formats used in this document are explained below.

| Proprietary name | Indicates a proprietary name. |
|------------------|-------------------------------|
|------------------|-------------------------------|

Name® Indicates a protected name.

Brand™ Indicates a brand available on the open market.

Underlined terms Refer to technical details of the vehicle or indicate technical terms, which

are explained in the glossary.

2.1 Use definition – intended use

This vehicle has been designed and built to withstand the normal stresses and strains of racing. This vehicle complies with the currently valid regulations and categories of the top international motorsports organizations.



Info

Only operate this vehicle in closed-off areas remote from public road traffic.

2.2 Misuse

The vehicle must only be used as intended.

Dangers can arise for people, property and the environment through use not as intended.

Any use of the vehicle beyond the intended and defined use constitutes misuse.

Misuse also includes the use of operating and auxiliary fluids which do not meet the required specification for the respective use.

2.3 Safety advice

A number of safety instructions need to be followed to operate the product described safely. Therefore read this instruction and all further instructions included carefully. The safety instructions are highlighted in the text and are referred to at the relevant passages.



Info

Various information and warning labels are attached in prominent locations on the product described. Do not remove any information or warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

2.4 Degrees of risk and symbols



Danger

Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



Warning

Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



Caution

Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

Note

Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.



Note

Indicates a danger that will lead to environmental damage if the appropriate measures are not taken.

2.5 Tampering warning

Tampering with the noise control system is prohibited. Federal law prohibits the following acts or the causing thereof:

- 1 The removal or rendering inoperative by any person other than for purposes of servicing, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- 2 the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

- 1 Removal or puncturing of the main silencers, baffles, header pipes or any other components which conduct exhaust gases.
- 2 Removal or puncturing of parts of the intake system.
- 3 Lack of proper maintenance.
- 4 Replacing moving parts of the vehicle, or parts of the exhaust system or intake system, with parts other than those specified by the manufacturer.

2.6 Safe operation



Danger

Danger of accidents A rider who is not fit to ride poses a danger to him or herself and others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs or medication.
- Do not operate the vehicle if you are physically or mentally impaired.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.



Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, shock absorber, or brake system before the vehicle parts have cooled down.
- Let the vehicle parts cool down before you perform any work on the vehicle.

Only operate the vehicle when it is in perfect technical condition, in accordance with its intended use, and in a safe and environmentally compatible manner.

The vehicle should only be used by trained persons.

Have malfunctions that impair safety promptly eliminated by an authorized KTM workshop.

Adhere to the information and warning labels on the vehicle.

2.7 Protective clothing



Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as trousers and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.

In the interest of your own safety, KTM recommends that you only operate the vehicle while wearing protective clothing.

2.8 Work rules

Unless specified otherwise, the ignition must be turned off during all work (models with ignition lock, models with remote key) or the engine must be at a standstill (models without ignition lock or remote key).

Special tools are necessary for certain tasks. The tools are not a component of the vehicle, but can be ordered using the number in parentheses. Example: bearing puller (15112017000)

During assembly, use new parts to replace parts which cannot be reused (e.g. self-locking screws and nuts, expansion screws, seals, sealing rings, O-rings, pins, and lock washers).

In the case of certain screws, a screw adhesive (e.g. $\textbf{Loctite}^{\textcircled{@}}$) is required. Observe the manufacturer's instructions.

If thread locker (e.g., **Precote®**) has already been applied to a new part, do not apply any additional thread locker. After disassembly, clean the parts that are to be reused and check them for damage and wear. Change damaged or worn parts.

After completing a repair or service work, check the operating safety of the vehicle.

2.9 Environment

If you use your motorcycle responsibly, you can ensure that problems and conflicts do not occur. To protect the future of the motorcycle sport, make sure that you use your motorcycle legally, display environmental consciousness, and respect the rights of others.

When disposing of used oil, other operating and auxiliary fluids, and used components, comply with the laws and regulations of the respective country.

Because motorcycles are not subject to the EU regulations governing the disposal of used vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. Your authorized KTM dealer will be glad to advise you.

2.10 Owner's Manual

It is important that you read this Owner's Manual carefully and completely before making your first trip. The Owner's Manual contains useful information and many tips on how to operate, handle, and service your motorcycle. Only then will you find out how to customize the vehicle ideally for your own use and how you can protect yourself from injury.

Keep the Owner's Manual in an accessible place to enable you to refer to it as needed.

If you would like to know more about the vehicle or have questions on the material you read, please contact an authorized KTM dealer.

The Owner's Manual is an important component of the vehicle and must be handed over to the new owner if the vehicle is sold.

The Owner's Manual is also available for download from your authorized KTM dealer and on the KTM website. International KTM Website: http://www.ktm.com

The work prescribed in the service schedule must only be carried out in an authorized KTM workshop and confirmed in the **KTM Dealer.net**, as otherwise all warranty claims will be void. Damage or secondary damage caused by tampering with and/or conversions on the vehicle are not covered by the manufacturer warranty.

3.2 Fuel, auxiliary substances



Note

Environmental hazard Improper handling of fuel is a danger to the environment.

Do not allow fuel to enter the groundwater, the soil, or the sewage system.

Use fuels and auxiliary substances in accordance with the Owner's Manual and specification.

3.3 Spare parts, accessories

For your own safety, only use spare parts and accessory products that are approved and/or recommended by KTM and have them installed by an authorized KTM workshop. KTM accepts no liability for other products and any resulting damage or loss.

Certain spare parts and accessory products are specified in parentheses in the descriptions. Your authorized KTM dealer will be glad to advise you.

The current **KTM PowerParts** for your vehicle can be found on the KTM website.

International KTM Website: http://www.ktm.com

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the Owner's Manual. An incorrect suspension setting can lead to damage and breakage of chassis components.

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can result in significantly increased wear of components, such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

It is imperative that you adhere to the stipulated run-in times and service intervals. If you observe these exactly, you will ensure a much longer service life for your motorcycle.

The relevant mileage or time interval is whichever occurs first.

3.5 Figures

The figures contained in the manual may depict special equipment.

In the interest of clarity, some components may be shown disassembled or may not be shown at all. It is not always necessary to disassemble the component to perform the activity in question. Please follow the instructions in the text.

3.6 Customer service

Your authorized KTM dealer will be happy to answer any questions you may have on your vehicle and KTM.

A list of authorized KTM dealers can be found on the KTM website.


International KTM Website: http://www.ktm.com

4.1 View of vehicle, front left (example)




- 1 Hand brake lever (p. 14)
- 2 Clutch lever (p. 14)
- 3 Air filter box cover
- 4 Plug-in stand
- **5** Shift lever (p. 16)
- **6** Choke (p. 16)
- 7 Fuel tap

4.2 View of vehicle, rear right (example)




- 1 Seat
- 2 Fuel tank filler cap
- 3 Switch-off button (p. 14)
- 4 Throttle grip (p. 14)
- **5** Kick starter lever (p. 17)
- 6 Foot brake lever (p. 17)
- **7** Shock absorber compression adjustment
- 8 Shock absorber rebound adjustment
- **9** Level viewer for brake fluid, rear

5.1 Vehicle identification number




The vehicle identification number **1** is stamped on the right side of the steering head.

5.2 Type label




The type label 1 is fixed to the front of the steering head.

5.3 Engine number




The engine number **1** is stamped on the left side of the engine under the engine sprocket.

5.4 Fork part number




The fork part number **1** is stamped on the inside of the axle clamp.

5.5 Shock absorber article number




Shock absorber article number 1 is stamped on the top of the shock absorber above the adjusting ring towards the engine side.

6.1 Clutch lever




Clutch lever **1** is fitted on the handlebar on the left. The clutch is activated hydraulically and adjusts itself automatically.

6.2 Hand brake lever




Hand brake lever **1** is fitted on the right side of the handlebar. The front brake is engaged using the hand brake lever.

6.3 Throttle grip



Throttle grip **1** is fitted on the right side of the handlebar.

6.4 Switch-off button



Switch-off button 1 is fitted on the left side of the handlebar.

Possible states

- The switch-off button

 is in the basic position In this
 position, the ignition circuit is closed and the engine can be
 started
- The switch-off button ⋈ is pressed In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.

6.5 Opening fuel tank filler cap



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.



Note


Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



Turn fuel tank filler cap 1 counterclockwise and lift it off.

6.6 Closing the fuel tank filler cap




 Mount fuel tank filler cap 1 and turn it clockwise until the fuel tank is tightly closed.



Info

Route fuel tank breather hose **2** without kinks.

6.7 Fuel tap



The fuel tap is on the left side of the fuel tank.

Open or close the fuel supply to the carburetor using tap handle
on the fuel tap.

Possible states

- Fuel supply closed **OFF** Fuel cannot flow from the fuel tank to the carburetor.
- Open fuel supply **ON** Fuel can flow from the fuel tank to the carburetor. The fuel tank empties completely.

6.8 Choke



Choke ① is fitted on the left side of the carburetor.

Activating the choke function frees a drill hole in the carburetor through which the engine can draw extra fuel. This results in a richer fuel-air mixture, which is needed for a cold start.




Info

If the engine is warm, the choke function must be deactivated.

Possible states

- Choke function activated The choke lever is pulled out to the stop.
- Choke function deactivated The choke lever is pushed in to the stop.


6.9 Shift lever



Shift lever 1 is mounted on the left of the engine.

The gear positions can be seen in the photograph. The neutral or idle position is between the first and second gears.

6.10 Kick starter lever




Kick starter lever **1** is fitted on the right side of the engine. The kick starter lever can be swiveled.



Info


Before riding, swing the kick starter lever inwards towards the engine.

6.11 Foot brake lever



Foot brake lever **1** is located in front of the right footrest. The foot brake lever is used to activate the rear brake.

6.12 Plug-in stand



The holder for the plug-in stand **1** is the left side of the wheel spindle.

The plug-in stand is used to park the motorcycle.


The plug-in stand is used as a fork locker when transporting the motorcycle.



Info

Remove the plug-in stand before riding.

6.13 Service hour counter



The service hour counter 1 is fitted in front of the handlebar. It shows the total number of service hours of the engine. The service hour counter begins counting when the engine is started and stops when the engine is switched off.



Info

The value indicated by the service hour counter cannot be cleared or adjusted.

7.1 Advice on preparing for first use



Danger

Danger of accidents A rider who is not fit to ride poses a danger to him or herself and others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs or medication.
- Do not operate the vehicle if you are physically or mentally impaired.



Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as trousers and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.



Warning

Danger of crashing Different tire tread patterns on the front and rear wheel impair the handling characteristic.

Different tire tread patterns can make the vehicle significantly more difficult to control.

- Make sure that only tires with a similar tire tread pattern are fitted to the front and rear wheel.



Warning

Danger of accidents An unadapted riding style impairs the handling characteristic.

- Adapt your riding speed to the road conditions and your riding ability.



Warning

Danger of accidents The vehicle is not designed to carry passengers.

- Do not ride with a passenger.



Warning

Danger of accidents The brake system fails in the event of overheating.

If the foot brake lever is not released, the brake linings drag continuously.

- Take your foot off the foot brake lever when you are not braking.



Warning

Danger of accidents Total weight and axle loads influence the handling characteristic.

- Do not exceed the maximum permissible overall weight or the axle loads.



Warning

Risk of misappropriation People who act without authorization endanger themselves and others.

- Do not leave the vehicle unattended if the engine is running.
- Protect the vehicle against access by unauthorized persons.



Info

When using your motorcycle, remember that others may feel disturbed by excessive noise.

- Make sure that the pre-sales inspection work has been carried out by an authorized KTM workshop.
 - ✓ You will receive a delivery certificate when the vehicle is handed over.
- Before riding for the first time, read the entire Owner's Manual carefully.
- Get to know the controls.
- Adjust the basic position of the clutch lever. (
 p. 72)
- Adjust the basic position of the hand brake lever. (p. 75)

- Adjust the basic position of the foot brake lever. ♣ (💷 p. 81)
- Get used to the handling characteristics of the motorcycle on a suitable surface before undertaking more challenging trips.



Info

Your motorcycle is not approved for use on public roads.

When off road, it is recommended that you are accompanied by another person on another vehicle so that you can help each other.

- Try also to ride as slowly as possible and in a standing position to get a better feel for the motorcycle.
- Do not make any off-road trips that exceed your ability and experience.
- Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.
- Do not take luggage along.
- Do not exceed the maximum permissible weight and the maximum permissible axle loads.

Guideline

| I | Maximum permissible overall weight | 335 kg (739 lb.) |
|---|-------------------------------------|------------------|
| П | Maximum permissible front axle load | 145 kg (320 lb.) |
| П | Maximum permissible rear axle load | 190 kg (419 lb.) |



Info

The spoke tension must be checked after half an hour of operation.

Run in the engine. (
 p. 20)

7.2 Running in the engine

During the running-in phase, do not exceed the specified engine performance.

Guideline

| Maximum engine performance | |
|------------------------------------|---------|
| During the first 3 operating hours | < 70 % |
| During the first 5 operating hours | < 100 % |

Avoid fully opening the throttle!

7.3 Preparing the vehicle for difficult operating conditions



Info

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy circuits/surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

- Prepare air filter box cover for securing. ◄ (□ p. 60)
- Clean the air filter and air filter box. 4 (
 p. 59)



Info

Check the air filter approx. every 30 minutes.

Check the electrical connector for humidity and corrosion and to ensure it is firmly seated.

- » If humidity, corrosion, or damage is found:
 - Clean and dry the connector, or change it if necessary.

Difficult operating conditions are:

- Rides on dry sand. (p. 21)
- Rides on wet sand. (p. 22)
- Rides on wet and muddy circuits. (p. 24)
- Riding at high temperatures or slow riding. (
 p. 24)
- Riding at low temperatures and in snow. (p. 25)

7.4 Preparing the vehicle for riding on dry sand



Check the radiator cap.

Value on the radiator cap 1.8 bar (26 psi)

» If the indicated value does not correspond to the setpoint value:



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.
- Change the radiator cap.
- Mount the air filter dust cover.

Air filter dust cover (79006920000)





Info

Observe the fitting instructions for $\mbox{KTM PowerParts}.$




Mount the air filter sand cover.

Air filter sand cover (79006922000)



Info

Observe the fitting instructions for **KTM PowerParts**.



- Adjust the carburetor jetting and setting.



Info

Your authorized KTM workshop can recommend the right carburetor tuning.



- Clean the chain.

Chain cleaner (p. 126)

- Mount the steel sprocket.
- Grease the chain.

Universal oil spray (🕮 p. 127)

- Clean the radiator fins.
- Straighten the bent radiator fins carefully.

Condition

Regular use in sand

- Change the piston every 10 operating hours.

7.5 Preparing the vehicle for riding on wet sand



Check the radiator cap.

Value on the radiator cap 1.8 bar (26 psi)

If the indicated value does not correspond to the setpoint value:

Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.
- Change the radiator cap.
- Mount the air filter rain cover.

Air filter rain cover (79006921000)



Info

Observe the fitting instructions for KTM PowerParts.




Adjust the carburetor jetting and setting.



Info

Your authorized KTM workshop can recommend the right carburetor tuning.



- Clean the chain.

Chain cleaner (p. 126)

- Mount the steel sprocket.
- Grease the chain.

Universal oil spray (🕮 p. 127)

- Clean the radiator fins.
- Straighten the bent radiator fins carefully.

Condition

Regular use in sand

- Change the piston every 10 operating hours.



7.6 Preparing the vehicle for riding on wet and muddy circuits




Mount the air filter rain cover.

Air filter rain cover (79006921000)



Info

Observe the fitting instructions for **KTM PowerParts**.



Adjust the carburetor jetting and setting.



Info

Your authorized KTM workshop can recommend the right carburetor tuning.



- Mount the steel sprocket.
- Clean the motorcycle. (
 p. 111)
- Straighten the bent radiator fins carefully.

7.7 Preparing vehicle for high temperatures or slow riding



- Check the radiator cap.

| Value on the radiator cap | 1.8 bar (26 psi) |
|---------------------------|------------------|
| | |

» If the indicated value does not correspond to the setpoint value:

Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.
- Change the radiator cap.
- Adjust the secondary drive to the road conditions.



Info

The engine oil heats up quickly when the clutch is operated frequently due to an excessively high secondary ratio.

Clean the chain.

Chain cleaner (🕮 p. 126)

- Clean the radiator fins.
- Straighten the bent radiator fins carefully.
- Check the coolant level. (p. 94)

600868-01

7.8 Preparing the vehicle for low temperatures or snow




Mount the air filter rain cover.

Air filter rain cover (79006921000)



Info

Observe the fitting instructions for $\mbox{KTM PowerParts}.$



Adjust the carburetor jetting and setting.



Info


Your authorized KTM workshop can recommend the right carburetor tuning.

8.1 Checks and maintenance measures when preparing for use



Info

Before every trip, check the condition of the vehicle and ensure that it is safe to operate. The vehicle must be in perfect technical condition when it is being operated.



- Check the gear oil level. (p. 108)
- Check the front brake fluid level. (p. 76)
- Check the rear brake fluid level. (p. 82)

- Check that the brake system is functioning properly.

- Check the chain, rear sprocket, engine sprocket, and chain guide. (p. 67)
- Check the tire condition. (p. 91)
- Check the spoke tension. (
 p. 92)



Info

The spoke tension must be checked regularly as incorrect spoke tension will strongly impair riding safety.

- Bleed the fork legs. (
 p. 44)
- Check the air filter.
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check all screws, nuts, and hose clamps regularly for tightness.
- Check the fuel level.

_

8.2 Starting



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.

Note

Engine damage High revving speed with a cold engine negatively impacts the lifespan of the engine.

Always run the engine warm at a low speed.



Info

If the motorcycle is unwilling to start, the cause can be old fuel in the float chamber. The flammable elements of the fuel evaporate after a long time of standing.

If the float chamber is filled with fresh fuel, the engine starts immediately.

The motorcycle has been out of use for more than 1 week

- Turn tap handle of the fuel tap to the **ON** position.
 - ✓ Fuel can flow from the fuel tank to the carburetor.
- Remove the plug-in stand.
- Shift the transmission into neutral.

Condition

The engine is cold

- Pull the choke lever out as far as possible.
- Press the kick starter lever robustly through its full range.



Info

Do not open the throttle.

8.3 Starting off



Info

The plug-in stand must be removed before riding.

When you are riding, the side stand must be folded up and secured with the rubber strap.

 Pull the clutch lever, shift into first gear, release the clutch lever slowly and at the same time open the throttle carefully.

8.4 Shifting, riding



Warning

Danger of accidents If you change down at high engine speed, the rear wheel blocks and the engine races.

- Do not change into a low gear at high engine speed.



Info

If you hear unusual noises while riding, stop immediately, switch off the engine, and contact an authorized KTM workshop.

First gear is used for starting off and for steep inclines.

- Shift into a higher gear when conditions allow (incline, road situation, etc.). To do so, release the throttle
 while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever and open the
 throttle.
- If the choke function has been activated, deactivate it after the engine has warmed up.
- After reaching maximum speed by fully opening the throttle grip, turn the throttle back so it is ¾ open. This
 will barely reduce the speed, but fuel consumption will be considerably lower.
- Always open the throttle only as much as the engine can handle abrupt throttle opening increases fuel consumption.
- To shift down, apply the brakes and close the throttle at the same time.

- Pull the clutch lever and shift into a lower gear, release the clutch lever slowly, and either open the throttle or shift again.
- Switch off the engine if running at idle speed or stationary for a long time. Guideline

≥ 2 min

- Avoid frequent or lengthy slipping of the clutch. This causes the gear oil, engine and cooling system to heat
- Ride at a low engine speed instead of at a high engine speed with a slipping clutch.

8.5 Applying the brakes



Warning

Danger of accidents Excessively forceful application of the brakes blocks the wheels.

Adjust application of the brakes to the respective riding situation and riding surface conditions.



Warning

Danger of accidents A spongy pressure point on the front or rear brake reduces braking efficiency.

- Check the brake system and do not continue riding until the problem is eliminated. (Your authorized KTM workshop will be glad to help.)



Warning

Danger of accidents Moisture and dirt impair the brake system.

- Brake carefully several times to dry out and remove dirt from the brake linings and the brake discs.
- On sandy, wet, or slippery surfaces, use the rear brake mostly if possible.
- Always finish braking before you go into a bend. Change down to a lower gear appropriate to your road speed.
- Use the braking effect of the engine on long downhill stretches. Change down one or two gears, but do not over-rev the engine. You will have to apply the brakes far less frequently as a result and the brake system will not overheat.

8.6 Stopping, parking



Warning

Risk of misappropriation People who act without authorization endanger themselves and others.

- Do not leave the vehicle unattended if the engine is running.
- Protect the vehicle against access by unauthorized persons.



Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, shock absorber, or brake system before the vehicle parts have cooled down.
- Let the vehicle parts cool down before you perform any work on the vehicle.

Note

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near to materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.

Note

Material damage The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.
- Apply the brakes on the motorcycle.
- Shift the transmission to neutral position.
- Press and hold the switch-off button \boxtimes while the engine is idling until the engine stops.
- Turn tap handle of the fuel tap to the **OFF** position.
- Rest the vehicle on the plug-in stand.

8.7 **Transporting**

Note


Danger of damage The parked vehicle can roll away or fall over.

Park the vehicle on a firm and level surface.

Note

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near to materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.





Switch off the engine.

Mount plug-in stand on the fork legs.

Plug-in stand (79029094000)

Info


The plug-in stand is included.

Make sure the brake line runs in front of the plug-in stand and does not become wedged.

Use tension belts or other suitable devices to secure the motorcycle against falling over or rolling away.



Only tighten the tension belts to the point that the plug-in stand is in contact with the fender and tires. Pay attention to the alignment of the plug-in stand to the fender.



8.8 Refueling



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.


- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.



Note

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Switch off the engine.
- Open fuel tank filler cap. (p. 15)
 - Fill the fuel tank with fuel up to measurement **A**. Guideline

| Measurement of A | 35 mm | (1.38 in) |
|-----------------------------------|------------------------|--|
| Total fuel tank capacity, approx. | 7.5 I (1.98 US gal) | Super unleaded (95 octane) mixed with 2-stroke engine oil (1:60) (p. 125) |

Engine oil, 2-stroke (🕮 p. 124) Close the fuel tank filler cap. (p. 15)

9.1 Additional information

Any further work that results from the compulsory work or from the recommended work must be ordered separately and invoiced separately.

Different service intervals may apply in your country, depending on the local operating conditions. Individual service intervals and scopes may change in the course of technical developments. The most up-to-date service schedule can always be found on KTM Dealer.net. Your authorized KTM dealer will be happy to advise you.

9.2 Required work

| | | | aft | er ev | ery r | ace |
|--|---------|-------|-------|-------|-------|-----|
| E | very 4 | 10 op | erati | ng ho | ours | |
| Every | 20 op | erati | ng ho | ours | | |
| Every 10 o | perati | ng ho | urs | | | |
| After 5 operat | ting ho | ours | | | | |
| After 1 operating | hour | | | | | |
| Change the gear oil. ◀ (ՀՀ p. 108) | | 0 | | • | • | |
| Check the front brake linings. (🕮 p. 78) | | | • | • | • | • |
| Check the brake linings of the rear brake. (🕮 p. 84) | | | • | • | • | • |
| Check the brake discs. (p. 75) | | | • | • | • | • |
| Check the brake lines for damage and leakage. | | | • | • | • | • |
| Check the rear brake fluid level. (p. 82) | | | • | • | • | • |
| Check the free travel of the foot brake lever. (p. 81) | | | • | • | • | • |
| Check the frame. ◀ (🕮 p. 70) | | | • | • | • | • |
| Check the link fork. ◀ (의 p. 70) | | | • | • | • | • |
| Checking the fork bearing for play. ◀ | | | | • | • | |
| Checking the shock absorber heim joint for play. | | | • | • | • | • |
| Check the shock absorber linkage. ◀ | | | • | • | • | • |
| Check the tire condition. (🕮 p. 91) | 0 | | • | • | • | • |
| Check tire pressure. (🕮 p. 91) | 0 | | • | • | • | • |
| Check the wheel bearing for play. | | | • | • | • | • |
| Check the wheel hubs. 4 | | | • | • | • | • |
| Check the rim run-out. | 0 | | • | • | • | • |
| Check the spoke tension. (🗐 p. 92) | 0 | | • | • | • | • |
| Check the chain, rear sprocket, engine sprocket, and chain guide. (p. 67) | | | • | • | • | • |
| Check the chain tension. (🕮 p. 65) | 0 | | • | • | • | • |
| Grease all moving parts (e.g., hand lever, chain,) and check for smooth operation. ◀ | | | • | • | • | • |
| Check/correct the fluid level of the hydraulic clutch. (| | | • | • | • | • |
| Check the front brake fluid level. (p. 76) | | | • | • | • | • |
| Check the free travel of the hand brake lever. (p. 75) | | | • | • | • | • |
| Check steering head bearing play. (🕮 p. 50) | 0 | | • | • | • | • |
| Change the spark plug and spark plug connector. 🔏 | | | | • | • | |
| Check all hoses (e.g. fuel, cooling, bleeder, drainage, etc.) and sleeves for cracking, leaks, and incorrect routing. \blacktriangleleft | 0 | | • | • | • | • |
| Check the antifreeze and coolant level. (p. 93) | 0 | | • | • | • | • |
| Check the cables for damage and for routing without kinks. ◀ | | | • | • | • | • |

- One-time interval
- Periodic interval

9.3 Recommended work

| Every 40 operating hours | | | | | ours |
|--|-------|-------|------|---|------|
| After 20 operating hours / Every 20 operating hours | | | | | |
| After 10 operating hours / Every 10 op | erati | ng ho | ours | | |
| every 4 | 8 moi | nths | | | |
| every 12 mo | nths | | | | |
| Change the front brake fluid. 🌂 | • | • | | | |
| Change the rear brake fluid. 🔏 | • | • | | | |
| Change the hydraulic clutch fluid. ◀ (ՀՀ) p. 73) | • | • | | | |
| Lubricate the steering head bearing. ◀ (의 p. 51) | • | • | | | |
| Service the fork. | | | 0 | | |
| Perform the shock absorber service. 4 | | | | 0 | |
| Check/adjust the carburetor components. ◂ | • | • | | | • |
| Change the needle jet. 4 | • | • | | | • |
| Change the coolant. ◀ (의 p. 97) | | • | | | |
| Perform minor engine service. (Check the reed valve housing, reed valve, and intake flange. Check the clutch. Under difficult operating conditions: Change the piston and check the cylinder and Z dimension.) | | | • | • | • |
| Perform the intermediate engine service. (Change the piston and check the cylinder and Z dimension. Check the exhaust control for functioning and smooth operation.) | | | | • | • |
| Perform major engine service including removing and installing the engine. (Change the connecting rod, conrod bearing, and crank pin. Check the transmission and shift mechanism. Change all engine bearings.) | | | | | • |


- One-time interval
- Periodic interval

10.1 Checking the basic chassis setting with rider's weight

i

Info

When adjusting the basic chassis setting, first adjust the shock absorber and then the fork.



- For optimal motorcycle riding characteristics and to avoid damage to forks, shock absorbers, link fork and frame, the basic settings of the suspension components must match the rider's weight.
- As delivered, KTM offroad motorcycles are adjusted for an average rider's weight (with full protective clothing).
 Guideline

| Standard rider weight | 75 85 kg (165 |
|-----------------------|---------------|
| | 187 lb.) |

- If the rider's weight is above or below this range, the basic setting of the suspension components must be adjusted accordingly.
- Small weight differences can be compensated by adjusting the spring preload, but in the case of large weight differences, the springs must be replaced.

10.2 Air suspension XACT 5448



Air suspension **WP Suspension XACT 5448** is used in the fork. In this system, suspension is located in the left fork leg and damping in the right fork leg.

As fork springs are no longer required, a significant weight advantage is achieved when compared to conventional forks. The response on slightly uneven surfaces is significantly improved. In normal driving mode, suspension is provided exclusively by an air cushion. A steel spring is located in the left fork leg as an end stop.



Info

If the fork is frequently overloaded, then the air pressure in the fork must be increased to avoid damage to the fork and frame

The air pressure in the fork can be quickly adjusted to the rider's weight, surface conditions and the rider's preference using a fork airpump. The fork does not have to be dismantled. The time consuming mounting of harder or softer fork springs is not required. If the air chamber loses air due to a damaged seal, the fork will still not sag. In this case the air is retained in the fork. The suspension travel is maintained as far as possible. The damping becomes harder and the riding comfort reduces.

As with a conventional fork, the damping can be adjusted in rebound and compression stages.

The rebound adjuster is located at the lower end of the right fork leg.

The compression adjuster is located at the upper end of the right fork leg.

10.3 **Compression damping of the shock absorber**

The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed. High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed.

The high-speed compression adjuster has an effect, for example, when landing after a jump: the rear wheel suspension compresses quickly.

The low-speed compression adjuster has an effect, for example, when riding over long ground swells: the rear wheel suspension compresses slowly.

These two ranges can be adjusted separately, although the transition between high-speed and low-speed is gradual. Thus, modifications in the high-speed range affect the compression damping in the low-speed range and vice versa.

10.4 Adjusting the low-speed compression damping of the shock absorber



Caution


Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

Please follow the description provided. (Your authorized KTM workshop will be glad to help.)



Info

The effect of the low-speed compression adjuster can be seen in slow to normal compression of the shock



Turn adjusting screw 1 clockwise with a screwdriver as far as the last perceptible click.



Info

Do not loosen fitting 2!



Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

| Lowspeed compression damping | |
|------------------------------|-----------|
| Comfort | 17 clicks |
| Standard | 15 clicks |
| Sport | 13 clicks |



Info

Turn clockwise to increase the damping; turn counterclockwise to reduce the damping.

10.5 Adjusting the high-speed compression damping of the shock absorber



Caution


Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided. (Your authorized KTM workshop will be glad to help.)



Info

The effect of the high-speed compression adjuster can be seen in fast compression of the shock absorber.



Turn adjusting screw all the way clockwise with a socket wrench.



Info

Do not loosen fitting 2!

 Turn counterclockwise by the number of turns corresponding to the shock absorber type.

Guideline

| Highspeed compression damping | | |
|-------------------------------|-----------|--|
| Comfort 2.5 turns | | |
| Standard | 2 turns | |
| Sport | 1.5 turns | |



Info

Turn clockwise to increase the damping; turn counterclockwise to reduce the damping.


10.6 Adjusting the rebound damping of the shock absorber



Caution

Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

Please follow the description provided. (Your authorized KTM workshop will be glad to help.)



- Turn adjusting screw 1 clockwise up to the last perceptible click.
- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.


Guideline

| Rebound damping | und damping | |
|-----------------|-------------|--|
| Comfort | 17 clicks | |
| Standard | 15 clicks | |
| Sport | 13 clicks | |

Info

Turn clockwise to increase the damping; turn counterclockwise to reduce damping when the shock absorber rebounds.

10.7 Measuring the rear wheel dimension unloaded



Preparatory work

Raise the motorcycle with a lift stand. (p. 44)

Main work

Position the sag gage in the rear axle and measure the distance to marking SAG on the rear fender.

Sag gauge (00029090000)

Sag gage pin (00029990010)


Note down the value as dimension **A**.



Finishing work

Remove the motorcycle from the lift stand. (p. 44)

10.8 Checking the static sag of the shock absorber



- Hold the motorcycle upright with aid of an assistant.
- Measure the distance again between the rear axle and marking SAG on the rear fender using the sag gage.
- Note the value as dimension **B**.



Info


The static sag is the difference between measurements $\bf A$ and $\bf B$.

- Check the static sag.

Static sag 35 mm (1.38 in)

- » If the static sag is less or more than the specified value:
 - Adjust the spring preload of the shock absorber.
 (p. 38)

10.9 Checking the riding sag of the shock absorber



- Measure dimension ♠ of rear wheel unloaded. (♠ p. 36)
- With another person holding the motorcycle, the rider, wearing full protective clothing, sits on the seat in a normal sitting position (feet on footrests) and bounces up and down a few times.
 - ✓ The rear wheel suspension levels out.
- Another person again measures the distance between the rear axle and marking SAG on the rear fender using the sag gage.
- Note the value as dimension **6**.



Info

The riding sag is the difference between measurements $\bf A$ and $\bf C$.

Check riding sag.

Guideline

Riding sag 105 mm (4.13 in)

- » If the riding sag differs from the specified measurement:
 - Adjust the riding sag. ◄ (♠ p. 39)

10.10 Adjusting the spring preload of the shock absorber 4



Caution


Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

Please follow the description provided. (Your authorized KTM workshop will be glad to help.)



Info

Before changing the spring preload, make a note of the present setting, e.g., by measuring the spring length.



Preparatory work

- Raise the motorcycle with a lift stand. (
 p. 44)
- Remove the shock absorber. 🔌 (🕮 p. 53)
- After removing the shock absorber, clean it thoroughly.

Main work

- Loosen screw 1.
- Turn adjusting ring 2 until the spring is no longer under tension.

Hook wrench (90129051000)

- Measure the total spring length while the spring is not under tension
- Tension the spring by turning adjusting ring 2 to specified dimension A.

Guideline

Spring preload 7 mm (0.28 in)



Info

Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

- Tighten screw 1.

Guideline

| Screw, shock | M5 | 5 Nm (3.7 lbf ft) |
|--------------------|----|-------------------|
| absorber adjusting | | |
| ring | | |


Finishing work

- Install the shock absorber. ◀ (🕮 p. 54)
- Remove the motorcycle from the lift stand. (
 p. 44)

10.11 Adjusting the riding sag 🔦

Preparatory work

- Remove the shock absorber. 🔌 🕮 p. 53)
- After removing the shock absorber, clean it thoroughly.



Main worl

Choose and mount a suitable spring.

Guideline

| Spring rate | |
|--|---------------------|
| Weight of rider: 65 75 kg (143 165 lb.) | 39 N/mm (223 lb/in) |
| Weight of rider: 75 85 kg (165 187 lb.) | 42 N/mm (240 lb/in) |
| Weight of rider: 85 95 kg (187 209 lb.) | 45 N/mm (257 lb/in) |



Info

The spring rate is shown on the outside of the spring.

Finishing work


- Install the shock absorber. 🔌 🕮 p. 54)
- Remove the motorcycle from the lift stand. (
 p. 44)

10.12 Checking the basic setting of the fork



Info

For various reasons, no exact riding sag can be determined for the fork.



- Smaller differences in the rider's weight can be compensated for by the fork air pressure.
- However, if the fork frequently bottoms out (hard end stop on compression), the fork air pressure must be increased, within the specified values, to avoid damage to the fork and frame.
- If the fork feels unusually hard after extended periods of operation, the fork legs need to be bled.

•

10.13 Adjusting the fork air pressure



Warning

Danger of accident Modifications to the suspension setting may seriously alter the handling characteristic.

Extreme modifications to the suspension setting may cause a serious deterioration in the handling characteristic and overload components.


- Only make adjustments within the recommended range.
- Ride slowly to start with after making adjustments to get the feel of the new handling characteristic.



Info

Check or adjust the air pressure under the same conditions at the earliest 5 minutes after switching off the engine.

The air suspension is located in the left fork leg. The pressure and rebound damping is located in the right fork leg.



Preparatory work

Main work

- Remove protection cap 1
- Push together fork airpump 2 fully.

Fork airpump (79412966100)



Info

The fork airpump is included as part of the motorcycle's accessory pack.

- Connect the fork airpump to the left fork leg.
 - ✓ The fork airpump indicator switches on automatically.
 - A little air escapes from the fork leg when connecting.



Info

This is due to the volume of the hose and not due to a defect in the fork airpump or the fork.

Read the accompanying KTM PowerParts instructions.

Adjust the air pressure as specified.

Guideline

| Air pressure | 10.4 bar (151 psi) |
|--|--------------------|
| Gradual changing of the air pressure in steps of | 0.2 bar (3 psi) |
| Minimum air pressure | 7 bar (102 psi) |
| Maximum air pressure | 12 bar (174 psi) |



Info

Never adjust the air pressure to a value outside the stated range.

- Disconnect the fork airpump from the left fork leg.

- ✓ When disconnecting, excess pressure will escape from the hose – the fork leg itself does not lose any air.
- ✓ The fork airpump indicator switches off automatically after 80 seconds.
- Mount the protection cap.



Info

Only mount the protection cap by hand.

Finishing work

- Remove the motorcycle from the lift stand. (p. 44)

10.14 Adjusting the compression damping of the fork



Info

The hydraulic compression damping determines the fork suspension behavior.



Turn adjusting screw 1 clockwise all the way.



Info

Adjusting screw is located at the upper end of the right fork leg.

 Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

| Compression damping | |
|---------------------|-----------|
| Comfort | 17 clicks |
| Standard | 12 clicks |
| Sport | 7 clicks |



Info


Turn clockwise to increase damping; turn counterclockwise to reduce damping during compression.

10.15 Adjusting the rebound damping of the fork



Info

The hydraulic rebound damping determines the fork suspension behavior.



- Take off protection cap 1.
- Turn adjusting screw 2 clockwise all the way.



Info

Adjusting screw 2 is located at the lower end of the right fork leg.

 Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

| Rebound damping | |
|-----------------|-----------|
| Comfort | 23 clicks |
| Standard | 18 clicks |
| Sport | 13 clicks |




Info

Turn clockwise to increase the damping; turn counterclockwise to reduce damping when the shock absorber rebounds.

Mount protection cap 1.

•

10.16 Handlebar position



The holes on the handlebar supports are placed at a distance of $\bf A$ from the center.

Hole distance A 3.5 mm (0.138 in)

The handlebar can be mounted in 2 different positions. In this way, the handlebar can be mounted in the most comfortable position for the rider.

10.17 Adjusting the handlebar position 🔌



Warning


Danger of accidents A repaired handlebar poses a safety risk.

If the handlebar is bent or straightened, the material becomes fatigued. The handlebar may break as a result.

- Change the handlebar if the handlebar is damaged or bent.

Preparatory work

- Remove the handlebar cushion.



Remove screws

 Remove the handlebar clamp. Remove the handlebar and lay it to one side.



Info

Cover the components to protect them against damage. Do not kink the cables and lines.

- Remove screws 2. Take off handlebar supports 3.
- Position rubber bushings 4 and push through nuts 5 from below.
- Place the handlebar supports in the required position.



Info

The handlebar supports are longer and higher on one side.

Position the left and right handlebar supports evenly.

- Mount and tighten screws **2**.

Guideline

| Screw, handle- | M10 | 40 Nm (29.5 lbf ft) |
|----------------|-----|---------------------|
| bar support | | Loctite®243™ |

Position the handlebar.



Info

Make sure the cables and wiring are positioned correctly.

- Position the handlebar clamp.
- Mount screws 1 but do not tighten yet.
- First bolt the handlebar clamp with screws onto the longer, higher side of the handlebar supports so that both parts touch.
 Guideline

| Screw, handlebar | M8 | 20 Nm (14.8 lbf ft) |
|------------------|----|---------------------|
| clamp | | |

Tighten screws 1 evenly.

Guideline

| Screw, handlebar | M8 | 20 Nm (14.8 lbf ft) |
|------------------|----|---------------------|
| clamp | | |

Finishing work

- Mount the handlebar cushion.

_

11.1 Raising the motorcycle with a lift stand


Note

Material damage The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.



- Raise the motorcycle at the frame underneath the engine.

Lift stand (78129955100)

- ✓ Neither wheel is in contact with the ground.
- Secure the motorcycle against falling over.

11.2 Removing the motorcycle from the lift stand


Note

Material damage The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.



- Remove the motorcycle from the lift stand.
- Remove the lift stand.
- To park the motorcycle, insert plug-in stand 1 into the left side of the wheel spindle.




Info

Remove the plug-in stand before riding.

11.3 Bleeding the fork legs

Preparatory work



- Release bleeder screws 1.
 - ✓ Any excess pressure escapes from the interior of the fork.
- Tighten the bleeder screws.

Finishing work

- Remove the motorcycle from the lift stand. (p. 44)

11.4 Cleaning the dust boots of the fork legs

Preparatory work

Main work

Push dust boots of both fork legs downward.



Info

The dust boots remove dust and coarse dirt particles from the inside fork tubes. Over time, dirt can accumulate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.
- Clean and oil the dust boots and inner fork tubes of both fork legs.


Universal oil spray (🕮 p. 127)

- Press the dust boots back into their normal position.
- Remove excess oil.


Finishing work


- Install the fork protector. (
 p. 47)
- Remove the motorcycle from the lift stand. (p. 44)

_



11.5 Removing the fork legs 🔦





Preparatory work

- Raise the motorcycle with a lift stand. (p. 44)

Main work

- Remove screws 1 and take off the clamp.
- Remove screws 2 and take off the brake caliper.
- Allow the brake caliper and brake line to hang loosely to the side.




Info

Do not actuate the hand brake lever when the front wheel is removed.

- Loosen screws 3. Remove the left fork leg.
- Loosen screws 4. Remove the right fork leg.

11.6 Installing the fork legs 4




Main work

- Position the fork legs.
 - ✓ Air bleeder screw of the right fork leg is positioned to the front.
 - ✓ Valve ♠ of the left fork leg faces the front.



Info

Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp. The air suspension is located in the left fork leg. The pressure and rebound damping is located in the right fork leg.



- Tighten screws **2**.


Guideline

| Screw, top triple | M8 | 17 Nm (12.5 lbf ft) |
|-------------------|----|---------------------|
| clamp | | |

– Tighten screws 🔞.

Guideline

| Screw, bottom triple | M8 | 12 Nm (8.9 lbf ft) |
|----------------------|----|--------------------|
| clamp | | |



- Position the brake caliper. Mount and tighten screws **4**. Guideline


| Screw, front | M8 | 25 Nm (18.4 lbf ft) |
|---------------|----|---------------------|
| brake caliper | | Loctite®243™ |

 Position the brake line and the clamp. Mount and tighten screws 5.

Finishing work


Removing the fork protector

11.7



- Remove screws 1. Remove the clamp.
- Remove screws 2. Take off the left fork protector.
- Remove screws 3. Take off the right fork protector.

11.8 Installing the fork protector



 Position the fork protection on the left fork leg. Mount and tighten screws ①.

Guideline

| Remaining screws, | M6 | 10 Nm (7.4 lbf ft) |
|-------------------|----|--------------------|
| chassis | | |

- Position the brake line and clamp. Mount and tighten screws **2**.
- Position the fork protector on the right fork leg. Mount and tighten screws 3.

Guideline

| Remaining screws, | M6 | 10 Nm (7.4 lbf ft) |
|-------------------|----|--------------------|
| chassis | | |

11.9 Removing the lower triple clamp 🔌

Preparatory work

- Raise the motorcycle with a lift stand. (p. 44)
- Remove the front wheel. ♣ (♠ p. 87)

- Remove front fender. (
 p. 52)
- Remove the handlebar cushion.

11 SERVICE WORK ON THE CHASSIS





Main work

- Remove screw 1.
 - Remove screw 2.
- Take off the upper triple clamp with the handlebar and hang them to the side.




Info

Cover the components to protect them against damage. Do not kink the cables and lines.

- Remove O-ring 3. Remove protective ring 4.
- Take off the lower triple clamp with the steering stem.
- Remove the upper steering head bearing.

11.10 Installing the lower triple clamp 4



Main work


 Clean the bearing and sealing elements, check for damage, and grease.

High viscosity grease (p. 126)

- Insert the lower triple clamp with the steering stem. Mount upper steering head bearing.
- Check whether upper steering head seal 1 is correctly positioned.
- Slide on protective ring 2 and O-ring 3.



- Position the upper triple clamp with the handlebar.
- Mount screw 4, but do not tighten yet.



- Position the fork legs.
 - ✓ Air bleeder screw **5** of the right fork leg is positioned to
 - ✓ Valve ♠ of the left fork leg faces the front.



Info

The air suspension **AER** valve is located in the left fork


Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp.



Tighten screws **6**.

Guideline


| Screw, bottom triple | M8 | 12 Nm (8.9 lbf ft) |
|----------------------|----|--------------------|
| clamp | | |



Tighten screw 4.

Guideline


| Screw, top steering | M20x1.5 | 12 Nm (8.9 lbf ft) |
|---------------------|---------|--------------------|
| head | | |



Mount and tighten screw 7.

Guideline


| Screw, top | M8 | 20 Nm (14.8 lbf ft) |
|---------------|----|---------------------|
| steering stem | | Loctite®243™ |



Tighten screws 8.

Guideline

| Screw, top triple | M8 | 17 Nm (12.5 lbf ft) |
|-------------------|----|---------------------|
| clamp | | |



Position the brake caliper. Mount and tighten screws **9**.
 Guideline

| Screw, front | M8 | 25 Nm (18.4 lbf ft) |
|---------------|----|---------------------|
| brake caliper | | Loctite®243™ |

- Position the brake line and the clamp. Mount and tighten screws **10**.

Finishing work

- Check that the wiring harness, throttle cables, and brake and clutch lines can move freely and are routed correctly.
- Install front fender. (
 p. 52)
- Install the front wheel. (p. 88)
- Remove the motorcycle from the lift stand. (p. 44)
- Mount the handlebar cushion.

11.11 Checking steering head bearing play



Warning


Danger of accidents Incorrect steering head bearing play impairs the handling characteristic and damages components.

 Correct incorrect steering head bearing play immediately. (Your authorized KTM workshop will be glad to help.)



Info

If the vehicle is operated for a lengthy period with play in the steering head bearing, the bearings and the bearing seats in the frame can become damaged over time.



Preparatory work

- Raise the motorcycle with a lift stand. (p. 44)

Main work

H01167-01

 Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

Play should not be detectable on the steering head bearing.

- If there is detectable play:
 - Adjust steering head bearing play. 🔌 🕮 p. 51)
- Move the handlebar to and fro over the entire steering range.

It must be possible to move the handlebar easily over the entire steering range. There should be no detectable detent positions.

- » If detent positions are detected:
 - Adjust steering head bearing play. 🔌 🕮 p. 51)
 - Check the steering head bearing and change if necessary.

Finishing work

- Remove the motorcycle from the lift stand. (p. 44)

11.12 Adjusting steering head bearing play &

Preparatory work

- Raise the motorcycle with a lift stand. (p. 44)
- Remove the handlebar cushion.

Main work

- Loosen screws 1.
- Remove screw 2.
- Loosen and retighten screw 3.

Guideline

| Screw, top steering | M20x1.5 | 12 Nm (8.9 lbf ft) |
|---------------------|---------|--------------------|
| head | | |

- Using a plastic hammer, tap lightly on the upper triple clamp to avoid stresses.
- Tighten screws 1.

Guideline

| Screw, top triple | M8 | 17 Nm (12.5 lbf ft) |
|-------------------|----|---------------------|
| clamp | | |

Mount and tighten screw 2.


Guideline

| Screw, top | M8 | 20 Nm (14.8 lbf ft) |
|---------------|----|---------------------|
| steering stem | | Loctite®243™ |

Finishing work

- Check steering head bearing play. (p. 50)
- Remove the motorcycle from the lift stand. (p. 44)
- Mount the handlebar cushion.

11.13 Lubricating the steering head bearing 4



- Install the lower triple clamp. 🔌 🕮 p. 48)



Info


The steering head bearing is cleaned and lubricated in the course of removal and installation.

11.14 Removing the start number plate




- Remove screw 1.
- Disconnect the brake line at the start number plate. Take off the start number plate.

11.15 Installing the start number plate



- Connect the brake line at the start number plate.
- Position the start number plate.
 - ✓ The holding lugs engage in the fender.
- Mount and tighten screw 1.

11.16 Removing front fender




Preparatory work

Main work

Remove screws 1 and 2. Remove front fender.

11.17 Installing front fender



Main work


Position front fender. Mount and tighten screws 1 and 2.
 Guideline

| Remaining screws, | M6 | 10 Nm (7.4 lbf ft) |
|-------------------|----|--------------------|
| chassis | | |

Finishing work

- Install the start number plate. (p. 52)


11.18 Removing the shock absorber 🔦



Preparatory work

Raise the motorcycle with a lift stand. (p. 44)

- Remove the cable ties.
- Remove screws 1 with the washers.
- Remove screw 2.
- Take off the left frame protector.
- Push the right frame protector to the front and take off at the




- Remove screw 3.
- Remove fitting **4**.



V01525-10


Raise the wheel slightly to be able to remove the screws more easily.



- Press angle lever **5** toward the rear.
- Press linkage lever 6 downward.



Remove screws 7 and pull foot brake cylinder off the push



- Remove the connecting link of the chain.

Info

Cover the components to protect them against damage.

Take off the chain.


11 SERVICE WORK ON THE CHASSIS



- Remove nut 8 and pull out the swingarm pivot.
- Push the link fork back and secure it against falling over.



- Hold the shock absorber and remove screw **9**.



Remove the shock absorber carefully at the bottom.

11.19 Installing the shock absorber 4



Main work


 Carefully position the shock absorber into the vehicle from the bottom.



Mount and tighten screw ①.

Guideline

| Screw, top | M10 | 60 Nm (44.3 lbf ft) |
|----------------|-----|---------------------|
| shock absorber | | Loctite®2701™ |





Position the link fork and mount the swingarm pivot.

Info


Pay attention to flat area **A**.

Mount and tighten nut **2**. Guideline

| Nut, fork pivot | M16x1.5 | 100 Nm |
|-----------------|---------|---------------|
| | | (73.8 lbf ft) |

- Mount the chain.
- Connect the chain with the connecting link.

The closed side of the chain joint lock must face in the direction of travel.





Position the foot brake cylinder.


✓ Push rod **3** engages in the foot brake cylinder.

✓ The dust boot is correctly positioned.

Mount and tighten screws **4**.

Guideline

| Remaining screws, | M6 | 10 Nm (7.4 lbf ft) |
|-------------------|----|--------------------|
| chassis | | |



- Position the angle lever and linkage lever.
- Mount and tighten fitting **5**.

Guideline

| Nut, linkage lever on | M14x1.5 | 60 Nm (44.3 lbf ft) |
|-----------------------|---------|---------------------|
| angle lever | | |



K00864-10

Info

Pay attention to flat area **B**.

Mount and tighten screw **6**.

Guideline


| Screw, bottom | M10 | 60 Nm (44.3 lbf ft) |
|----------------|-----|---------------------|
| shock absorber | | Loctite®2701™ |



Info

Raise the wheel slightly to be able to mount screw more easily.

11 SERVICE WORK ON THE CHASSIS



- Position the left frame protector.
- Insert the right frame protector from below and push it to the rear
- Mount and tighten screws with the washers.
 Guideline

| Screw, frame protec- | M5 | 3 Nm (2.2 lbf ft) |
|----------------------|----|-------------------|
| tor | | |

- Mount and tighten screw 8 .

Guideline

| Screw, frame protec- | M5 | 3 Nm (2.2 lbf ft) |
|----------------------|----|-------------------|
| tor | | |

- Mount the new cable ties.


Finishing work

Remove the motorcycle from the lift stand. (
 p. 44)

11.20 Removing the seat




Remove screw 1.



- Raise the rear of the seat, pull the seat back, and lift it off.

11.21 Mounting the seat



- Mount the front of the seat on the collar bushing of the fuel tank, lower the seat at the rear, and push the seat forward.
- Make sure that the seat is locked in correctly.




Mount and tighten screw 1. Guideline

| Remaining screws, | M6 | 10 Nm (7.4 lbf ft) |
|-------------------|----|--------------------|
| chassis | | |


11.22 Removing the air filter box cover

The air filter box cover is secured.

- Remove the seat. (p. 56)
- Remove screw 1.




Pull off the air filter box cover in area (A) sideways and take off toward the front.




The air filter box cover is not secured.

Pull off the air filter box cover in area (A) sideways and take off toward the front.




11.23 Installing the air filter box cover



Condition

The air filter box cover is secured.


Insert the air filter box cover in area and clip it into area area



Mount and tighten screw ①.
 Guideline

| Screw, air filter box | EJOT PT® | 3 Nm (2.2 lbf ft) |
|-----------------------|----------|-------------------|
| cover | K60x20-Z | |

- Mount the seat. (p. 56)



Condition

The air filter box cover is not secured.

Insert the air filter box cover in area and clip it into area .

11.24 Removing the air filter 4

Note

Engine damage Unfiltered intake air has a negative effect on the service life of the engine.

Dust and dirt will enter the engine without an air filter.

- Never start to use the vehicle without an air filter.



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Preparatory work

- Remove the air filter box cover. (p. 57)



- Detach retaining tab 1. Remove air filter with air filter support.
- Take off air filter from air filter support.

11.25 Cleaning the air filter and air filter box 4



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

Do not clean the air filter with fuel or petroleum since these substances attack the foam.



Preparatory work

- Remove the air filter box cover. (p. 57)
- Remove the air filter. ♣ (♠ p. 58)

Main work

- Wash the air filter thoroughly in special cleaning liquid and allow it to dry properly.

Air filter cleaner (🕮 p. 126)



Info

Only press the air filter to dry it, never wring it out.

- Oil the dry air filter with a high-grade air filter oil.


Oil for foam air filter (p. 126)

- Clean the air filter box.
- Clean the intake flange and check it for damage and tightness.

Finishing work

- Install the air filter. 4 (p. 60)


11.26 Installing the air filter 4



Main work

- Mount the clean air filter on the air filter support.
- Grease the air filter in area $oldsymbol{A}$.

Long-life grease (p. 126)



- Insert the air filter and position the top retaining pin **1** in bushing **B**.
 - ✓ The air filter is correctly positioned.
- Secure the bottom retaining pin with holding tab **2**.




Info

If the air filter is not mounted correctly, dust and dirt may enter the engine and result in damage.

Finishing work

- Install the air filter box cover. (p. 58)

11.27 Preparing air filter box cover for securing 4



Preparatory work

Main work

Drill a hole at marking (A).
 Guideline

Diameter 6 mm (0.24 in)

Finishing work

- Install the air filter box cover. (p. 58)


11.28 Removing the main silencer



Warning


Danger of burns The exhaust system gets very hot when the vehicle is driven.

- Allow the exhaust system to cool down before performing any work on the vehicle.



- Remove screws 1 with the washers.
- Pull off the main silencer from the manifold at exhaust sleeve 2.

11.29 Installing the main silencer



- Position the main silencer in exhaust sleeve 1.
- Mount and tighten screws 2 with the washers.
 Guideline

| Remaining screws, | M6 | 10 Nm (7.4 lbf ft) |
|-------------------|----|--------------------|
| chassis | | |

11.30 Changing the glass fiber yarn filling in the main silencer 🔌



Warning

Danger of burns The exhaust system gets very hot when the vehicle is driven.


- Allow the exhaust system to cool down before performing any work on the vehicle.



Info

Over time, the fibers of the rock wool escape into the air, and the main silencer "burns out". Not only is the noise level higher, the performance characteristic changes.

Preparatory work



- Remove screws 1. Pull out inner tube 2.
- Remove the glass fiber yarn filling **3** from the inner tube.
- Clean the parts that need to be reinstalled and check for damage.
- Fit the new glass fiber yarn filling 3 into the inner tube.
- Slide outer tube over the inner tube with the new glass fiber yarn filling.
- Mount and tighten all screws ①.
 Guideline

| Screws on main | M5 | 7 Nm (5.2 lbf ft) |
|----------------|----|-------------------|
| silencer | | |

Finishing work

11.31 Removing the fuel tank 🔌



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.




Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.

Preparatory work

- Remove the seat. (🕮 p. 56)
- Turn tap handle of the fuel tap to the **OFF** position.



Pull off the fuel hose.




Info

Remaining fuel may flow out of the fuel hose.

Remove screws 1.



- Remove screw 2 with the rubber bushing.
- Pull the fuel tank breather hose off the fuel tank lid.



Pull both spoilers laterally off the radiator and take off the fuel tank upwards.

11.32 Installing the fuel tank &



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.


- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.




- Check throttle cable routing. (p. 70)
- Position the fuel tank and fit the two spoilers laterally to the radiator.
- Make sure that no cables or throttle cables are trapped or damaged.



- Attach the fuel tank breather hose.
- Mount and tighten screw 1 with the rubber bushing.
 Guideline

| Remaining screws, | M6 | 10 Nm (7.4 lbf ft) |
|-------------------|----|--------------------|
| chassis | | |



Mount and tighten screws 2.
 Guideline


| Remaining screws, | M6 | 10 Nm (7.4 lbf ft) |
|-------------------|----|--------------------|
| chassis | | |

Connect the fuel hose.

Finishing work

- Mount the seat. (p. 56)

11.33 Checking the chain for dirt



- Check the chain for heavy soiling.
 - » If the chain is very dirty:
 - Clean the chain. (p. 65)

•

11.34 Cleaning the chain



Warning

Danger of accidents Lubricants on the tires reduces the road grip.

Remove lubricants from the tires using a suitable cleaning agent.



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



Note


Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

The service life of the chain depends largely on its maintenance.



Preparatory work

- Raise the motorcycle with a lift stand. (p. 44)

Main work

- Rinse off loose dirt with a soft jet of water.
- Remove old grease residue with chain cleaner.

Chain cleaner (p. 126)

After drying, apply chain spray.

Off-road chain spray (🕮 p. 126)

Finishing work

Remove the motorcycle from the lift stand. (
 p. 44)

11.35 Checking the chain tension



Warning


Danger of accidents Incorrect chain tension damages components and results in accidents.

If the chain is tensioned too much, the chain, engine sprocket, rear sprocket, transmission and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the engine sprocket or the rear sprocket. As a result, the rear wheel locks or the engine will be damaged.

- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

Preparatory work



 Pull the chain at the end of the chain sliding piece upward to measure chain tension A.

Guideline

Lower chain section 1 must be taut.



Info

Chain wear is not always even, so you should repeat this measurement at different chain positions.

| Chain tension | 55 58 mm (2.17 |
|---------------|----------------|
| | • |
| | 2.28 in) |
| | • |

- » If the chain tension does not meet the specification:
 - Adjust the chain tension. (
 p. 66)

Finishing work

Remove the motorcycle from the lift stand. (
 p. 44)

11.36 Adjusting the chain tension



Warning

Danger of accidents Incorrect chain tension damages components and results in accidents.


If the chain is tensioned too much, the chain, engine sprocket, rear sprocket, transmission and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the engine sprocket or the rear sprocket. As a result, the rear wheel locks or the engine will be damaged.

- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

Preparatory work

- Check the chain tension. (p. 65)



- Loosen nut 1.
- Loosen nuts 2.
- Adjust the chain tension by turning adjusting screws **3** left and right.

Guideline

| | 55 58 mm (2.17 2.28 in) | |
|---|----------------------------|--|
| Turn adjusting screws 3 on the left and right so that the | | |
| markings on the left and right chain adjusters are in the | | |

Turn adjusting screws **3** on the left and right so that the markings on the left and right chain adjusters are in the same position relative to reference marks **3**. The rear wheel is then correctly aligned.

- Tighten nuts **2**.
- Make sure that chain adjusters 4 are fitted correctly on adjusting screws 3.
- Tighten nut 1.

Guideline

| Nut, rear wheel spin- | M25x1.5 | 80 Nm (59 lbf ft) |
|-----------------------|---------|-------------------|
| dle | | |



Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.

Chain adjusters 4 can be turned by 180°.

Finishing work

- Remove the motorcycle from the lift stand. (p. 44)

11.37 Checking the chain, rear sprocket, engine sprocket, and chain guide

Preparatory work

- Raise the motorcycle with a lift stand. (p. 44)


Main work

- Shift the transmission into neutral.
- Check the chain, rear sprocket, and engine sprocket for wear.
 - » If the chain, rear sprocket or engine sprocket is worn:
 - Change the drivetrain kit.




Info

The engine sprocket, rear sprocket, and chain should always be replaced together.



11 SERVICE WORK ON THE CHASSIS



 Pull on the top section of the chain with the specified weight A.

Guideline

| Weight, chain wear measure- | 10 15 kg (22 33 lb.) |
|-----------------------------|----------------------|
| ment | |

- Measure distance **B** of 18 chain rollers in the lower chain section.



Info

Chain wear is not always even, so you should repeat this measurement at different chain positions.

| Maximum distance B from | 272 mm (10.71 in) |
|--------------------------------|-------------------|
| 18 chain rollers at the | |
| longest chain section | |

- » If distance **B** is greater than the specified measurement:
 - Change the drivetrain kit.





Info

When a new chain is mounted, the rear sprocket and engine sprocket should also be changed. New chains wear out faster on an old, worn rear sprocket or engine sprocket.

- Check the chain sliding guard for wear.
 - » If the lower edge of the chain pins is in line with, or below, the chain sliding guard:
 - Change the chain sliding guard. 🔌
- Check that the chain sliding guard is firmly seated.
 - » If the chain sliding guard is loose:
 - Tighten screws on the chain sliding guard.
 Guideline

| Screw, chain | M6 | 10 Nm (7.4 lbf ft) |
|---------------|----|--------------------|
| sliding guard | | Loctite®243™ |







- Check the chain sliding piece for wear.
 - If the lower edge of the chain pins is in line with or below the chain sliding piece:
 - Change the chain sliding piece. 🔌
- Check that the chain sliding piece is firmly seated.
 - If the chain sliding piece is loose:
 - Tighten screw on the chain sliding piece.

Guideline

| Screw, chain slid- | M8 | 15 Nm |
|--------------------|----|---------------|
| ing piece | | (11.1 lbf ft) |



Check the chain guide with a slide gage for dimension **()**.



- If the measured value is less than the specification:
 - Change the chain guide.



- Check that the chain guide is firmly seated.
 - If the chain guide is loose:
 - Tighten the screws on the chain guide. Guideline

| duideillie | | |
|-------------------|----|------|
| Remaining screws, | M6 | 10 N |
| chassis | | (7.4 |

| Remaining screws, | M6 | 10 Nm |
|-------------------|-----|--------------|
| chassis | | (7.4 lbf ft) |
| Remaining nuts, | M6 | 10 Nm |
| chassis | | (7.4 lbf ft) |
| | WIO | 20 |

Finishing work

Remove the motorcycle from the lift stand. (p. 44)

11.38 Checking the frame 🔦



- Check the frame for cracks and deformation.
 - » If the frame exhibits cracks or deformation due to a mechanical impact:
 - Change the frame. 🔦



Info

Always replace a frame that has been damaged due to a mechanical impact. Repair of the frame is not authorized by KTM.

11.39 Checking the link fork 4



- Check the link fork for damage, cracking, and deformation.
 - » If the link fork exhibits damage, cracking, or deformation:
 - Change the link fork. 🔦



Info

Always replace a damaged link fork. Repairing the link fork is not authorized by KTM.

11.40 Checking throttle cable routing



Warning

Danger of accidents The throttle cable may slip out of the guide if routed incorrectly.

The throttle slide will then no longer be closed and the speed can no longer be controlled.

- Make sure that the throttle cable routing and the play in the throttle cable comply with the specification.

Preparatory work

- Remove the seat. (p. 56)
- Turn tap handle of the fuel tap to the OFF position.
- Remove the fuel tank. ♣ (♣ p. 62)



Main work

Check throttle cable routing.


The throttle cable must be routed along the back of the handlebar, to the right of the frame, above the fuel tank bracket, and to the carburetor. The throttle cable must be secured on the fuel tank bracket with a rubber strap.

- If the throttle cable routing is not as specified:
 - Correct the throttle cable routing.

Finishing work

- Install the fuel tank. 🔌 (🕮 p. 63)
- Mount the seat. (p. 56)

Checking the rubber grip 11.41



Check the rubber grips on the handlebar for damage, wear, and looseness.



Info


The rubber grips are vulcanized onto a sleeve on the left and onto the handle tube of the throttle grip on the right. The left sleeve is clamped onto the handlebar. The rubber grip can only be replaced with the sleeve or the throttle tube.

- If a rubber grip is damaged or worn:
 - Change the rubber grip.
- Check that screw 1 is firmly seated.


Guideline



Diamond A must be located at the top.



11.42 Adjusting the basic position of the clutch lever



- Adjust the basic position of the clutch lever to your hand size by turning adjusting screw 1.



Info

Turn the adjusting screw counterclockwise to decrease the distance between the clutch lever and the handle-bar

Turn the adjusting screw clockwise to increase the distance between the clutch lever and the handlebar. The range of adjustment is limited.

Turn the adjusting screw by hand only, and do not apply any force.

Do not make any adjustments while riding.

11.43 Checking/correcting the fluid level of the hydraulic clutch



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.




Info

The fluid level rises with increasing wear of the clutch facing discs.

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and clutch lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.

Only use clean brake fluid from a sealed container.



- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws 1.
- Remove cover **2** with membrane **3**.
- Check the fluid level.

| Fluid level below container | 4 mm (0.16 in) |
|-----------------------------|----------------|
| rim | |

- » If the fluid level does not meet specifications:
 - Correct the fluid level of the hydraulic clutch.

Brake fluid DOT 4 / DOT 5.1 (🕮 p. 124)

Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilled brake fluid immediately with water.

•

11.44 Changing the hydraulic clutch fluid 🔌



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.




Info


Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and clutch lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.

Only use clean brake fluid from a sealed container.



- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws 1.
- Remove cover 2 with membrane 3.




- Fill bleeding syringe 4 with the appropriate hydraulic fluid.

Syringe (50329050000)

Brake fluid DOT 4 / DOT 5.1 (p. 124)

On the clutch slave cylinder, remove bleeder screw **5** and mount bleeding syringe **4**.

11 SERVICE WORK ON THE CHASSIS



- Now inject the liquid into the system until it emerges from the drill hole 6 of the master cylinder without bubbles.
- Now and then, extract fluid from the master cylinder reservoir to prevent overflow.
- Remove the bleeding syringe. Mount and tighten screws bleeder screw.
- Correct the fluid level of the hydraulic clutch.
 Guideline

| Fluid level below container | 4 mm (0.16 in) |
|-----------------------------|----------------|
| rim | |

Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilled brake fluid immediately with water.

•

12.1 Checking the free travel of the hand brake lever




Warning

Danger of accidents The brake system fails in the event of overheating.

If there is no free travel on the hand brake lever, pressure builds up on the front brake circuit.

Set the free travel on the hand brake lever in accordance with the specification.




Push the hand brake lever forward and check free travel **A**.



Free travel of hand brake $\geq 3 \text{ mm } (\geq 0.12 \text{ in})$ lever

- If the free travel does not match the specification:
 - Adjust the basic position of the hand brake lever. (🕮 p. 75)

12.2 Adjusting the basic position of the hand brake lever



- Check the free travel of the hand brake lever. (p. 75)
- Adjust the basic position of the hand brake lever to your hand size by turning adjusting screw 1.



Info

Turn the adjusting screw clockwise to increase the distance between the hand brake lever and the handlebar.

Turn the adjusting screw counterclockwise to decrease the distance between the hand brake lever and the handlebar.

The range of adjustment is limited.

Only turn the adjusting screw by hand, and do not use

Do not make any adjustments while riding.


12.3 Checking the brake discs



Warning

Danger of accidents Worn-out brake discs reduce the braking effect.

Make sure that worn-out brake discs are replaced immediately. (Your authorized KTM workshop will be glad to help.)



- Check the front and rear brake disc thickness at multiple points for the dimension **A**.



Info

Wear reduces the thickness of the brake disc around the contact surface of the brake linings.

| Brake discs - wear limit | |
|--------------------------|-------------------|
| front | 2.5 mm (0.098 in) |
| rear | 3.5 mm (0.138 in) |

- » If the brake disc thickness is less than the specified value:
 - Change the front brake disc.
 - Change the rear brake disc.
- Check the front and rear brake discs for damage, cracking, and deformation.
 - » If the brake disc exhibits damage, cracking, or deformation:
 - Change the front brake disc.
 - Change the rear brake disc.

12.4 Checking the front brake fluid level



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.

 Check the brake system and do not continue riding until the problem is eliminated. (Your authorized KTM workshop will be glad to help.)



Warning


Danger of accidents Old brake fluid reduces the braking effect.

 Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized KTM workshop will be glad to help.)




Preparatory work





- Check the brake fluid level in level viewer 1.
 - ightharpoonup If the brake fluid level has dropped below the marking $oldsymbol{A}$:
 - Add front brake fluid. ♣ (♠ p. 77)



12.5 Adding front brake fluid 🔦



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.

 Check the brake system and do not continue riding until the problem is eliminated. (Your authorized KTM workshop will be glad to help.)



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Warning

Danger of accidents Old brake fluid reduces the braking effect.

 Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized KTM workshop will be glad to help.)



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info


Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.

Only use clean brake fluid from a sealed container.

Preparatory work

- Check the front brake linings. (p. 78)



Main work

- Move the brake reservoir mounted on the handlebar to a horizontal position.
- Remove screws 1.
- Take off cover **2** with membrane **3**.
- Add brake fluid to level A.
 Guideline

| Level A (brake fluid level below reservoir rim) | 5 mm (0.2 in) |
|--|---------------|
|--|---------------|

Brake fluid DOT 4 / DOT 5.1 (p. 124)

Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilled brake fluid immediately with water.


12.6 Checking the front brake linings



Warning

Danger of accidents Worn-out brake linings reduce the braking effect.

- Ensure that worn-out brake linings are replaced immediately. (Your authorized KTM workshop will be glad to help.)



Check the brake linings for minimum thickness A.

Minimum thickness **A** ≥ 1 mm (≥ 0.04 in)

- » If the minimum thickness is less than specified:
- Check the brake linings for damage and cracking.
 - » If damage or wear is encountered:
 - Change the front brake linings. ♣ (🕮 p. 78)

12.7 Changing the front brake linings &



Warning

Danger of accidents Incorrect servicing will cause the brake system to fail.

- Ensure that service work and repairs are performed professionally. (Your authorized KTM workshop will be glad to help.)



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Warning

Danger of accidents Old brake fluid reduces the braking effect.

 Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized KTM workshop will be glad to help.)



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



Warning

Danger of accidents Brake linings which have not been approved alter the braking efficiency.

Not all brake linings are tested and approved for KTM motorcycles. The structure and friction coefficient of the brake linings, and thus their brake power, may vary greatly from that of original brake linings. If brake linings are used that differ from the original equipment, compliance with the original homologation is not guaranteed. In this case, the vehicle no longer corresponds to its condition at delivery and the manufacturer warranty shall be void.

Only use brake linings approved and recommended by KTM.



Note

Environmental hazard Hazardous substances cause environmental damage.


 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint. Only use clean brake fluid from a sealed container.




- Move the brake reservoir mounted on the handlebar to a horizontal position.
- Remove screws 1.
- Take off cover **2** with membrane **3**.
- Manually press the brake caliper toward the brake disc to push back the brake pistons. Ensure that brake fluid does not flow out of the brake fluid reservoir, if necessary extract excess.




Info

Make sure that you do not press the brake caliper against the spokes when pushing back the brake pistons.

- Remove cotter pins 4, pull out pin 5, and remove the brake linings.
- Clean the brake caliper and brake caliper bracket.



Check that spring plate 6 in the brake caliper and sliding plate 7 in the brake caliper bracket are seated correctly.



Insert the new brake linings, insert pin, and mount cotter pins.



Info

Always change the brake linings in pairs.

 Operate the hand brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



Correct the brake fluid quantity to level A.
 Guideline

Level (A) (brake fluid level 5 mm (0.2 in) below reservoir rim)

Brake fluid DOT 4 / DOT 5.1 (p. 124)

Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilled brake fluid immediately with water.

•

12.8 Checking the free travel of foot brake lever




Warning

Danger of accidents The brake system fails in the event of overheating.

If there is no free travel on the foot brake lever, pressure builds up in the brake system on the rear brake.

- Set the free travel on the foot brake lever in accordance with the specification.



- Disconnect spring 1.
- Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel (A).

Guideline

Free travel at foot brake lever 3 ... 5 mm (0.12 ... 0.2 in)

- » If the free travel does not meet specifications:
 - Adjust the basic position of the foot brake lever. ♣
 (□ p. 81)
- Reconnect spring 1.

12.9 Adjusting the basic position of the foot brake lever 🔌




Warning

Danger of accidents The brake system fails in the event of overheating.

If there is no free travel on the foot brake lever, pressure builds up in the brake system on the rear brake.

- Set the free travel on the foot brake lever in accordance with the specification.



- Detach spring 1.
- Loosen nut 2 and, with push rod 3, turn it back until you have maximum free travel.
- To adjust the basic position of the foot brake lever to individual requirements, loosen nut 4 and turn screw 5 accordingly.



Info

The range of adjustment is limited.

Turn push rod 3 accordingly until you have free travel A. If necessary, adjust the basic position of the foot brake lever.
 Guideline

Free travel at foot brake lever 3 ... 5 mm (0.12 ... 0.2 in)

Hold screw 6 and tighten nut 4.
 Guideline

| Nut, foot brake lever | M8 | 20 Nm (14.8 lbf ft) |
|-----------------------|----|---------------------|
| stop | | |

- Hold push rod 3 and tighten nut 2.

Guideline

| Remaining nuts, | M6 | 10 Nm (7.4 lbf ft) |
|-----------------|----|--------------------|
| chassis | | |

Attach spring 1.

12.10 Checking the rear brake fluid level



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.

 Check the brake system and do not continue riding until the problem is eliminated. (Your authorized KTM workshop will be glad to help.)



Warning

Danger of accidents Old brake fluid reduces the braking effect.


 Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized KTM workshop will be glad to help.)

Preparatory work

Check the brake linings of the rear brake. (
 p. 84)

Main work

- Stand the vehicle upright.
- Check the brake fluid level in level viewer 1.
 - If the brake fluid has dropped below marking **A**:
 - Add rear brake fluid. 🐴 (🕮 p. 82)



12.11 Adding rear brake fluid 🔌



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.

 Check the brake system and do not continue riding until the problem is eliminated. (Your authorized KTM workshop will be glad to help.)



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Warning

Danger of accidents Old brake fluid reduces the braking effect.

 Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized KTM workshop will be glad to help.)



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.




Info

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.

Only use clean brake fluid from a sealed container.



Preparatory work

- Check the brake linings of the rear brake. (p. 84)

Main work

- Stand the vehicle upright.
- Remove screw cap **1** with membrane **2** and the O-ring.
- Add brake fluid to level A

Brake fluid DOT 4 / DOT 5.1 (p. 124)

- Mount the screw cap with the membrane and the O-ring.



Info

Clean up overflowed or spilled brake fluid immediately with water.


12.12 Checking the brake linings of the rear brake



Warning

Danger of accidents Worn-out brake linings reduce the braking effect.

Ensure that worn-out brake linings are replaced immediately. (Your authorized KTM workshop will be glad to help.)



Check the brake linings for minimum thickness **A**.



Minimum thickness **A**

≥ 1 mm (≥ 0.04 in)

- If the minimum thickness is less than specified:
- Check the brake linings for damage and cracking.
 - If damage or wear is encountered:

12.13 Changing the rear brake linings 4



Warning

Danger of accidents Incorrect servicing will cause the brake system to fail.

 Ensure that service work and repairs are performed professionally. (Your authorized KTM workshop will be glad to help.)



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Warning

Danger of accidents Old brake fluid reduces the braking effect.

Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized KTM workshop will be glad to help.)



Environmental hazard Hazardous substances cause environmental damage.


Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.




Info

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint. Only use clean brake fluid from a sealed container.



- Stand the vehicle upright.
- Remove screw cap with membrane and the O-ring.



 Manually press the brake caliper toward the brake disc to push back the brake piston. Ensure that brake fluid does not flow out of the brake fluid reservoir, if necessary extract excess.



Info


Make sure that you do not press the brake caliper against the spokes when pushing back the brake piston.

- Remove cotter pins **3**, pull out pin **4**, and remove the brake linings.
- Clean the brake caliper and brake caliper bracket.
- Check that spring plate **6** in the brake caliper and sliding plate **6** in the brake caliper bracket are seated properly.



Info

The arrow on the spring plate points in the direction of rotation of the brake disc.




Insert the new brake linings, insert pin 4, and mount the cotter pins 3.




Info

Always change the brake linings in pairs. Make sure that decoupling plate **7** is mounted on the piston side brake lining.

Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.





Add brake fluid to level A.

Brake fluid DOT 4 / DOT 5.1 (p. 124)


Mount and tighten screw cap with membrane and the O-ring.



Info

Clean up overflowed or spilled brake fluid immediately with water

13.1 Removing the front wheel 🔦



Preparatory work

Raise the motorcycle with a lift stand. (p. 44)


Manually press the brake caliper toward the brake disc to push back the brake pistons.




Info

Make sure that you do not press the brake caliper against the spokes when pushing back the brake pistons.





- Press on screw 1 to push the wheel spindle out of the axle clamp.
- Remove screw 1.





Warning

Danger of accidents Damaged brake discs reduce the braking effect.


- Always lay the wheel down in such a way that the brake disc is not damaged.
- Hold the front wheel and remove the wheel spindle. Take the front wheel out of the fork.




Info

Do not actuate the hand brake lever when the front wheel is removed.

Remove spacers 3.





H01340-10




13.2 Installing the front wheel 🔦




Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.







- » If the wheel bearing is damaged or worn:
 - Change front wheel bearing.
- Clean and grease shaft seal rings 1 and contact surfaces A of the spacers.



- Insert the spacers.
- Clean and grease the wheel spindle.



✓ The brake linings are correctly positioned.



Guideline

| Screw, front wheel | M20x1.5 | 35 Nm (25.8 lbf ft) |
|--------------------|---------|---------------------|
| spindle | | |

- Operate the hand brake lever several times until the brake linings are seated correctly against the brake disc.
- Operate the front brake and compress the fork a few times firmly.
 - ✓ The fork legs straighten.
- Tighten screws **3**.

Guideline


| Screw, fork stub | M8 | 15 Nm (11.1 lbf ft) |
|------------------|----|---------------------|
|------------------|----|---------------------|

4

13.3 Removing the rear wheel 4

Preparatory work

Raise the motorcycle with a lift stand. (
 p. 44)



Main work

 Manually press the brake caliper toward the brake disc to push back the brake piston.



Info

Make sure that you do not press the brake caliper against the spokes when pushing back the brake piston.

- Remove nut 1.
- Take off chain adjuster **2**. Pull out wheel spindle **3** far enough to allow the rear wheel to be pushed forward.
- Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.



Info

Cover the components to protect them against damage.



Warning

Danger of accidents Damaged brake discs reduce the braking effect.


- Always lay the wheel down in such a way that the brake disc is not damaged.
- Hold the rear wheel and remove the wheel spindle. Take the rear wheel out of the link fork.



Info

Do not operate the foot brake lever when the rear wheel is removed.

- Remove spacers **4**.




13.4 Installing the rear wheel 4



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.




Main work - Check

- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the rear wheel bearing.
- Clean and grease shaft seal rings **1** and contact surfaces **A** of the spacers.


Long-life grease (🕮 p. 126)

- Insert the spacers.
- Clean and grease the wheel spindle.

Long-life grease (🕮 p. 126)



- Position rear wheel and insert wheel spindle 2.
 - ✓ The brake linings are correctly positioned.
- Mount the chain.



- Position chain adjuster **3**. Mount nut **4**, but do not tighten it vet.
- Make sure that chain adjusters 3 are fitted correctly on adjusting screws 5.
- Tighten nut **4**.

Guideline

| Nut, rear wheel spin- | M25x1.5 | 80 Nm (59 lbf ft) |
|-----------------------|---------|-------------------|
| dle | | |



Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.

Chain adjusters 3 can be turned by 180°.

 Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.

Finishing work

Remove the motorcycle from the lift stand. (
 p. 44)

•

13.5 Checking the tire condition



Info


Only mount tires approved and/or recommended by KTM.

Other tires could have a negative effect on handling characteristics.


The type, condition, and pressure of the tires all have a major impact on the handling characteristic of the motorcycle.

The tires mounted on the front and rear wheels must have a similar profile.

Worn tires have a negative effect on handling characteristics, especially on wet surfaces.



- Check the front and rear tires for cuts, run-in objects, and other damage.
 - » If the tires have cuts, run-in objects, or other damage:
 - Change the tires.



- Check the tire age.



Info

The tire date of manufacture is usually contained in the tire label and is indicated by the last four digits of the **DOT** number. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.

KTM recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.


- » If the tires are more than 5 years old:
 - Change the tires.

13.6 Checking tire pressure



Info

Low tire pressure leads to abnormal wear and overheating of the tire. Correct tire pressure ensures optimal riding comfort and maximum tire service life.



- Remove the protection cap.
- Check the tire pressure when the tires are cold.

| Offroad tire pressure | |
|-----------------------|------------------|
| front | 1.0 bar (15 psi) |
| rear | 1.0 bar (15 psi) |

- » If the tire pressure does not meet specifications:
 - Correct the tire pressure.
- Mount the protection cap.

13.7 Checking spoke tension




Warning

Danger of accidents Incorrectly tensioned spokes impair the handling characteristic and result in secondary damage.

The spokes break due to being overloaded if they are too tightly tensioned. If the tension in the spokes is too low, then lateral and radial run-out will form in the wheel. Other spokes will become looser as a result.

 Check spoke tension regularly, and in particular on a new vehicle. (Your authorized KTM workshop will be glad to help.)



Strike each spoke briefly using a screwdriver blade.



Info

The frequency of the sound depends on the spoke length and spoke diameter.

If you hear different tone frequencies from different spokes of equal length and diameter, this is an indication of different spoke tensions.

You should hear a high note.


- » If the spoke tension differs:
 - Correct the spoke tension.
- Check the spoke torque.

Guideline

| Spoke nipple, front wheel | M4.5 | 6 Nm (4.4 lbf ft) |
|---------------------------|------|-------------------|
| Spoke nipple, rear wheel | M4.5 | 6 Nm (4.4 lbf ft) |

Torque wrench kit (58429094000)

14.1 Cooling system



Water pump 1 in the engine ensures forced circulation of the coolant

The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ②. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

14.2 Checking the antifreeze and coolant level



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.


- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses
 or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



Warning

Danger of poisoning Coolant is toxic and a health hazard.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.



Condition

The engine is cold.

- Stand the motorcycle upright on a horizontal surface.
- Remove the radiator cap.
- Check the coolant antifreeze.

- » If the antifreeze in the coolant does not match the specified value:
 - Correct the coolant antifreeze.
- Check the coolant level in the radiator.

| Coolant level (A) above the | 10 mm (0.39 in) |
|-----------------------------|-----------------|
| radiator fins | |

- » If the coolant level does not match the specified value:
 - Correct the coolant level.

Coolant (IP p. 124)

- Mount the radiator cap.

14.3 Checking the coolant level



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.


- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



Warning

Danger of poisoning Coolant is toxic and a health hazard.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.



Condition

The engine is cold.

- Stand the motorcycle upright on a horizontal surface.
- Remove the radiator cap.
- Check the coolant level in the radiator.

| Coolant level A above the | 10 mm (0.39 in) |
|---------------------------|-----------------|
| radiator fins | |

- » If the coolant level does not match the specified value:
 - Correct the coolant level.

Coolant (🕮 p. 124)

Mount the radiator cap.

14.4 Draining the coolant 🔦



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.

_



Warning

Danger of poisoning Coolant is toxic and a health hazard.


- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.

Condition

The engine is cold.

- Position the motorcycle upright.
- Place an appropriate container under the water pump cover.
- Remove screw 1. Take off radiator cap 2.
- Completely drain the coolant.
- Mount and tighten screw with a new seal ring.
 Guideline

| Screw, water pump | M6 | 10 Nm (7.4 lbf ft) |
|-------------------|----|--------------------|
| cover | | |




14.5 Refilling with coolant 🔌



Warning


Danger of poisoning Coolant is toxic and a health hazard.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.



Main work


- Make sure that screw 1 is tightened.
- Position the motorcycle upright.



Pour coolant in up to measurement above the radiator fins.
 Guideline


10 mm (0.39 in)

Coolant (p. 124)



- Loosen screw 2 and wait until coolant escapes without bubbles
- Mount and tighten screw 2.
 Guideline


| Bleeder screw, cylin- | M6 | 10 Nm (7.4 lbf ft) |
|-----------------------|----|--------------------|
| der head | | |



Pour coolant in up to measurement
 A above the radiator fins.
 Guideline

10 mm (0.39 in)

Coolant (p. 124)



Mount radiator cap 3.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.
- Allow the engine to warm up and cool down again.

Finishing work

14.6 Changing the coolant 🔦



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.


- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



Warning


Danger of poisoning Coolant is toxic and a health hazard.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.




- Position the motorcycle upright.
- Place an appropriate container under the water pump cover.
- Remove screw 1. Take off radiator cap 2.
- Completely drain the coolant.
- Mount and tighten screw with a new seal ring.
 Guideline

| Screw, water pump | M6 | 10 Nm (7.4 lbf ft) |
|-------------------|----|--------------------|
| cover | | |




Pour coolant in up to measurement **A** above the radiator fins.

| 10 mm (0.39 in) | |
|-------------------|--|
| Coolant (p. 124) | |



- Loosen screw 3 and wait until coolant escapes without bubbles
- Mount and tighten screw 3.
 Guideline


| Bleeder screw, cylin- | M6 | 10 Nm (7.4 lbf ft) |
|-----------------------|----|--------------------|
| der head | | |



Pour coolant in up to measurement above the radiator fins.
 Guideline

10 mm (0.39 in)

Coolant (p. 124)



– Mount radiator cap **2**.




Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.
- Allow the engine to warm up and cool down again.
- Check the cooling system for leaks.

Finishing work

- Check the coolant level. (p. 94)



- Check the throttle grip for smooth operation.
- Move the handlebar to the straight-ahead position. Turn the throttle grip back and forth slightly and determine the play in throttle cable (A).

| Throttle cable play | 2 3 mm (0.08 |
|---------------------|--------------|
| | 0.12 in) |

- » If the throttle cable play does not meet specifications:
 - Adjust throttle cable play. 🔌 (🕮 p. 99)



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.
- Start the engine and let it run at idle speed. Move the handlebar to and fro over the entire steering range.

The idle speed must not change.

- » If the idle speed changes:
 - Adjust throttle cable play. 🔌 🕮 p. 99)

15.2 Adjusting throttle cable play 🔌



Info


If the correct routing of the throttle cable has already been secured, the fuel tank does not need to be removed.


Preparatory work

- Remove the seat. (p. 56)
- Turn tap handle of the fuel tap to the OFF position.
- Remove the fuel tank. ♣ (♥ p. 62)

Main work

- Move the handlebar to the straight-ahead position.
- Push back sleeve 1.
- Ensure that the throttle cable sleeve is pushed all the way into barrel adjuster 2.
- Loosen nut 3.





Turn barrel adjuster **2** so that there is play **A** in the throttle cable at the throttle grip.

Guideline

| Throttle cable play | 2 3 mm (0.08 |
|---------------------|--------------|
| | 0.12 in) |


- Tighten nut 3.
- Slide on sleeve 1.

Finishing work

- Check the throttle grip for smooth operation.
- Install the fuel tank. 4 (
 p. 63)
- Mount the seat. (
 p. 56)
- Check throttle cable play. (p. 99)

15.3 Carburetor tuning

Effects of carburetor tuning



The different carburetor components must be tuned both to one another and for the use intended.

Main jet MJ

The main jet MJ has the greatest influence with the throttle slide open (full throttle).

If the insulator of a new spark plug is very light or white after a brief ride at full throttle, or if the engine knocks, a larger main jet needs to be used. If the insulator is dark brown or sooty, a smaller main jet needs to be used.

Needle position POS

The needle position has the greatest influence in the mid throttle slide range.

If the engine stutters when accelerating with a partially open throttle slide, the jet needle must be lowered. If the engine knocks when accelerating at the full power rpm range, the jet needle must be raised.

Cylindrical part of the needle CYL

The cylindrical part of the needle has the greatest influence when the throttle slide is almost closed.

Idling jet IJ


The idling jet has the greatest influence in the low to mid throttle slide range.

If the engine stutters at idle speed or when accelerating with a partially open throttle slide, a smaller idling jet must be used. If the engine knocks in this power range, then a larger idling jet must be used.

Idle air adjusting screw open ASO


The idle air adjusting screw has the greatest influence at idle speed.

Influence of throttle slide adjustment




The idling jet has the greatest influence when the throttle slide is closed. The first cylindrical part of the needle and the clip position have only minimal influence.

When the throttle slide is 1/8 open, the first cylindrical part of the needle, the idling jet and the clip position have the greatest influence.



When the throttle slide is 1/4 open, the idling jet and the clip position have the greatest influence. The influence of the first cylindrical part of the needle is less.

When the throttle slide is 1/2 open, the position of the needle has the greatest influence. The influence of the main jet and the idling jet is only minimal.



When the throttle slide is 3/4 open, the influence of the main jet is greatest. The clip position and the idling jet have only minimal influence.

When the throttle slide is fully open, the influence of the main jet is greatest. The clip position and the idling jet have only minimal influence.

Needle overview

The jet needles available are shown in the following table.

| | 1 | 2 | 3 | 4 |
|---|-----------|-----------|-----------|-----------|
| A | 6BFY42-71 | 6BFY43-71 | 6BFY44-71 | 2,71 mm |
| В | 6BFY42-72 | 6BFY43-72 | 6BFY44-72 | 2.72 mm |
| С | 6BFY42-73 | 6BFY43-73 | 6BFY44-73 | 2.73 mm |
| D | 6BFY42-74 | 6BFY43-74 | 6BFY44-74 | 2.74 mm |
| E | 6BFY42-75 | 6BFY43-75 | 6BFY44-75 | 2.75 mm |
| F | 6BFY42-76 | 6BFY43-76 | 6BFY44-76 | 2.76 mm |
| | | | | 402674-01 |

Column 2 corresponds to a needle in the standard position.

Column 1 corresponds to a needle which is half a clip leaner.


Column **3** corresponds to a needle which is half a clip richer.

Column 4 specifies the diameter of the first cylindrical part of the needle. The smaller the diameter of the first cylindrical part of the needle, the richer the mixture preparation. The larger the diameter of the first cylindrical part of the needle, the leaner the mixture preparation. The first cylindrical part of the needle has the greatest influence in the lowest load range.



Info

The top right jet needle A3 corresponds to the richest setting of the carburetor, and the bottom left jet needle F1 corresponds to the leanest. The optimal carburetor tuning is shown under the respective model.




Clip position

| 1 5 | Clip position from above |
|-----|--------------------------|
|-----|--------------------------|

The five possible clip positions are shown here.

The carburetor tuning depends on the defined ambient and operating conditions.

15.4 **Carburetor idle control**



The idle setting of the carburetor has a big influence on the starting behavior, stable idle speed, and the response to throttle opening. This means that an engine with a correctly set idle speed will be easier to start than one with an incorrectly set idle speed.



The carburetor and its components are subject to increased wear caused by engine vibration. Wear can result in malfunctioning.

The factory setting for the carburetor is set for the following values.


| Height above sea level | 301 750 m (988 2,461 ft) |
|---|--------------------------|
| Ambient tempera- | 16 24 °C (61 75 °F) |
| ture | |
| Super unleaded (95 octane) mixed with 2-stroke engine oil | |
| (1.60) (🗐 n. 125) | |

The idle speed is adjusted with adjusting screw 1.

The idle mixture is adjusted using the idle air adjusting screw 2.



15.5 Carburetor - adjusting the idle speed 🔌



 Screw in idle air adjusting screw all the way and turn it to the specified basic setting.



Info

The basic adjustment is shown under the respective model.

- Run the engine until warm.

Guideline

Warming-up phase

≥ 5 min



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.
- Adjust the idle speed with adjusting screw 2.
 Guideline

Choke function deactivated – The choke lever is pushed in to the stop. (p. 16)

Idle speed 1,400 ... 1,500 rpm

- Turn idle air adjusting screw slowly in a clockwise direction until the idle speed begins to fall.
- Note the position and turn the idle air adjusting screw slowly counterclockwise until the idle speed again begins to fall.
- Adjust to the point between these two positions with the highest idle speed.



Info

If there is a big engine speed rise, reduce the idle speed to a normal level and repeat the above steps. If the procedure described here does not lead to satisfactory results, the cause may be a wrongly dimensioned idling jet.

If you can turn the idle air adjusting screw to the end without any change of engine speed, mount a smaller idling jet.

After changing the jet, start from the beginning with the adjusting steps.

Following extreme air temperature or altitude changes, adjust the idle speed again.

15.6 Plug-in connector of ignition timing map adjustment



Plug-in connector **1** of the ignition timing map adjustment is located on the frame under the fuel tank.

Possible states

- Soft The plug-in connector of the ignition timing map adjustment is disconnected to achieve better rideability.
- Performance The plug-in connector of the ignition timing map adjustment is joined to achieve higher performance.

15.7 Changing the ignition timing map

Switching the ignition timing map from Performance to Soft

- Disconnect plug-in connector of the ignition timing map adjustment. (Figure K01214-10 ♥ p. 104)
 - ✓ Soft better rideability

Switching the ignition timing map from Soft to Performance


- Join plug-in connector **①** of the ignition timing map adjustment. (Figure K01214-10 [□] p. 104)
 - ✓ Performance better performance

15.8 Checking the basic position of the shift lever



Info


When driving, the shift lever must not touch the rider's boot when in the basic position. When the shift lever keeps touching the boot, the transmission will be subject to an excessive load.




| Distance between shift lever | 10 20 mm (0.39 |
|------------------------------|----------------|
| and upper edge of boot | 0.79 in) |

- » If the distance does not meet specifications:

15.9 Adjusting the basic position of the shift lever 🔌



 Remove screw 1 with the washers and take off shift lever 2.



- Clean gear teeth of the shift lever and shift shaft.
- Mount the shift lever on the shift shaft in the required position and engage gearing.

i

Info

The range of adjustment is limited.


The shift lever must not come into contact with any other vehicle components during the shift procedure.

Mount and tighten screw 1 with the washers.

Guideline

| Screw, shift | M6 | 14 Nm (10.3 lbf ft) |
|--------------|----|---------------------|
| lever | | Loctite®243™ |

15.10 Engine characteristic – auxiliary spring



The auxiliary spring is located on the right side of the engine below the water pump cover.

Possible states

- Auxiliary spring with yellow marking Auxiliary spring mounted at the factory with medium tuning (standard) for good rideability.
- Auxiliary spring with green marking Auxiliary spring for even softer performance.
- Auxiliary spring with red marking Auxiliary spring for aggressive performance.

The engine characteristic can be influenced by different spring strengths of auxiliary spring 1.

15.11 Engine characteristic – adjusting the auxiliary spring 4



Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.


- Do not touch any parts such as the exhaust system, radiator, engine, shock absorber, or brake system before the vehicle parts have cooled down.
- Let the vehicle parts cool down before you perform any work on the vehicle.

Preparatory work

Tilt the motorcycle to the left and secure against falling in this position.


Guideline

| Angle of title approx. | 45° |
|------------------------|-----|
|------------------------|-----|




Main work

Remove screws 1.



- Remove cap **2**, adjusting spring **3**, auxiliary spring **4**, and spring insert **5** from the clutch cover.
- Pull both springs off of the spring insert.



Auxiliary spring with yellow marking (54637072300)

Auxiliary spring with green marking (54837072100)

Auxiliary spring with red marking (54837072000)

✓ The recess in spring insert **5** engages in the angle lever.



Info

Screw **6** must not be turned as this would worsen the engine characteristic.

- Check the O-ring in the cap.
- Position the cap.
- Mount and tighten the screws.

Guideline

| Screw, exhaust con- | M5 | 4 Nm (3 lbf ft) |
|---------------------|----|-----------------|
| trol cover | | |

•

16.1 **Emptying the carburetor float chamber**



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.



Note

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



Info

Carry out work with a cold engine.

Water in the float chamber results in malfunctioning.



Preparatory work

- Turn tap handle of the fuel tap to the **OFF** position.
 - ✓ Fuel no longer flows from the fuel tank to the carburetor.



- Place a cloth under the carburetor to capture the draining fuel.
- Remove screw plug 1.
- Fully drain the fuel.
- Mount and tighten the screw plug.



16.2 Checking the gear oil level




Info

The gear oil level must be checked when the engine is cold.

Preparatory work

Stand the motorcycle upright on a horizontal surface.

- Detach the foot brake lever spring.
- Remove gear oil level monitoring screw 1.




A small quantity of gear oil must run out of the drilled hole.

- » If no gear oil runs out:
 - Add the gear oil. ◀ (ՀՀ p. 109)
- Mount and tighten the gear oil level monitoring screw.

| Screw, gear oil level | M6 | 8 Nm (5.9 lbf ft) |
|-----------------------|----|-------------------|
| monitoring | | |

Attach the foot brake lever spring.



16.3 Changing the gear oil 4



Warning

Danger of scalding Engine and gear oil get very hot when the motorcycle is ridden.

- Wear suitable protective clothing and safety gloves.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



Environmental hazard Hazardous substances cause environmental damage.

Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.




Drain the gear oil while the engine is at operating temperature.

Preparatory work

- Park the motorcycle on a level surface.
- Position an appropriate container under the engine.

- Remove gear oil drain plug 1 with magnet.
- Let the gear oil drain fully.
- Thoroughly clean the gear oil drain plug with magnet.
- Clean the sealing surface on the engine.
- Mount and tighten gear oil drain plug with the magnet and a new seal ring.





듵 401955-11

Guideline

| Gear oil drain plug | M12x1.5 | 20 Nm (14.8 lbf ft) |
|---------------------|---------|---------------------|
| with magnet | | |

Remove filler plug **2** with the O-ring, and fill up with gear oil.

| Gear oil | 0.80 I | Engine oil |
|----------|------------|------------|
| | (0.85 qt.) | (15W/50) |
| | | (🕮 p. 124) |

Mount and tighten the filler plug together with the O-ring.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.
- Start the engine and check for leaks.

Finishing work

Check the gear oil level. (p. 108)

16.4 Adding the gear oil 🔌




Too little gear oil or poor-quality gear oil results in premature wear to the transmission. Gear oil must only be topped up when the engine is cold.


Preparatory work

Park the motorcycle on a level surface.

Remove gear oil level monitoring screw 1.







- Remove filler plug **2** with the O-ring.
- Add gear oil until it emerges from the drill hole of the gear oil level monitoring screw.

Engine oil (15W/50) (p. 124)

Mount and tighten the gear oil level monitoring screw. Guideline

| Screw, gear oil level | M6 | 8 Nm (5.9 lbf ft) |
|-----------------------|----|-------------------|
| monitoring | | |

Mount and tighten filler plug **2** with the O-ring.

Finishing work



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.
- Start the engine and check for leaks.

4

17.1 Cleaning the motorcycle

Note

Material damage Components become damaged or destroyed if a pressure cleaner is used incorrectly.

The high pressure forces water into the electrical components, connectors, throttle cables, and bearings, etc. Pressure which is too high causes malfunctions and destroys components.

- Do not direct the water jet directly on to electrical components, connectors, throttle cables or bearings.
- Maintain a minimum distance between the nozzle of the pressure cleaner and the component.
 Minimum clearance
 60 cm (23.6 in)



Note


Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

To maintain the value and appearance of the motorcycle over a long period, clean it regularly. Avoid direct sunshine when cleaning the motorcycle.



- Close off the exhaust system to keep water from entering.
- Remove coarse dirt particles with a gentle water jet.
- Spray heavily soiled parts with a normal commercial motorcycle cleaner and then brush off with a soft brush.

Motorcycle cleaner (p. 126)



Info

Use warm water containing normal motorcycle cleaner and a soft sponge.

Never apply motorcycle cleaner to a dry vehicle; always rinse the vehicle with water first.

- After rinsing the motorcycle with a gentle spray of water, allow it to dry thoroughly.
- Empty the carburetor float chamber. ♣ (♠ p. 107)
- Remove the closure of the exhaust system.



Warning

Danger of accidents Moisture and dirt impair the brake system.

- Brake carefully several times to dry out and remove dirt from the brake linings and the brake discs.
- After cleaning, ride the vehicle a short distance until the engine warms up.



Info

The heat produced causes water at inaccessible locations in the engine and on the brake system to evaporate.

- After the motorcycle has cooled down, lubricate all moving parts and pivot points.
- Clean the chain. (p. 65)
- Treat bare metal (except for brake discs and the exhaust system) with a corrosion inhibitor.

Preserving materials for paints, metal and rubber ($\ensuremath{\belowdisplayskip}$ p. 126)

 Treat all plastic parts and powder-coated parts with a mild cleaning and care product.

Special cleaner for glossy and matte paint finishes, metal and plastic surfaces ($\ensuremath{\mathbb{Q}}$ p. 127)

4

18.1 Storage



Warning

Danger of poisoning Fuel is poisonous and a health hazard.


- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.



Info

If you plan to garage the motorcycle for a longer period, perform the following steps or have them performed.

Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.



 When refueling for the last time before taking the motorcycle out of service, add fuel additive.

Fuel additive (p. 126)

- Refuel. (🕮 p. 30)
- Clean the motorcycle. (
 p. 111)
- Change the gear oil. ◀ (IP p. 108)
- Empty the carburetor float chamber. ◄ (□ p. 107)
- Check tire pressure. (p. 91)
- Store the vehicle in a dry location that is not subject to large fluctuations in temperature.



Info

KTM recommends jacking up the motorcycle.

- Cover the vehicle with a tarp or similar cover that is permeable to air.




Info

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion. Avoid running the engine for a short time only. Because the engine will not warm up sufficiently, the water vapor produced during combustion will condense, causing engine parts and the exhaust system to rust.

•

18.2 Preparing for use after storage



- Remove the motorcycle from the lift stand. (p. 44)
- Perform checks and maintenance measures when preparing for use. (
 p. 26)
- Make a test ride.

4

19 TROUBLESHOOTING

| Faults | Possible cause | Action |
|---|---|---|
| Engine stalls or is popping into the carburetor | Engine takes in bad air | Check the intake flange and carburetor for tightness. |
| | The connector or ignition coil is loose or oxidized | Clean the connector and treat it with contact spray. |
| Engine overheats | Too little coolant in cooling sys- | Check the cooling system for leakage. |
| | tem | Check the coolant level. (|
| | Too little air stream | Switch off engine when stationary. |
| | Radiator fins very dirty | Clean the radiator fins. |
| | Foam formation in cooling sys- | Drain the coolant. ◀ (♥ p. 94) |
| | tem | – Refill with coolant. 4 (🕮 p. 95) |
| | Damaged cylinder head or | Check the cylinder head and cylinder |
| | cylinder head gasket | head gasket. |
| | Bent radiator hose | Change the radiator hose. |
| White smoke emission (steam in exhaust gas) | Damaged cylinder head or cylinder head gasket | Check the cylinder head and cylinder head gasket. |
| Gear oil exits at the vent hose | Too much gear oil added | - Check the gear oil level. (🕮 p. 108) |
| Water in the gear oil | Damaged radial shaft seal ring or water pump | Check the radial shaft seal ring and the water pump. |

20.1 Engine

| Design | 1-cylinder 2-stroke engine, water-cooled, with reed intake and exhaust control |
|---|---|
| Displacement | 249 cm ³ (15.19 cu in) |
| Stroke | 72 mm (2.83 in) |
| Hole | 66.4 mm (2.614 in) |
| Exhaust control - setting measurement | 1.8 ± 0.2 mm (0.071 ± 0.008 in) |
| Crankshaft bearing | 1 grooved ball bearing/1 roller bearing |
| Conrod bearing | Needle bearing |
| Piston pin bearing | Needle bearing |
| Piston | Cast aluminum |
| Piston rings | 2 half keystone rings |
| X distance (upper edge of piston to upper edge of cylinder) | 0 0.10 mm (0 0.0039 in) |
| Z distance (height of control flap) | 49.0 mm (1.929 in) |
| Primary transmission | 26:73 |
| Clutch | Multidisc clutch in oil bath/hydraulically activated |
| Transmission | 5-gear transmission, claw shifted |
| Transmission ratio | |
| first-gear | 14:28 |
| second-gear | 16:26 |
| third-gear | 18:24 |
| fourth-gear | 21:24 |
| fifth-gear | 22:21 |
| Ignition system | Contactless controlled fully electronic ignition with digital ignition adjustment |
| Spark plug | NGK BR 8 ECM |
| Spark plug electrode gap | 0.60 mm (0.0236 in) |
| Starting aid | Kick starter system |
| | |

20.2 Engine tightening torques

| Screw, inner membrane sheets | EJOTDELTA PT® 35x25 | 1 Nm (0.7 lbf ft) | |
|-------------------------------------|---------------------|-------------------|--------------|
| Screw, membrane support plate | EJOTDELTA PT® 30x12 | 1 Nm (0.7 lbf ft) | |
| Screw, outer membrane sheets | EJOTDELTA PT® 30x6 | 1 Nm (0.7 lbf ft) | |
| Screw, angle lever, exhaust control | M5 | 6 Nm (4.4 lbf ft) | |
| | | | Loctite®243™ |
| Screw, bearing retainer | M5 | 6 Nm (4.4 lbf ft) | |
| | | | Loctite®243™ |
| Screw, clutch spring retainer | M5 | 6 Nm (4.4 lbf ft) | |
| Screw, crankshaft speed sensor | M5 | 6 Nm (4.4 lbf ft) | |
| | | | Loctite®243™ |
| Screw, exhaust control bearing | M5 | 6 Nm (4.4 lbf ft) | |
| support | | | Loctite®243™ |
| Screw, exhaust control cap | M5 | 5 Nm (3.7 lbf ft) | |
| Screw, exhaust control cover | M5 | 4 Nm (3 lbf ft) | |

| Screw, locking lever | M5 | 6 Nm (4.4 lbf ft) Loctite®243™ |
|---|-----------|--|
| Screw, retaining bracket of exhaust control | M5 | 6 Nm (4.4 lbf ft) Loctite®2701™ |
| Screw, stator | M5 | 6 Nm (4.4 lbf ft) Loctite®243™ |
| Bleeder screw, cylinder head | M6 | 10 Nm (7.4 lbf ft) |
| Nut, water pump impeller | M6 | 5 Nm (3.7 lbf ft) |
| | | Loctite®243™ |
| Screw, alternator cover | M6 | 8 Nm (5.9 lbf ft) |
| Screw, clutch slave cylinder | M6 | 10 Nm (7.4 lbf ft) |
| Screw, control flap, exhaust con- | M6 | 10 Nm (7.4 lbf ft) |
| trol | MC | Loctite®243™ |
| Screw, engine case | M6 | 10 Nm (7.4 lbf ft) |
| Screw, exhaust control thrust bearing | M6 | 8 Nm (5.9 lbf ft) Loctite®243™ |
| Screw, exhaust flange | M6 | 8 Nm (5.9 lbf ft) |
| Screw, gear oil level monitoring | M6 | 8 Nm (5.9 lbf ft) |
| Screw, intake flange/reed valve housing | M6 | 6 Nm (4.4 lbf ft) |
| Screw, intermediate clutch cover | M6 | 10 Nm (7.4 lbf ft) |
| Screw, kick starter intermediate | M6 | 10 Nm (7.4 lbf ft) |
| gear steel pin | | Loctite®243™ |
| Screw, kick starter stop plate | M6 | 10 Nm (7.4 lbf ft) Loctite®243™ |
| Screw, outer clutch cover | M6 | 8 Nm (5.9 lbf ft) |
| Screw, shift drum locating | M6 | 10 Nm (7.4 lbf ft) Loctite®243™ |
| Screw, shift lever | M6 | 14 Nm (10.3 lbf ft) Loctite®243™ |
| Screw, water pump cover | M6 | 10 Nm (7.4 lbf ft) |
| Vacuum connection, housing breather | M6 | 2 Nm (1.5 lbf ft) |
| Screw, balancer shaft | M8 | 30 Nm (22.1 lbf ft) Loctite®243™ |
| Screw, cylinder head | M8 | 27 Nm (19.9 lbf ft) |
| Screw, kick starter lever | M8 | 25 Nm (18.4 lbf ft) |
| Nut, cylinder base | M10 | Loctite®2701™ 35 Nm (25.8 lbf ft) |
| , , | M10 | 20 Nm (25.8 lbf ft) |
| Screw, cylinder base Screw, drive chain engine sprocket | M10 | 60 Nm (14.8 lbf ft) |
| Screw, unive chain engine sprocket | IAITO | 60 Nm (44.3 lbf ft) Loctite®2701™ |
| Nut, rotor | M12x1 | 60 Nm (44.3 lbf ft) |
| Gear oil drain plug with magnet | M12x1.5 | 20 Nm (14.8 lbf ft) |
| Spark plug | M14x1.25 | 25 Nm (18.4 lbf ft) |
| Nut, inner clutch hub | M18x1.5 | 100 Nm (73.8 lbf ft) Loctite® 648™ |
| Nut, primary gear wheel | M18LHx1.5 | 150 Nm (110.6 lbf ft) Loctite® 648™ |

20.3 Carburetor

| Carburetor type | MIKUNI TMX 38 |
|----------------------------------|----------------------------|
| Carburetor identification number | TMX 38 89 |
| Needle position | 3rd position from top |
| Jet needle | 6BFY42-71 (6BFY43-71) |
| Main jet | 450 (430, 440, 460, 470) |
| Idling jet | 35 (30 / 32.5 / 37.5 / 40) |
| Choke nozzle | 80 |
| Needle jet | S-1 |
| Idle air adjusting screw | |
| Open | 1.5 turns |

20.3.1 Carburetor tuning

MIKUNI TMX 38

| ASL | ТЕМР | -207 °C (-4 19 °F) | -6 5 °C (21 41 °F) | 6 15 °C (43 59 °F) | 16 24 °C (61 75 °F) | 25 36 °C (77 97 °F) | 37 49 °C (99 120 °F) |
|---|-------------------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|
| 2,301 3,000 m (7,549 9,843 ft) | ASO IJ NDL POS MJ | 1.5 35 42-71 3 450 | 1.5 32.5 42-71 3 440 | 2 32.5 42-71 3 430 | 1.5 32.5 43-71 2 430 | 1.5 30 43-71 2 420 | |
| 1,501 2,300 m (4,925 7,546 ft) | ASO IJ NDL POS MJ | 1.5 32.5 43-71 3 450 | 1.5 35 42-71 3 450 | 1.5 32.5 42-71 3 440 | 2 32.5 42-71 3 430 | 1.5 32.5 43-71 2 430 | 1.5 30 43-71 2 420 |
| 751 1,500 m (2,464 4,921 ft) | ASO IJ NDL POS MJ | 1.5 35 43-71 3 460 | 1.5 32.5 43-71 3 450 | 1.5 35 42-71 3 450 | 1.5 32.5 42-71 3 440 | 2 32.5 42-71 3 430 | 1.5 32.5 43-71 2 430 |
| 301 750 m (988 2,461 ft) | ASO IJ NDL POS MJ | 1.5 37.5 43-71 3 470 | 1.5 35 43-71 3 460 | 1.5 32.5 43-71 3 450 | 1,5 35 42-71 3 450 | 1.5 32.5 42-71 3 440 | 2 30 42-71 3 430 |
| 0 300 m (0 984 ft) | ASO IJ NDL POS MJ | 1.5 37.5 43-71 3 470 | 1.5 35 43-71 3 460 | 1.5 32.5 43-71 3 450 | 1.5 35 42-71 3 450 | 1.5 32.5 42-71 3 440 | 2 32.5 42-71 3 430 |

| ASL | Sea level |
|------|-------------------------------|
| TEMP | Temperature |
| ASO | Idle air adjusting screw open |
| IJ | Idling jet |
| NDL | Needle |
| POS | Needle position from top |
| MJ | Main jet |

Info

Do not use on sandy terrain.

20.3.2 Carburetor - basic setting for sandy surfaces

| Idle air adjusting screw | | |
|--------------------------|-----------------------|--|
| Open | 1.5 turns | |
| Idling jet | 37.5 | |
| Jet needle | 6BFY43-71 | |
| Needle position | 3rd position from top | |
| Main jet | 470 | |

i

Info

If the engine is not running smoothly, use a smaller main jet.

20.4 Capacities

20.4.1 Gear oil

| ear oil | 0.80 I (0.85 qt.) | Engine oil (15W/50) (🕮 p. 124) |
|---------|-------------------|--------------------------------|
|---------|-------------------|--------------------------------|

20.4.2 Coolant

| Coolant | 1.2 l (1.3 qt.) | Coolant (p. 124) |
|---------|-----------------|-------------------|

20.4.3 Fuel

| Total fuel tank capacity, approx. | 7.5 I (1.98 US gal) | Super unleaded (95 octane) mixed |
|-----------------------------------|---------------------|----------------------------------|
| | | with 2-stroke engine oil (1:60) |
| | | (🙉 p. 125) |

20.5 Chassis

| Frame | Central tube frame made of chrome molybdenum steel |
|--------------------------|--|
| | tubing |
| Fork | WP XACT 5448 |
| Suspension travel | · |
| front | 310 mm (12.2 in) |
| rear | 300 mm (11.81 in) |
| Fork offset | 22 mm (0.87 in) |
| Shock absorber | WP XACT 5750 |
| Brake system | Disc brakes, floating brake calipers |
| Brake discs - diameter | · |
| front | 260 mm (10.24 in) |
| rear | 220 mm (8.66 in) |
| Brake discs - wear limit | · |
| front | 2.5 mm (0.098 in) |
| rear | 3.5 mm (0.138 in) |
| Offroad tire pressure | • |

| front | 1.0 bar (15 psi) |
|-------------------------------------|---------------------------------|
| rear | 1.0 bar (15 psi) |
| Secondary ratio | 14:49 |
| Chain | 5/8 x 1/4" |
| Rear sprockets available | 48, 50, 52 |
| Steering head angle | 63.9° |
| Wheelbase | 1,485 ± 10 mm (58.46 ± 0.39 in) |
| Seat height unloaded | 950 mm (37.4 in) |
| Ground clearance unloaded | 375 mm (14.76 in) |
| Weight without fuel, approx. | 95.5 kg (210.5 lb.) |
| Maximum permissible front axle load | 145 kg (320 lb.) |
| Maximum permissible rear axle load | 190 kg (419 lb.) |
| Maximum permissible overall weight | 335 kg (739 lb.) |

20.6 Electrical system

20.7 Tires

| Front tire | Rear tire |
|---|--|
| 80/100 - 21 51M TT Dunlop GEOMAX MX33F | 110/90 - 19 62M TT Dunlop GEOMAX MX33 |

The tires specified represent one of the possible series production tires. Additional information is available in the Service section under: http://www.ktm.com

20.8 Fork

| Fork article number | 34.18.8U.03 | |
|---------------------|--------------------|--|
| Fork | WP XACT 5448 | |
| Compression damping | | |
| Comfort | 17 clicks | |
| Standard | 12 clicks | |
| Sport | 7 clicks | |
| Rebound damping | | |
| Comfort | 23 clicks | |
| Standard | 18 clicks | |
| Sport | 13 clicks | |
| Air pressure | 10.4 bar (151 psi) | |
| Fork length | 950 mm (37.4 in) | |

| Oil capacity external mechanism left | 230 ± ½ ml (7.78 ± 0.34 fl. oz.) | Fork oil (SAE 4) (48601166S1) (🕮 p. 125) |
|---------------------------------------|-----------------------------------|---|
| Oil capacity external mechanism right | 230 ± 10 ml (7.78 ± 0.34 fl. oz.) | Fork oil (SAE 4) (48601166S1) (🕮 p. 125) |
| Grease capacity, left cartridge | 5 g (0.18 oz) | Special grease (00062010053) (p. 127) |
| Oil capacity, right cartridge | 380 ml (12.85 fl. oz.) | Fork oil (SAE 4) (48601166S1) (🕮 p. 125) |

20.9 Shock absorber

| Shock absorber article number | 18.18.7U.03 |
|---|---------------------|
| Shock absorber | WP XACT 5750 |
| Lowspeed compression damping | |
| Comfort | 17 clicks |
| Standard | 15 clicks |
| Sport | 13 clicks |
| Highspeed compression damping | |
| Comfort | 2.5 turns |
| Standard | 2 turns |
| Sport | 1.5 turns |
| Rebound damping | |
| Comfort | 17 clicks |
| Standard | 15 clicks |
| Sport | 13 clicks |
| Spring preload | 7 mm (0.28 in) |
| Spring rate | |
| Weight of rider: 65 75 kg (143 165 lb.) | 39 N/mm (223 lb/in) |
| Weight of rider: 75 85 kg (165 187 lb.) | 42 N/mm (240 lb/in) |
| Weight of rider: 85 95 kg (187 209 lb.) | 45 N/mm (257 lb/in) |
| Spring length | 260 mm (10.24 in) |
| Gas pressure | 10 bar (145 psi) |
| Static sag | 35 mm (1.38 in) |
| Riding sag | 105 mm (4.13 in) |
| Fitted length | 477 mm (18.78 in) |
| Shock absorber fluid (p. 125) | SAE 2.5 |

20.10 Chassis tightening torques

| Screw, start button | M3 | 0.4 Nm (0.3 lbf ft) |
|----------------------------------|------|----------------------|
| Screw, switch-off button | M3 | 0.4 Nm (0.3 lbf ft) |
| Screw, fixed grip | M4 | 5 Nm (3.7 lbf ft) |
| | | Loctite®243™ |
| Screw, service hour counter | M4 | 0.8 Nm (0.59 lbf ft) |
| Spoke nipple, front wheel | M4.5 | 6 Nm (4.4 lbf ft) |
| Spoke nipple, rear wheel | M4.5 | 6 Nm (4.4 lbf ft) |
| Remaining nuts, chassis | M5 | 5 Nm (3.7 lbf ft) |
| Remaining screws, chassis | M5 | 5 Nm (3.7 lbf ft) |
| Screw, shock absorber adjusting | M5 | 5 Nm (3.7 lbf ft) |
| ring | | |
| Screws on main silencer | M5 | 7 Nm (5.2 lbf ft) |
| Remaining nuts, chassis | M6 | 10 Nm (7.4 lbf ft) |
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
| Screw, ball joint of push rod on | M6 | 10 Nm (7.4 lbf ft) |
| foot brake cylinder | | Loctite®243™ |

| Screw, chain sliding guard | M6 | 10 Nm (7.4 lbf ft) |
|-----------------------------------|---------|---|
| , | | Loctite®243™ |
| Screw, front brake disc | M6 | 14 Nm (10.3 lbf ft) |
| | N.C. | Loctite®243™ |
| Screw, rear brake disc | M6 | 14 Nm (10.3 lbf ft) |
| Screw, throttle grip | M6 | 5 Nm (3.7 lbf ft) |
| Nut, foot brake lever stop | M8 | 20 Nm (14.8 lbf ft) |
| Nut, rear sprocket screw | M8 | 35 Nm (25.8 lbf ft) |
| , | | Loctite®2701™ |
| Nut, rim lock | M8 | 12 Nm (8.9 lbf ft) |
| Remaining nuts, chassis | M8 | 25 Nm (18.4 lbf ft) |
| Remaining screws, chassis | M8 | 25 Nm (18.4 lbf ft) |
| Screw, bottom triple clamp | M8 | 12 Nm (8.9 lbf ft) |
| Screw, chain sliding piece | M8 | 15 Nm (11.1 lbf ft) |
| Screw, engine brace on frame | M8x15 | 25 Nm (18.4 lbf ft) |
| | | Loctite®2701™ |
| Screw, fork stub | M8 | 15 Nm (11.1 lbf ft) |
| Screw, front brake caliper | M8 | 25 Nm (18.4 lbf ft) |
| Screw, handlebar clamp | M8 | 20 Nm (14.8 lbf ft) |
| Screw, manifold | M8 | 15 Nm (11.1 lbf ft) |
| Screw, subframe bottom | M8x18 | 30 Nm (22.1 lbf ft) |
| Screw, Subtraine bottom | IVIOXIO | Loctite®2701™ |
| Screw, subframe top | M8x20 | 35 Nm (25.8 lbf ft) |
| | | Loctite®2701™ |
| Screw, top steering stem | M8 | 20 Nm (14.8 lbf ft) Loctite®243™ |
| Screw, top triple clamp | M8 | 17 Nm (12.5 lbf ft) |
| Engine bracket screw | M10 | 60 Nm (44.3 lbf ft) |
| Remaining nuts, chassis | M10 | 45 Nm (33.2 lbf ft) |
| Remaining screws, chassis | M10 | 45 Nm (33.2 lbf ft) |
| Screw, bottom shock absorber | M10 | 60 Nm (44.3 lbf ft) |
| | | Loctite®2701™ |
| Screw, handlebar support | M10 | 40 Nm (29.5 lbf ft) Loctite®243™ |
| Screw, top shock absorber | M10 | 60 Nm (44.3 lbf ft) |
| Nut, angle lever to link fork | M14x1.5 | Loctite®2701™ 60 Nm (44.3 lbf ft) |
| Nut, frame on linkage lever | M14x1.5 | 60 Nm (44.3 lbf ft) |
| Nut, linkage lever on angle lever | M14x1.5 | 60 Nm (44.3 lbf ft) |
| Nut, fork pivot | M16x1.5 | 100 Nm (73.8 lbf ft) |
| Screw, front wheel spindle | M20x1.5 | 35 Nm (25.8 lbf ft) |
| Screw, top steering head | M20x1.5 | 12 Nm (8.9 lbf ft) |
| Screw-in fitting, cooling system | M24x1.5 | 18 Nm (13.3 lbf ft) |
| | | Loctite®243™ |
| Nut, rear wheel spindle | M25x1.5 | 80 Nm (59 lbf ft) |

Brake fluid DOT 4 / DOT 5.1

Standard/classification

DOT

Guideline

 Use only brake fluid that complies with the specified standard (see specifications on the container) and that exhibits the corresponding properties.

Recommended supplier

Castrol

REACT PERFORMANCE DOT 4

MOTOREX®

Brake Fluid DOT 5.1

Coolant

Guideline

- Only use high-grade, silicate-free coolant with corrosion inhibitor additive for aluminum motors. Low grade and unsuitable antifreeze causes corrosion, deposits and frothing.
- Do not use pure water as only coolant is able to meet the requirements needed in terms of corrosion protection and lubrication properties.
- Only use coolant that complies with the requirements stated (see specifications on the container) and that has the relevant properties.

| Antifreeze protection to at least | -25 °C (-13 °F) |
|-----------------------------------|-----------------|
| · · · · · · · · · - · - · | |

The mixture ratio must be adjusted to the necessary antifreeze protection. Use distilled water if the coolant needs to be diluted.

The use of premixed coolant is recommended.

Observe the coolant manufacturer specifications for antifreeze protection, dilution and miscibility (compatibility) with other coolants.

Recommended supplier MOTOREX®

- COOLANT M3.0

Engine oil (15W/50)

Standard/classification

- JASO T903 MA2 (🕮 p. 128)
- SAE (♀ p. 128) (15W/50)

Guideline

 Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Recommended supplier MOTOREX®

Top Speed 4T

Engine oil, 2-stroke

Standard/classification

– JASO FD (🕮 p. 128)

Guideline

Only use high grade 2-stroke engine oil of a reputable brand.

Fully synthetic

Recommended supplier MOTOREX®

- Cross Power 2T

Fork oil (SAE 4) (48601166S1)

Standard/classification

- SAE (♀ p. 128) (SAE 4)

Guideline

 Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Shock absorber fluid (SAE 2.5) (50180751S1)

Standard/classification

- SAE (ℚ p. 128) (SAE 2.5)

Guideline

 Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Super unleaded (ROZ 95/RON 95/PON 91)

Standard/classification

- DIN EN 228 (ROZ 95/RON 95/PON 91)

Guideline

- Only use unleaded super fuel that matches or is equivalent to the specified fuel grade.
- Fuel with an ethanol content of up to 10 % (E10 fuel) is safe to use.



Info

Do **not** use fuel containing methanol (e. g. M15, M85, M100) or more than 10 % ethanol (e. g. E15, E25, E85, E100).

Super unleaded (95 octane) mixed with 2-stroke engine oil (1:60)

Standard/classification

- DIN EN 228
- JASO FD (□ p. 128) (1:60)

Mixture ratio

| 1:60 | Engine oil, 2-stroke (🕮 p. 124) |
|------|---|
| | Super unleaded (ROZ 95/RON 95/PON 91) (p. 125) |

Recommended supplier MOTOREX®

- Cross Power 2T

Air filter cleaner

Recommended supplier MOTOREX®

Racing Bio Dirt Remover

Chain cleaner

Recommended supplier MOTOREX®

Chain Clean

Fuel additive

Recommended supplier MOTOREX®

Fuel Stabilizer

High viscosity grease

Recommended supplier SKF^{\otimes}

– LGHB 2

Long-life grease

Recommended supplier MOTOREX®

- Bike Grease 2000

Motorcycle cleaner

Recommended supplier MOTOREX®

Moto Clean

Off-road chain spray

Recommended supplier MOTOREX®

Chainlube Offroad

Oil for foam air filter

Recommended supplier MOTOREX®

- Racing Bio Liquid Power

Preserving materials for paints, metal and rubber

Recommended supplier MOTOREX®

Moto Protect

Special cleaner for glossy and matte paint finishes, metal and plastic surfaces

Recommended supplier MOTOREX®

Quick Cleaner

Special grease (00062010053)

Recommended supplier
Klüber Lubrication®

- KLÜBERFOOD NH1 34-401

Universal oil spray

Recommended supplier MOTOREX®

- Joker 440 Synthetic

JASO T903 MA2

Different technical development directions required a separate specification for motorcycles – the **JASO T903 MA2** standard.

Earlier, engine oils from the automobile industry were used for motorcycles because there was no separate motorcycle specification.

Whereas long service intervals are demanded for automobile engines, the focus for motorcycle engines is on high performance at high engine speeds.

In most motorcycle engines, the transmission and clutch are lubricated with the same oil.

The **JASO T903 MA2** standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

JASO FD

JASO FD is a classification for a 2-stroke engine oil that was specifically developed for the extreme demands of racing. Thanks to first-rate synthetic esters and specially designed additives, superb combustion is achieved even under extreme operating conditions.

| Art. no. | Article number |
|----------|----------------|
| ca. | circa |
| cf. | compare |
| e.g. | for example |
| etc. | et cetera |
| i.a. | inter alia |
| no. | number |
| poss. | possibly |

| Accessories 9 checking 65 Air filter Cleaning 59 installing 60 removing 58 Air filter box cleaning 59 Air filter box cleaning 59 Air filter box cleaning 59 Air filter box celaning 59 Air filter box cover installing 58 | | Chain tension |
|--|------------------------------|------------------------------------|
| Air filter Choke 16 cleaning 59 Clutch 16 installing 60 fluid level, checking/correcting 7.2 Air filter box Cleaning 59 Clutch lever 1.4 cleaning 59 Clutch lever 1.4 basic position, adjusting 7.2 Air suspension XACT 5448 33 Coolant Antifreeze checking 93 Coolant fevel checking 93 Coolant level changing 9.2 Auxiliary substances 9 Coolant level 9.2 checking 93 Coolant level 9.2 checking with rider's weight 33 D D Basic chassis setting checking with rider's weight 33 D D Brake dids 0 D D D Brake dids 0 D D D D Brake fluid level 10 D D D D D D D | A | • |
| Cleaning 59 | Accessories | checking65 |
| installing | Air filter | Choke 16 |
| Air filter box cleaning 58 fluid, changing 73 Air filter box cleaning 59 Clutch lever 14 cleaning 59 Clutch lever 14 Air filter box cover installing 58 Compression damping 72 Air suspensing vaccing 60 Coolant Coolant removing 57 Changing 97 Air suspension XACT 5448 33 Coolant Changing 97 Air suspension XACT 5448 33 Coolant Changing 99 Auxiliary substances 9 Coolant level Checking 99 Checking 93 Coolant level Coolant level Coolant level Brake fluid 30 Difficult operating conditions 20 Customer service 9 Coolant level 93 Brake fluid level 75 Graw brake, checking 82 Graw brake, checking 82 Graw brake, checking 84 Engine For fear brake, checking 78 Engine Coolant level < | 3 | Clutch |
| Air filter box cleaning 59 cleaning 59 installing 58 preparing for securing 67 removing 57 Air suspension XACT 5448 33 Antifreeze checking 93 Autifreeze checking 69 Basic chassis setting checking 75 Brake discs 69 Brake fluid front brake, checking 76 rear brake, checking 76 rear brake, checking 78 front brake, checking 78 florit brake, checking 78 for brake lever 79 basic position, adjusting 81 free travel, checking 81 free travel, checking 81 free travel, checking 81 free travel, checking 81 | _ | |
| Cleaning 59 | | fluid, changing |
| Compression damping Fork, adjusting Fork | | |
| Installing | cleaning 59 | basic position, adjusting |
| December Coolant Coolant | Air filter box cover | Compression damping |
| Temoving | | fork, adjusting41 |
| Air suspension XACT 5448 33 draining 99 Antifreeze checking 93 Auxiliary substances 9 checking 93-94 Basic chassis setting checking with rider's weight 33 Brake discs checking 75 Brake fluid front brake, adding 77 rear brake, adding 77 rear brake, checking 76 rear brake, checking 76 rear brake, checking 76 rear brake, checking 76 of rear brake, checking 78 of rear brake, checking 89 of rear brake, checking 89 of rear brake, checking 89 of rear brake, checking 99 of rear bra | | Coolant |
| Antifreeze checking | - | changing 97 |
| Checking | Air suspension XACT 5448 | - |
| Auxiliary substances 9 Checking 93-94 B Cooling system 93 Cooling system 93 Customer service 9 Customer service | Antifreeze | refilling |
| Cooling system | checking 93 | Coolant level |
| Customer service Section Secti | Auxiliary substances | checking |
| Basic chassis setting Checking with rider's weight 33 Checking with rider's weight 33 Checking 75 Checking 75 Checking 75 Checking 75 Checking 75 Checking 75 Checking 76 Checking 76 Checking 76 Checking 76 Checking 78 Checking 7 | В | |
| Strake discs Checking 75 | Basic chassis setting | Customer service |
| checking 75 dry sand 21 Brake fluid high temperatures 24 front brake, adding 77 low temperature 25 rear brake, adding 82 muddy surfaces 24 Brake fluid level slow speed 24 front brake, checking 76 wet sand 22 front brake, checking 78 wet surfaces 24 Brake linings Front brake, changing 78 front brake, checking 78 front brake, checking 78 front brake, checking 26 wet surfaces 24 Brake linings Front brake, changing 78 front brake, checking 28 running in 20 front brake, checking 84 Engine faustiary spring 105 Capacity adjusting the auxiliary spring 105 colant 120 Engine characteristic auxiliary spring 105 Carburetor checking 67 Adjusting the idle speed 103 filling up fuel | checking with rider's weight | D |
| checking 75 dry sand 21 Brake fluid high temperatures 24 front brake, adding 77 low temperature 25 rear brake, adding 82 muddy surfaces 24 Brake fluid level slow speed 24 front brake, checking 76 wet sand 22 front brake, checking 78 wet surfaces 24 Brake linings Front brake, changing 78 front brake, checking 78 front brake, checking 78 front brake, checking 26 wet surfaces 24 Brake linings Front brake, changing 78 front brake, checking 28 running in 20 front brake, checking 84 Engine faustiary spring 105 Capacity adjusting the auxiliary spring 105 colant 120 Engine characteristic auxiliary spring 105 Carburetor checking 67 Adjusting the idle speed 103 filling up fuel | Brake discs | Difficult operating conditions |
| front brake, adding 77 low temperature 25 rear brake, adding 82 muddy surfaces 24 Brake fluid level slow speed 24 front brake, checking 76 snow 25 rear brake, checking 82 wet sand 22 wet surfaces 24 Brake linings 78 front brake, checking 78 front brake, checking 78 running in 20 front brake, checking 84 running in 20 ferar brake, checking 84 running in 20 Capacity adjusting the auxiliary spring 105 coolant 120 auxiliary spring 105 gear oil 109, 120 Engine number 12 Engine sprocket checking 67 Adjusting the idle speed 103 filing up float chamber, emptying 107 filling up fluel 30 Chain forbing 67 Checking <td< td=""><td>checking</td><td></td></td<> | checking | |
| rear brake, adding 82 muddy surfaces 24 Brake fluid level slow speed 24 front brake, checking 76 wet sand 22 rear brake, checking 82 wet surfaces 24 Brake linings Front brake, changing 78 Engine front brake, checking 78 Engine of rear brake, checking 84 Engine Capacity adjusting the auxiliary spring 105 coolant 120 auxiliary spring 105 gear oil 109, 120 Engine number 12 Carburetor checking 67 Adjusting the idle speed 103 Engine sprocket checking 67 Figures 9 Carburetor tuning 100 Foot brake lever 17 basic position, adjusting the auxiliary sprin | Brake fluid | high temperatures |
| rear brake, adding 82 muddy surfaces 24 Brake fluid level slow speed 24 front brake, checking 76 wet sand 25 rear brake, checking 78 wet surfaces 24 Brake linings 78 front brake, changing 78 front brake, checking 78 front brake, changing 84 running in 20 | front brake, adding | |
| Sanow 25 | | |
| Wet sand 22 | Brake fluid level | · |
| Brake linings Engine 20 front brake, changing 78 Engine of rear brake, checking 84 running in 20 cerar brake, checking 84 Engine characteristic 30 colant 120 auxiliary spring 105 gear oil 109, 120 Engine number 12 gear oil 109, 120 Engine sprocket Carburetor checking 67 Adjusting the idle speed 103 Environment 8 float chamber, emptying 107 Figures 9 flulle control 102 Figures 9 Carburetor tuning 100 Figures 9 Chain 67 cleaning 65 Chain guide 67 basic position, adjusting 81 checking 67 Fork | front brake, checking | |
| Brake linings Front brake, changing 78 Engine of rear brake, changing rear brake, checking 84 running in 20 Capacity Engine characteristic adjusting the auxiliary spring 105 coolant 120 Engine number 12 gear oil 109, 120 Engine sprocket Carburetor checking 67 Adjusting the idle speed 103 Environment 8 float chamber, emptying ldle control 102 Figures 9 Carburetor tuning 100 Filling up 100 Chain checking checking 67 5 Foot brake lever 17 basic position, adjusting free travel, checking 81 Fork | rear brake, checking | |
| Front brake, checking 78 Engine of rear brake, changing rear brake, checking 84 running in 20 Capacity adjusting the auxiliary spring auxiliary spring 105 coolant gear oil 120 Engine number 12 gear oil 109, 120 Engine sprocket Carburetor checking 67 Adjusting the idle speed 103 Environment 8 float chamber, emptying ldle control 102 Figures 9 Carburetor tuning 100 Filling up fuel 30 Chain checking 67 basic position, adjusting 81 Chain guide checking 67 Fork | Brake linings | |
| of rear brake, changing rear brake, checking 84 running in 20 rear brake, checking C Engine characteristic Capacity adjusting the auxiliary spring 105 auxiliary spring coolant gear oil 120 gear oil Engine number 12 gear oil Carburetor checking 67 Adjusting the idle speed float chamber, emptying lde control 103 float chamber, emptying lde control 107 fluit gup Carburetor tuning 100 fluin guide Filling up fuel 30 fluin guide Chain guide characteristic Foot brake lever 12 fluing up free travel, checking 81 free travel, checking 81 frork | front brake, changing | Ē |
| c Engine characteristic Capacity adjusting the auxiliary spring 105 coolant 120 Engine number 12 gear oil 109, 120 Engine sprocket Carburetor checking 67 Adjusting the idle speed 103 Environment 8 float chamber, emptying ldle control 102 Figures 9 Carburetor tuning 100 Filling up fuel 30 Chain foot brake lever 17 basic position, adjusting 81 Chain guide 67 Fork | front brake, checking | Engine |
| C adjusting the auxiliary spring 105 | , 5 5 | running in |
| Capacity auxiliary spring 105 coolant 120 Engine number 12 gear oil 109, 120 Engine sprocket 67 Carburetor checking 67 Adjusting the idle speed 103 Environment 8 float chamber, emptying 107 Figures 9 Idle control 102 Figures 9 Carburetor tuning 100 Filling up 6 Chain 67 Foot brake lever 17 basic position, adjusting 81 free travel, checking 81 fork Fork | rear brake, checking | Engine characteristic |
| Capacity 120 Engine number 12 gear oil 109, 120 Engine sprocket Carburetor checking 67 Adjusting the idle speed 103 Environment 8 float chamber, emptying 107 Idle control 102 Carburetor tuning 100 Figures 9 Chain 67 Filling up fuel 30 Checking 65 Foot brake lever 17 basic position, adjusting 81 free travel, checking 81 Fork | C | adjusting the auxiliary spring 105 |
| coolant 120 Engine number 12 gear oil 109, 120 Engine sprocket Carburetor checking 67 Adjusting the idle speed 103 Environment 8 float chamber, emptying 107 Figures 9 Idle control 102 Figures 9 Carburetor tuning 100 Filling up fuel 30 Chain 67 Cleaning 65 Foot brake lever 17 basic position, adjusting 81 free travel, checking 81 Fork | Canacity | auxiliary spring |
| gear oil 109, 120 Engine sprocket Carburetor checking 67 Adjusting the idle speed 103 Environment 8 float chamber, emptying 107 Figures 9 Idle control 102 Figures 9 Carburetor tuning 100 Filling up fuel 30 Chain 65 Foot brake lever 17 basic position, adjusting 81 Chain guide free travel, checking 81 checking 67 Fork | • | Engine number |
| Adjusting the idle speed 103 | | Engine sprocket |
| Foot brake lever 17 17 17 17 17 17 17 1 | Carburetor | checking |
| Foot brake lever 17 17 17 17 17 17 17 1 | Adjusting the idle speed | Environment |
| Idle control 102 Carburetor tuning 100 Chain fuel checking 67 cleaning 65 Chain guide free travel, checking 81 checking 67 checking 67 Fork Fork | | E |
| Carburetor tuning 100 Chain fuel 30 checking 67 Foot brake lever 17 basic position, adjusting 81 Chain guide free travel, checking 81 checking 67 Fork | Idle control | |
| Chain fuel 30 checking 67 67 cleaning 65 Foot brake lever 17 basic position, adjusting 81 free travel, checking 81 Fork Fork | Carburetor tuning | |
| checking 67 cleaning 65 Chain guide free travel, checking 81 checking 67 Fork Fork | Chain | |
| cleaning | | |
| Chain guide free travel, checking | | |
| checking | | |
| FORK | | |
| air pressure, adjusting 40 | | |
| | | air pressure, adjusting40 |

| article number | L |
|--------------------------------|---|
| basic setting, checking | Link fork |
| Fork legs | checking |
| bleeding | Lower triple clamp |
| dust boots, cleaning | installing |
| installing | removing |
| removing 46 | • |
| Fork protector | Low-speed compression damping shock absorber, adjusting |
| installing 47 | |
| removing 47 | M |
| Frame | Main silencer |
| checking | glass fiber yarn filling, changing 61 |
| Front fender | installing 61 |
| installing | removing |
| removing | Manufacturer warranty |
| Front wheel | Misuse 6 |
| installing | Motorcycle |
| removing | cleaning 111 |
| Fuel tank | lift stand, raising with44 |
| installing | lift stand, removing from 44 |
| removing | 0 |
| Fuel tank filler cap | Owner's Manual 8 |
| closing | P |
| opening | • |
| Fuel tap | Plug-in stand |
| Fuel, oils, etc | Preparing for use |
| | advice on preparing for first use |
| G | after storage |
| Gear oil | checks and maintenance measures when preparing for use |
| adding | · · · · · · |
| changing | Protective clothing 8 |
| Gear oil level | R |
| checking | Rear sprocket |
| Н | checking |
| Hand brake lever | Rear wheel |
| basic position, adjusting | installing |
| free travel, checking | removing |
| Handlebar position | Rebound damping |
| adjusting | fork, adjusting |
| High-speed compression damping | shock absorber, adjusting |
| shock absorber, adjusting | Riding sag |
| | adjusting |
| I | |
| Ignition timing map | Rubber grip |
| changing 104 | checking |
| plug-in connector | S |
| Implied warranty | Safe operation |
| Intended use6 | Seat |
| K | mounting56 |
| | removing |
| Kick starter lever | removing |

INDEX

| Service | 9 |
|------------------------------|---|
| Service hour counter | 8 |
| Shift lever | 6 |
| basic position, adjusting 10 | |
| basic position, checking | 4 |
| Shock absorber | |
| article number | |
| compression damping, general | |
| installing | |
| removing | |
| riding sag, checking | |
| static sag, checking | |
| Spare parts | |
| | פ |
| Spoke tension checking | 2 |
| | _ |
| Start number plate | 2 |
| installing | |
| • | |
| Starting | 6 |
| Steering head bearing | _ |
| lubricating 5 | I |
| Steering head bearing play | _ |
| adjusting | |
| checking 5 | |
| Storage | |
| Switch-off button | 4 |
| Т | |
| Technical data | |
| capacities | 0 |
| carburetor | |
| chassis | |
| chassis tightening torques | |
| electrical system | |
| engine11 | |
| engine tightening torques | |
| fork | |
| shock absorber | |
| tires 12 | 1 |
| Throttle cable play | |
| adjusting | |
| checking 9 | 9 |
| Throttle cable routing | |
| checking | 0 |
| Throttle grip | 4 |
| Tire condition | |
| checking9 | 1 |
| Tire pressure | |
| checking | 1 |

| ansporting | 29 |
|------------------------------|-----|
| roubleshooting | 16 |
| /pe label | 12 |
| | |
| se definition | . 6 |
| | |
| ehicle identification number | 12 |
| iew of vehicle | |
| front left | 10 |
| rear right | 11 |
| l | |
| lork rules | C |





3214210en

04/2020







