

125 SX
125 XC

ITEM NO.: 3240232EN



Congratulations on your decision to purchase a KTM motorcycle. You are now the owner of a state-of-the-art sports vehicle which, with proper care, will bring you pleasure for a long time to come.

We hope you enjoy your bike and have a safe journey at all times!

The owner's manual contained the latest information for this model series at the time of publication. However, minor differences due to further developments in design cannot be ruled out completely.

All specifications are non-binding. KTM Sportmotorcycle GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. KTM accepts no liability for delivery options, differences from illustrations and descriptions, misprints, and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of delivery.

© 2025 KTM Sportmotorcycle GmbH, Mattighofen Austria

All rights reserved. Figures: Mitterbauer / Visus Studios / KISKA / KTM

Written permission from the copyright owner is required before any duplication or reproduction.

ISO 9001

KTM applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard.



12 100 6061

Issuing institution:

TÜV SÜD Management Service GmbH

KTM Sportmotorcycle GmbH
Stallhofnerstraße 3
5230 Mattighofen, Austria

This document is valid for:

- 125 SX EU (F6101Z0)
- 125 SX US (F6175Z0)
- 125 XC US (F6175Z3)



Table of contents

1	Means of representation	9	6.12	Cold start button	24
1.1	Conventions	9	6.13	Idle speed adjustment screw	25
1.1.1	Icons	9	6.14	Gear shift lever	25
1.1.2	Formatting	9	6.15	Brake pedal	26
1.1.3	Abbreviations	9	6.16	Plug-in stand (All SX models)	26
2	Safety	10	6.17	Side stand (XC)	26
2.1	Safety instructions	10	7	Preparing for use	27
2.2	Ban on tampering	10	7.1	Notes on preparing for first use	27
2.3	Safe use	11	7.2	Running in the engine	28
2.4	Protective clothing	11	7.3	Starting performance of lithium-ion batteries at low temperatures	29
2.5	Work rules	11	7.4	Preparing the vehicle for difficult operating conditions	29
2.6	Environment	12	7.5	Preparing the vehicle for rides on dry sand	30
2.7	Owner's manual	12	7.6	Preparing the vehicle for rides on wet sand	30
2.8	Use definition – intended use	12	7.7	Preparing for rides on wet and muddy surfaces	31
2.9	Improper use	13	7.8	Preparing vehicle for rides at high temperature or slow speed	31
3	Important notes	14	7.9	Preparing the vehicle for low temperatures or snow	32
3.1	Manufacturer's warranty, implied warranty	14	8	Riding instructions	33
3.2	Auxiliary material, operating material	14	8.1	Checks and maintenance measures when preparing for use	33
3.3	Spare parts, accessories	14	8.2	Starting the vehicle	33
3.4	Service	14	8.3	Starting off	34
3.5	Figures	14	8.4	Shifting, riding	35
3.6	Customer service	14	8.5	Braking	35
4	View of the vehicle	15	8.6	Stop, park	36
4.1	View of vehicle, front left (example)	15	8.7	Transportation	36
4.2	View of vehicle, rear right (example)	16	8.8	Refueling	37
5	Serial number	17	9	Service schedule	39
5.1	Vehicle identification number	17	9.1	Service schedule	39
5.2	Frame label	17	10	Tuning the chassis	42
5.3	Engine number	17	10.1	Checking the basic chassis setting with the rider's weight	42
5.4	Fork part number	17	10.2	Compression damping of the shock absorber	42
5.5	Shock absorber part number	18	10.3	Adjusting the low-speed compression damping of the shock absorber	42
6	Controls	19	10.4	Adjusting the high-speed compression damping of the shock absorber	43
6.1	Clutch lever	19	10.5	Adjusting the rebound damping of the shock absorber	44
6.2	Handbrake lever	19	10.6	Measuring the dimension of the unloaded rear wheel	45
6.3	Throttle grip	20			
6.4	Kill button	20			
6.5	Electric starter	21			
6.6	Combination switch	21			
6.7	Overview of indicator lights (All SX models)	22			
6.8	Overview of indicator lights (XC)	22			
6.9	dashboard	23			
6.10	Opening the fuel tank cap	23			
6.11	Closing the fuel tank cap	24			












































10.7	Checking the static sag of the shock absorber	46	11.25	Installing the skid plate (XC)	72
10.8	Checking the rider sag of the shock absorber	46	11.26	Removing air filter box cover	72
10.9	Adjusting the preload for the shock absorber 	47	11.27	Installing air filter box cover	73
10.10	Adjusting the rider sag 	48	11.28	Removing the air filter 	74
10.11	Air suspension XACT	49	11.29	Cleaning the air filter and air filter box 	75
10.12	Checking the basic setting of the fork	49	11.30	Installing the air filter 	76
10.13	Adjusting the fork air pressure (All SX models)	50	11.31	Preparing the air filter box cover for securing 	76
10.14	Adjusting the compression damping of the fork	51	11.32	Removing the muffler	77
10.15	Adjusting the rebound damping of the fork	52	11.33	Installing muffler	77
10.16	Handlebar position	53	11.34	Changing the glass fiber yarn filling in the main silencer 	78
10.17	Adjusting the handlebar position 	53	11.35	Removing the fuel tank 	78
11	Service work on the chassis	56	11.36	Installing the fuel tank 	80
11.1	Raising the motorcycle with a lift stand	56	11.37	Checking the chain for dirt	82
11.2	Removing the motorcycle from the lift stand	56	11.38	Cleaning the chain	82
11.3	Bleeding the fork legs	57	11.39	Checking the chain tension	83
11.4	Cleaning the dust boots of the fork legs	57	11.40	Adjusting the chain tension	83
11.5	Removing the fork protector	58	11.41	Checking the chain, rear sprocket, front sprocket, and chain guide	84
11.6	Installing the fork protector	58	11.42	Checking the frame 	87
11.7	Removing the fork legs 	59	11.43	Checking the swingarm 	87
11.8	Installing the fork legs 	59	11.44	Checking the throttle cable routing	87
11.9	Removing the lower triple clamp 	60	11.45	Checking the hand grip	88
11.10	Installing the lower triple clamp 	61	11.46	Adjusting the basic position of the clutch lever	89
11.11	Checking the steering head bearing play	63	11.47	Checking/correcting the fluid level of hydraulic clutch	89
11.12	Adjusting the steering head bearing play 	64	11.48	Changing the hydraulic clutch fluid 	90
11.13	Lubricating the steering head bearing 	65	12	Brake system	92
11.14	Removing the number plate	65	12.1	Checking the free travel on the hand brake lever	92
11.15	Mounting the number plate	65	12.2	Adjusting the basic position of the hand brake lever	92
11.16	Removing the front top fender	66	12.3	Checking the brake discs	92
11.17	Installing the front top fender	66	12.4	Checking the brake fluid level for the front brake	93
11.18	Removing the shock absorber 	67	12.5	Adding brake fluid for the front brake 	94
11.19	Installing the shock absorber 	68	12.6	Checking that the brake pads of the front brake are secured	95
11.20	Removing the seat	69	12.7	Changing the brake pads of the front brake 	96
11.21	Mounting the seat	70	12.8	Checking the free travel of the brake pedal	98
11.22	Removing the frame protector	71	12.9	Adjusting the basic position of the brake pedal 	98
11.23	Installing the frame protector	71	12.10	Checking the brake fluid level for the rear brake	99
11.24	Removing the skid plate (XC)	71			









Table of contents

12.11	Adding brake fluid for the rear brake 	100	18	Service work on the engine	130
12.12	Checking that the brake pads of the rear brake are secured	101	18.1	Changing the fuel screen 	130
12.13	Changing the rear brake pads 	101	18.2	Checking the gear oil level	131
13	Wheels, tires	104	18.3	Changing the gear oil 	132
13.1	Removing the front wheel 	104	18.4	Adding gear oil 	133
13.2	Installing the front wheel 	105	19	Cleaning, care	135
13.3	Removing the rear wheel 	105	19.1	Cleaning the motorcycle	135
13.4	Installing the rear wheel 	106	20	Storage	137
13.5	Checking the tire condition	107	20.1	Storage	137
13.6	Checking the tire pressure	108	20.2	Preparing for use after storage	138
13.7	Checking the spoke tension	109	21	Troubleshooting	139
14	Cooling system	110	21.1	troubleshooting	139
14.1	Cooling system	110	22	Flash code	141
14.2	Checking the frost protection and coolant level	110	22.1	Flash codes	141
14.3	Checking the coolant level	111	23	Technical specifications	144
14.4	Draining the coolant 	112	23.1	Engine	144
14.5	Refilling the coolant 	112	23.1.1	Technical data - engine	144
14.6	Changing the coolant 	114	23.2	Chassis	145
15	Electrics	117	23.2.1	Technical data - chassis	145
15.1	Removing the 12 V battery 	117	23.2.2	Technical data - tires	146
15.2	Installing the 12 V battery 	118	23.2.3	Capacities - vehicle	146
15.3	Charging the 12 V battery 	119	23.3	Electrics	147
15.4	Changing the main fuse	121	23.3.1	Battery	147
15.5	Changing the fuse of the fuel pump	122	23.3.2	Fuses	147
15.6	Diagnostic connector	123	23.4	Fork	147
16	Exhaust control	124	23.4.1	Technical data - fork (All SX models)	147
16.1	Programming the end positions of the exhaust control 	124	23.4.2	Capacities - fork (All SX models)	148
17	Tuning the engine	126	23.4.3	Technical data - fork (XC)	148
17.1	Changing the mapping	126	23.4.4	Capacities - fork (XC)	148
17.2	Checking the play in the throttle cable	126	23.5	Shock absorber	149
17.3	Adjusting the throttle cable play 	127	23.5.1	Technical data - shock absorber (All SX models)	149
17.4	Adjusting the idle speed 	128	23.5.2	Technical data - shock absorber (XC)	149
17.5	Checking the basic position of the gear shift lever	128	23.6	Tightening torque	150
17.6	Adjusting the basic position of the gear shift lever 	129	23.6.1	engine tightening torques	150
			23.6.2	Chassis tightening torques	153
			Notes		159
			A	Technical terms	159
			B	Fuels	160
			C	Operating supplies	161
			D	Cleaning agents	163

E	Icons.....	164
	E.1 Symbol colors	164
	E.1.1 Yellow and orange symbols	164
	E.1.2 Green and white symbols.....	164
	Index	165

1.1 Conventions

1.1.1 Icons

-  Indicates a desired result (e.g. of a work step or a function).
-  Indicates an undesired result (e.g. of a work step or a function).
-  All work marked with this symbol requires specialist knowledge and technical understanding. Ensure that this work is carried out or supervised by trained personnel from an authorized KTM workshop, and that any special tools required are used.
-  Indicates a page reference.
-  Indicates information with more details.
-  Indicates a tip, e.g. to simplify work.
-  Indicates the result from a test step.
-  Indicates the end of an activity, including any rework.

1.1.2 Formatting

Proprietary name	Indicates a proprietary name.
Name[®]	Indicates a protected name.
Brand[™]	Indicates a brand available on the open market.
<u>Underlined terms</u>	Refer to technical details of the vehicle or indicate technical terms that are explained in the glossary.

1.1.3 Abbreviations

2-pc.	two-part
Part no.	Part number
or	respectively
approx.	circa
etc.	et cetera
poss.	possibly/possible
if necessary	if necessary
cmpl.	complete
min.	at least
no.	number
no fig.	no figure
s.	see
among others	among others/not limited to
and the like	and the like
etc.	et cetera
cf.	compare
e.g.	for example

2.1 Safety instructions

Function of the safety instruction

Safety instruction brings attention to dangers when handling the product. Hazards are classified, named, described, and supplemented with information on how to avoid them.

- If there is a safety instruction before a list of instructions, the danger exists throughout the entire activity.
- If there is a safety instruction immediately before an instruction, the next step presents a danger.

Safety instruction layout

All safety instructions are identified by a signal word and a warning symbol. The combination of signal word and warning symbol determines the degree of danger.



DANGER

Indicates an imminent danger that leads to serious injury or death.



WARNING

Indicates a potentially imminent danger that could lead to serious injury or death.



CAUTION

Indicates a potentially imminent danger that can lead to minor or slight injuries.



NOTE

Indicates a situation that can lead to damage to the product or the product environment.



NOTE

Indicates a situation that can lead to environmental damage.

2.2 Ban on tampering

No changes may be made to the noise control equipment and components.

Tampering that is prohibited

- Removing or disabling any devices or components used for noise control before the new vehicle is sold or delivered to the end customer.
- Removing or disabling any device or component used for noise control for purposes other than service, repair, or replacement during the service life of the vehicle.
- Use of the vehicle after a device or component used for noise control has been removed, disabled, or inadequately maintained.

Examples of prohibited tampering

- Removing or drilling through rear mufflers, baffle plates, manifolds, or other components that conduct exhaust gases.
- Removing or puncturing parts of the intake system.
- Replacing moving parts of the vehicle, or parts of the exhaust system or intake system, with parts other than those specified by the manufacturer.

2.3 Safe use



DANGER

Danger of accidents A rider who is not fit to ride poses a danger to themselves and to others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs, or medication.
- Do not operate the vehicle if you are physically or mentally incapable of doing so.



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.



WARNING

Danger of burns Some vehicle components become hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
- Allow the vehicle parts to cool down before performing any work on the vehicle.

The vehicle should only be used when it is in perfect technical condition, for its intended purpose, and in a safe and environmentally-friendly manner.

The vehicle must only be used by trained persons.

Have malfunctions that impair safety promptly eliminated by an authorized KTM workshop.

Adhere to the information and warning labels on the vehicle.

2.4 Protective clothing



WARNING

Risk of injury Missing or inadequate protective clothing increases the risk of injury.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as pants and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.

2.5 Work rules

Unless specified otherwise, the ignition must be switched off during all work (models with ignition lock, models with transponder key) or the engine must be at a standstill (models without ignition lock or transponder key).

Special tools are required for some work. The tools are not part of the vehicle, but can be ordered using the number in parentheses. Example: bearing puller (15112017000)

Unless otherwise noted, normal conditions apply to all tasks and descriptions.

Ambient temperature	20 °C (68.0 °F)
Ambient air pressure	1,013 mbar (14.69 psi)
Relative air humidity	60 ±5 %

During assembly, use new parts to replace parts which cannot be reused (e.g. self-locking screws and nuts, expansion screws, seals, sealing rings, O-rings, pins, and lock washers).

A thread lock (e.g. **Loctite**®) is required for some screw connections. Observe the manufacturer's specific instructions for use.

If thread lock (e.g. **Precote**®) has already been applied to a new part, do not apply any additional thread lock.

After disassembly, clean the parts that are to be reused and check them for damage and wear. Replace damaged or worn parts.

After completing a repair or service, check the operating safety of the vehicle.

2.6 Environment

Handling the vehicle responsibly reduces the risk of conflict with other road users and the surrounding area. The future of motorcycling also depends on using motorcycles legally, being environmentally conscious and respecting the rights of others.

When disposing of used oil, other operating and auxiliary fluids, and used components, the laws and regulations of the respective country must be observed.

As motorcycles are not subject to the EU regulations governing the disposal of end-of-life vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. More information is available from authorized KTM dealers.

2.7 Owner's manual

Read this owner's manual carefully and in full before riding off for the first time. The owner's manual contains information and tips on how to operate, handle, and service your vehicle, as well as advice on optimum tuning and how to avoid injuries.



Tip

Save this owner's manual on your smartphone, for example, so that you can access it at any time.

An authorized KTM dealer will be happy to assist you if you are unsure.

The owner's manual is an important component of the vehicle. If the vehicle is sold, the owner's manual must be downloaded again by the new owner.

The owner's manual can be downloaded multiple times using the QR code or the link on the delivery certificate.

The owner's manual is also available for download from your authorized KTM dealer and on the KTM website. A physical copy can also be ordered from your authorized KTM dealer.

International KTM Website: <https://www.ktm.com>

2.8 Use definition – intended use

(All SX models)

This vehicle has been designed and built to withstand the typical stresses and strains of racing. This vehicle complies with the currently valid regulations and categories of the top international motorsports organizations.



Note

Only use this vehicle on designated tracks away from public roads.

(XC)

This vehicle has been designed and built to withstand the typical stresses and strains of racing. This vehicle complies with the currently valid regulations and categories of the top international motorsports organizations.



Note

This vehicle is designed for use in offroad endurance competition, and not primarily for use in motocross.

Only use this vehicle on designated tracks away from public roads.

2.9 Improper use

The vehicle may only be used as intended.

Improper use can result in danger to people, property and the environment.

Any use of the vehicle beyond the intended and defined use constitutes misuse.

Improper use includes the use of operating and auxiliary materials that do not meet the required specifications for the respective use.

3 Important notes

3.1 Manufacturer's warranty, implied warranty

The work prescribed in the service schedule must be carried out in an authorized KTM workshop only and confirmed in the electronic proof of service. If this is not carried out, warranty claims will not be recognized. Damage or secondary damage caused by tampering with and/or conversions on the vehicle are not covered by the manufacturer's warranty.

3.2 Auxiliary material, operating material

Use operating materials and auxiliary materials in accordance with the operating instructions and specifications.

3.3 Spare parts, accessories

For safety reasons, only spare parts and accessories approved by KTM may be used. Installation must be carried out in an authorized KTM workshop. KTM accepts no liability for other products and any resulting damage or loss. Certain spare parts and accessory products are specified in parentheses in the descriptions. Authorized KTM dealers will be happy to help.

The current **KTM PowerParts** are listed for each vehicle on the KTM website.

International KTM Website: <https://www.ktm.com>

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the owner's manual. An incorrect suspension setting can lead to damage and breakage of chassis components.

Use of the vehicle under arduous conditions, such as on sand or on wet, dusty and muddy surfaces, can result in significantly increased wear of components, such as the powertrain, brake system, air filter, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service interval.

Please adhere to the prescribed run-in times and service intervals at all times. Strictly adhering to this will ensure a much longer service life for your motorcycle.

The relevant mileage or time interval is whichever occurs first.

3.5 Figures

Some of the figures in this document contain optional extras.

For clarity, some components may be shown disassembled or may not be shown at all. Disassembly is not always absolutely necessary in order to carry out the activities described. The textual information takes precedence.

3.6 Customer service

Authorized KTM dealers will be happy to answer questions about the vehicle and KTM.


A list of authorized KTM dealers can be found on the KTM website.


International KTM Website: <https://www.ktm.com>

4.1 View of vehicle, front left (example)




B06683-11

❶ Clutch lever  (p. 19)


❷ Combination switch  (p. 21)

❸ Air filter box cover

❹ Gear shift lever  (p. 25)

4 View of the vehicle

4.2 View of vehicle, rear right (example)




B06684-11

- ❶ Shock absorber compression adjustment
- ❷ Kill button 📖 (p. 20)
- ❸ Electric starter 📖 (p. 21)
- ❹ Throttle grip 📖 (p. 20)
- ❺ Fork compression adjustment


- ❻ Vehicle identification number 📖 (p. 17)
- ❼ Fork rebound adjustment
- ❼ Brake pedal 📖 (p. 26)
- ❽ Shock absorber rebound adjustment

5.1 Vehicle identification number




The vehicle identification number ① is stamped on the right-hand side of the steering head.

5.2 Frame label




Frame label ① is fixed to the front of the steering head.

5.3 Engine number



The engine number ① is located on the left side of the engine under the engine sprocket.


5.4 Fork part number



Fork part number ① is stamped on the inside of the fork shoe.

5 Serial number


5.5 Shock absorber part number



Shock absorber part number ❶ is stamped on the top right of the shock absorber.


6.1 Clutch lever

(All SX models)



Clutch lever ❶ is fitted on the left side of the handlebar. The clutch is activated hydraulically and adjusts itself automatically.


(XC)



Clutch lever ❶ is fitted on the left side of the handlebar. The clutch is activated hydraulically and adjusts itself automatically.


6.2 Handbrake lever

(All SX models)



Hand brake lever ❶ is fitted on the right side of the handlebar. The front brake is engaged using the hand brake lever.


(XC)



Hand brake lever ❶ is fitted on the right side of the handlebar. The front brake is engaged using the hand brake lever.


6.3 Throttle grip

(All SX models)



The throttle twist grip ❶ is fitted on the right side of the handlebar.


(XC)





The throttle twist grip ❶ is fitted on the right side of the handlebar.

6.4 Kill button


(All SX models)





Kill switch ❶ is fitted on the right side of the handlebar.

Condition	Meaning
Kill button  is not pressed.	In this position, the ignition circuit is closed, and the engine can be started.
The kill button  is pressed and held.	In this position, the ignition circuit is interrupted, a running engine stops, and an engine at standstill will not start.

(XC)




Kill switch ❶ is fitted on the right side of the handlebar.

Condition	Meaning
Kill button  is not pressed.	In this position, the ignition circuit is closed, and the engine can be started.
The kill button  is pressed and held.	In this position, the ignition circuit is interrupted, a running engine stops, and an engine at standstill will not start.

6.5 Electric starter


(All SX models)



Electric starter ❶ is fitted on the right side of the handlebar.

Condition	Meaning
Electric starter (❸) in the basic position	No function
Electric starter (❸) pressed	In this position, the starter motor is actuated.


(XC)



Electric starter ❶ is fitted on the right side of the handlebar.

Condition	Meaning
Electric starter (❸) in the basic position	No function
Electric starter (❸) pressed	In this position, the starter motor is actuated.

6.6 Combination switch




The combination switch is fitted on the left side of the handlebar.

The engine characteristic can be changed using button ❶ and button ❷ on the combination switch.


Condition	Meaning
STANDARD ❶	Lean mapping is activated when white indicator light A lights up. This mapping is recommended for firm/hard surfaces.
ADVANCED ❷	Rich mapping is activated when green indicator light B lights up. This mapping is recommended for sandy/loose surfaces.

6.7 Overview of indicator lights (All SX models)




Condition		Meaning
Fi	Failure indicator lamp lights up or flashes red	The OBD has detected a malfunction in the vehicle electronics. Come safely to a halt, and contact an authorized KTM workshop.
L	Indicator light A lights up white	Lean mapping is activated. This mapping is recommended for firm/hard surfaces.
7	Indicator light B lights up green	Rich mapping is activated. This mapping is recommended for sandy/loose surfaces.

6.8 Overview of indicator lights (XC)



Condition		Meaning
Fi	Failure indicator lamp lights up or flashes red	The OBD has detected a malfunction in the vehicle electronics. Come safely to a halt, and contact an authorized KTM workshop.
L	Indicator light A lights up white	Lean mapping is activated. This mapping is recommended for firm/hard surfaces.
7	Indicator light B lights up green	Rich mapping is activated. This mapping is recommended for sandy/loose surfaces.
FUEEL	FUEL is displayed	The fuel level has reached the reserve mark.

6.9 dashboard



Dashboard ① is fitted in the front of the handlebar. The dashboard shows the total operating hours of the engine. The operating hours are counted when the engine is started and stopped when the engine is switched off.

i Note
 Nothing can be cleared or modified on the dashboard. As soon as the diagnostics tool is connected, the hourmeter starts running. Before longer diagnostic sessions, unplug the hourmeter behind the number plate.

6.10 Opening the fuel tank cap



DANGER

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
- Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it up immediately.
- Do not overfill the fuel tank.



WARNING

Danger of poisoning Fuel is harmful to health.

- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.




NOTE


Environmental hazard Improper handling of fuel is dangerous to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.

(All SX models)

- Turn fuel tank cap ① counterclockwise and lift it off.






(XC)

- Press release button **1**, turn the fuel tank cap counter-clockwise, and lift it off.


6.11 Closing the fuel tank cap



(All SX models)

- Mount fuel tank cap **1** and turn it clockwise until the fuel tank is tightly closed.

Route hose of fuel tank vent **2** without kinks.




(XC)

- Mount filler cap **1** and turn it clockwise until the release button engages.

Route hose of fuel tank vent **2** without kinks.

6.12 Cold start button




Cold start button **1** is fitted to the bottom of the throttle body. The electronic fuel injection extends the injection time when the engine is cold and the ambient temperature is low. To help the engine burn the increased amount of fuel, it must be supplied with additional oxygen by pushing the cold start button.

After briefly opening up the throttle and then releasing the throttle twist grip again, or turning the throttle twist grip towards the front, the cold start button returns to its original position.

Condition	Meaning
The cold start button is pushed in all the way to the stop.	Cold start button activated
The cold start button is in the basic position.	Cold start button deactivated

Note
 Check whether the cold start button has returned to its basic position.

6.13 Idle speed adjustment screw




The idle setting of the throttle body substantially influences the vehicle's starting behavior, a stable idle speed, and the vehicle's response when the throttle is opened.

An engine with a correctly set idle speed is easier to start than an engine with the idle speed set incorrectly.


The idle speed is adjusted using idle speed adjustment screw **1**. Increase the idle speed by turning the idle speed adjustment screw clockwise.

Decrease the idle speed by turning the idle speed adjustment screw counterclockwise.

6.14 Gear shift lever




Gear shift lever **1** is mounted on the left of the engine.



The gear positions can be seen in the figure.


The neutral or idle position is between the first and second gears.

6.15 Brake pedal



Brake pedal ① is located in front of the right footpeg. The rear brake is operated with the brake pedal.

6.16 Plug-in stand (All SX models)




The holder for the plug-in stand ① is the left side of the wheel spindle. The plug-in stand is used to park the motorcycle. The plug-in stand is used as a fork support when transporting the motorcycle.

i Note

Remove the plug-in stand before riding.

6.17 Side stand (XC)



The side stand ① is located on the left of the vehicle. The side stand is used for parking the motorcycle.

i Note

When you are riding, side stand ① must be folded up and secured with rubber band ②.

7.1 Notes on preparing for first use



DANGER

Danger of accidents A rider who is not fit to ride poses a danger to themselves and to others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs, or medication.
- Do not operate the vehicle if you are physically or mentally incapable of doing so.



WARNING

Risk of injury Missing or inadequate protective clothing increases the risk of injury.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as pants and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.



WARNING

Danger of accidents Different tire profiles on the front and rear wheels can make it more difficult to control the vehicle.

- Make sure that only tires of the same tread type are mounted to the front and rear wheel.



WARNING

Danger of accidents Not adapting the riding style constitutes a major risk.

- Adapt the vehicle speed to the road conditions and your riding ability.



WARNING

Danger of accidents The vehicle is not designed to carry passengers.

- Do not ride with a passenger.



WARNING

Danger of accidents The brake system fails in the event of overheating.

If the brake pedal is not released, the brake pads grind continuously.

- Take your foot off the brake pedal when you are not braking.



WARNING

Danger of accidents Total weight and axle loads influence the handling characteristic.

- Do not exceed the maximum permissible total weight or the axle loads.



WARNING

Risk of injury People who act without authorization endanger themselves and others.

- Never leave the vehicle unattended while the engine is running.
- Secure the vehicle against unauthorized access.



Note

When using the motorcycle, remember that others may be disturbed by excessive noise.

- Ensure that the pre-delivery inspection has been carried out by an authorized KTM workshop.
 - ✓ The delivery certificate is transferred upon vehicle handover.
- Read the entire owner's manual before riding for the first time.
- Get to know the controls.
- Adjust the basic position of the clutch lever. 📖 (p. 89)
- Adjust the basic position of the hand brake lever. 📖 (p. 92)
- Adjust the basic position of the brake pedal. 🦶 📖 (p. 98)
- Adjust the basic position of the gear shift lever. 🦶 📖 (p. 129)

7 Preparing for use

- Get used to the handling characteristics of the motorcycle on suitable terrain before undertaking a more challenging ride.

i Note

This vehicle is not approved for use on public roads.

When off-road, it is recommended that you be accompanied by another person with another vehicle so that you can help each other.

- Also, ride as slowly as possible and in a standing position to get a better feel for the motorcycle.
- Do not make any off-road trips that exceed your ability and experience.
- Hold the handlebar firmly with both hands and keep your feet on the footpegs when riding.

(All SX models)

- Do not take any luggage.

(XC)


- If luggage is carried, ensure it is fixed firmly as close as possible to the center of the vehicle and ensure even weight distribution between the front and rear wheels.

i Note


Motorcycles react sensitively to any changes of weight distribution.

- The maximum permissible total weight and the maximum permissible axle loads must not be exceeded.

Maximum permissible total weight	335 kg (738.5 lb)
Maximum permissible front axle load	145 kg (319.7 lb)
Maximum permissible rear axle load	190 kg (418.9 lb)

- Check the spoke tension.  (p. 109)

The spoke tension must be checked after half an hour of operation.

- Run in the engine.  (p. 28)


7.2 Running in the engine

- During the running-in time, do not exceed the specified engine power.

Maximum engine power	
during the first 3 operating hours	< 70 %
during the first 5 operating hours	< 100 %

Avoid fully opening the throttle.

7.3 Starting performance of lithium-ion batteries at low temperatures



Lithium-ion batteries are far lighter than lead batteries, have a low self-discharge rate, and have more starting power at temperatures over 15 °C (60 °F). At low temperatures, however, the starting power of lithium-ion batteries drops to below that of lead batteries. Several attempts to start may be required. Press the start button for 5 seconds, and wait 30 seconds between attempts. The pauses are necessary so that the heat created can be distributed through the lithium-ion battery without damaging the lithium-ion battery. If the charged lithium-ion battery is unable to actuate the starter motor or does so only weakly at temperatures below 15 °C (60 °F), the battery is not faulty but needs to be warmed up internally to increase its starting power (current output).

The starting power increases as the battery warms up.

7.4 Preparing the vehicle for difficult operating conditions

i Note

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can result in significantly increased wear of components, such as the powertrain, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service interval.

- Prepare the air filter box cover for securing. (p. 76)
- Clean the air filter and air filter box. (p. 75)

i Note

Check the air filter approx. every 30 minutes.

- Check the electrical socket connector for humidity and corrosion and to ensure it is firmly seated.
 - » If moisture, corrosion, or damage is found:
 - Clean and dry the socket connector, or change it if necessary.
- Change the mapping. (p. 126)

Select mapping to match the background.

- Riding on dry sand. (p. 30)
- Riding on wet sand. (p. 30)
- Rides on wet and muddy surfaces. (p. 31)
- Riding at high temperatures or slow speed. (p. 31)
- Riding at low temperatures and in snow. (p. 32)

7.5 Preparing the vehicle for rides on dry sand



- Mount the air filter dust protection.

Read the accompanying mounting instructions.

Air filter dust protection cover (A46006920000)



- Mount the air filter sand protection.

Read the accompanying mounting instructions.

Air filter sand protection (A46006922000)




- Clean the chain.

Chain cleaner  (p. 163)

- Mount the steel sprocket.

- Grease the chain.

Universal oil spray  (p. 161)

- Clean the radiator fins.

- Straighten the bent radiator fins carefully.

Condition: Regular use in sand

- Change the piston every 10 operating hours.

7.6 Preparing the vehicle for rides on wet sand



- Mount the air filter water protection.

Read the accompanying mounting instructions.

Air filter water protection (A46006921000)



600868-01

- Clean the chain.

Chain cleaner  (p. 163)

- Mount the steel sprocket.
- Grease the chain.

Universal oil spray  (p. 161)

- Clean the radiator fins.
- Straighten the bent radiator fins carefully.

Condition: Regular use in sand

- Change the piston every 10 operating hours.



7.7 Preparing for rides on wet and muddy surfaces



F03668-01


- Mount the air filter water protection.

Read the accompanying mounting instructions.

Air filter water protection (A46006921000)



600868-01

- Mount the steel sprocket.
- Clean the motorcycle.  (p. 135)
- Straighten the bent radiator fins carefully.



7.8 Preparing vehicle for rides at high temperature or slow speed




600868-01

- Adjust the secondary transmission to the road conditions.

i Note
The engine oil heats up quickly when the clutch is operated frequently due to an excessively high secondary ratio.

- Clean the chain.

Chain cleaner  (p. 163)

- Clean the radiator fins.
- Straighten the bent radiator fins carefully.
- Check the coolant level.  (p. 111)



7.9 Preparing the vehicle for low temperatures or snow



- Mount the air filter water protection.


Read the accompanying mounting instructions.

Air filter water protection (A46006921000)

8.1 Checks and maintenance measures when preparing for use

i Note

Before every trip, check the condition of the vehicle and ensure that it is safe to operate. The vehicle must be in perfect technical condition when it is being operated.



- Check the gear oil level. 📖 (p. 131)
- Check the brake fluid level for the front brake. 📖 (p. 93)
- Check the brake fluid level for the rear brake. 📖 (p. 99)
- Check that the brake pads of the front brake are secured. 📖 (p. 95)
- Check that the brake pads of the rear brake are secured. 📖 (p. 101)
- Check that the brake system is functioning properly.
- Check the coolant level. 📖 (p. 111)
- Check the chain for dirt. 📖 (p. 82)
- Check the chain, rear sprocket, engine sprocket, and chain guide. 📖 (p. 84)
- Check the chain tension. 📖 (p. 83)
- Check the tire condition. 📖 (p. 107)
- Check the tire pressure. 📖 (p. 108)
- Check the spoke tension. 📖 (p. 109)

The spoke tension must be checked regularly as incorrect spoke tension will severely impair riding safety.

- Clean the dust boots of the fork legs. 📖 (p. 57)
- Bleed the fork legs. 📖 (p. 57)
- Check the air filter.
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check all screws, nuts, and hose clamps regularly for tightness.
- Check the fuel level.



8.2 Starting the vehicle



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.




NOTE

Engine failure Running a cold engine at high engine speeds negatively impacts the service life of the engine.


- Always warm up the engine at low engine speeds.

8 Riding instructions




(All SX models)

- Remove plug-in stand ①.



(XC)

- Take the motorcycle off side stand ① and secure the side stand with rubber band ②.
- Shift the transmission into the neutral position.



Condition: Ambient temperature: < 20 °C (< 68.0 °F)

- Press the cold start button in all the way to the stop.
- Press **electric starter** (⚡).

If the starting attempt is unsuccessful, wait for 15 seconds before making another attempt at starting.

After 6 unsuccessful starting attempts, do not try again, and check the vehicle for other malfunctions instead.

i Note

At low temperatures, wait for 30 seconds.

At temperatures below 6 °C (43 °F), several attempts at starting may be necessary to warm-up the lithium-ion battery and thereby increase the starting power.

The malfunction indicator light lights up during the starting process.

8.3 Starting off

i Note

The plug-in stand must be removed before riding.

When you are riding, the side stand must be folded up and secured with the rubber band.

- Pull the clutch lever, shift into first gear, release the clutch lever slowly and at the same time carefully open the throttle.

8.4 Shifting, riding



WARNING

- Danger of accidents** If you downshift at high engine speed, the rear wheel blocks and the engine races.
- Do not downshift to a lower gear at high engine speeds.



Note

- If you hear unusual noises while riding, stop immediately, switch off the engine, and contact an authorized KTM workshop.
First gear is used for starting off or for steep inclines.

- Shift into a higher gear when conditions allow (incline, riding situation, etc.). To do so, release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever and open the throttle.
- If you pushed the cold start button while starting, open the throttle briefly and release the throttle twist grip or turn the throttle twist grip forward.
 - ✓ The cold start button goes to the basic position.
- After reaching maximum speed by fully opening the throttle twist grip, turn the throttle back so that it is $\frac{3}{4}$ open. This will reduce the speed slightly, but the fuel consumption will be considerably lower.
- Only open the throttle as much as the engine can handle. Abruptly opening the throttle increases fuel consumption.
- To shift down, brake and close the throttle at the same time.
- Pull the clutch lever and shift into a lower gear, release the clutch lever slowly, and either open the throttle or shift again.
- Switch off the engine if you are likely to be running at idle speed or stationary for a long time.

≥ 1 min

- Avoid riding the clutch frequently or for too long. This causes the gear oil, engine, and cooling system to heat up.
- Ride at a low engine speed instead of at a high engine speed when riding the clutch.



8.5 Braking



WARNING

- Danger of accidents** Braking with excessive force locks the wheels.
- Adapt your braking to the riding situation and the road conditions.



WARNING

- Danger of accidents** A spongy pressure point on the front or rear brake reduces the brake action.
- Do not drive the vehicle if the brake system has a spongy pressure point.



WARNING

- Danger of accidents** Moisture and dirt impair the brake system.
- Brake carefully several times to dry out and remove dirt from the brake pads and the brake discs.

- On sandy, wet, or slippery surfaces, use mostly the rear brake.
- Always finish braking before you go into a bend. Shift into a lower gear that suits the speed.
- Use the brake action of the engine on long downhill stretches. Shift down one or two gears, but do not overrev the engine when doing so. This means that significantly less braking is required and means the brake system does not overheat.



8.6 Stop, park



WARNING

Risk of injury People who act without authorization endanger themselves and others.

- Never leave the vehicle unattended while the engine is running.
- Secure the vehicle against unauthorized access.



WARNING

Danger of burns Some vehicle components become hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
- Allow the vehicle parts to cool down before performing any work on the vehicle.



NOTE

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.




NOTE

Material damage The vehicle may be damaged if parked incorrectly.

Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Make sure that nobody sits on the vehicle when it is parked on a stand.

- Brake the motorcycle.
- Shift the transmission into the neutral position.
- Press kill button  when the engine is at idle speed until the engine stops.
- Park the motorcycle on firm ground.

8.7 Transportation



NOTE

Material damage The vehicle may be damaged if parked incorrectly.

Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Make sure that nobody sits on the vehicle when it is parked on a stand.




NOTE

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.

(All SX models)



- Switch off the engine.
- Mount the plug-in stand on the fork legs.


Make sure the brake line runs in front of the plug-in stand and does not become wedged.

Plug-in stand (A46029094000)



Note

The plug-in stand is included in the scope of supply.




- Use tension belts or other suitable devices to secure the motorcycle against falling over or rolling away.

Only tighten the tension belts to the point that the plug-in stand is firmly in contact with the fender and the tires.

Make sure that the plug-in stand is aligned with the underside of the fender.

(XC)



- Switch off the engine.
- Use tension belts or other suitable devices to secure the motorcycle against falling over or rolling away.

8.8 Refueling



DANGER

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
- Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it up immediately.
- Do not overfill the fuel tank.



WARNING

Danger of poisoning Fuel is harmful to health.

- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.

8 Riding instructions


- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.



NOTE

Environmental hazard Improper handling of fuel is dangerous to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Switch off the engine.
- Open the fuel tank cap. 📖 (p. 23)
- Fill the fuel tank with fuel no higher than **A**.

Level A	35 mm (1.38 in)
----------------	--------------------

Total fuel tank capacity, approx.
(All SX models)

Super unleaded (98 octane) mixed with 2-stroke engine oil 📖 (p. 160) Mixture ratio: 1:40	7.2 l (1.90 liq. gal _{US})
---	---

Total fuel tank capacity, approx.
(XC)































Super unleaded (98 octane) mixed with 2-stroke engine oil 📖 (p. 160) Mixture ratio: 1:40	8.5 l (2.25 liq. gal _{US})
---	---

2-stroke engine oil 📖 (p. 161)
fully synthetic




































- Close the fuel tank cap. 📖 (p. 24)

9.1 Service schedule

Any further work that results from the service work must be ordered separately and invoiced separately. Different service intervals may apply in your country, depending on the local operating conditions. If the vehicle is used in particularly harsh conditions such as heavy rain, mud, sand, snow, extreme temperatures, frequent full load etc., shorter service intervals than those in the table may be necessary. Individual service intervals and scopes may change in the course of technical developments. The most up-to-date service schedule is available for authorized dealers for the electronic proof of service. Your authorized dealer will be happy to advise you.

	Every 24 months				
	Every 90 operating hours				
	Every 45 operating hours				
	After 15 operating hours / Every 15 operating hours				
	After one operating hour				
Read out the fault memory using the diagnostics tool. 	○	●	●	●	●
Check that the electrical equipment is functioning properly. 	○	●	●	●	
Check and charge the 12 V battery. 	○	●	●	●	●
Check that the brake pads of the front brake are secured.  (p. 95)	○	●	●	●	●
Check that the brake pads of the rear brake are secured.  (p. 101)	○	●	●	●	●
Check the brake discs.  (p. 92)	○	●	●	●	●
Check the brake lines for damage and tightness.	○	●	●	●	●
Check the brake fluid level for the front brake.  (p. 93)	○	●	●		
Change the brake fluid for the front brake. 				●	●
Check the brake fluid level for the rear brake.  (p. 99)	○	●	●		
Change the brake fluid for the rear brake. 				●	●
Check/correct the fluid level of the hydraulic clutch.  (p. 89)				●	
Change the hydraulic clutch fluid.   (p. 90)				●	●
Check the free travel on the hand brake lever.  (p. 92)	○	●	●	●	●
Check the free travel of the brake pedal.  (p. 98)	○	●	●	●	●
Check the idle speed. 	○	●	●	●	●
Change the gear oil.   (p. 132)	○	●	●	●	●
Check all hoses (e.g. fuel, cooling, bleeder, drainage, etc.) and boots for cracking, leaks, and correct routing. 	○	●	●	●	●
Check the cables for damage and that there are no kinks in the routing. 		●	●	●	●
Check that the clutch cables are undamaged, routed without kinks, and set correctly.		●	●	●	●
Check the frame.   (p. 87)		●	●	●	
Check the swingarm.   (p. 87)		●	●	●	
Check the swingarm bearing for play. 			●	●	
Check the heim joint on the shock absorber for play. 			●	●	
Check the shock absorber linkage. 		●	●	●	
Check the tire condition.  (p. 107)		●	●	●	●
Check the tire pressure.  (p. 108)	○	●	●	●	●
Check the wheel bearing for play. 		●	●	●	

9 Service schedule


		Every 24 months			
			Every 90 operating hours		
			Every 45 operating hours		
		After 15 operating hours / Every 15 operating hours			
		After one operating hour			
Check the hubs. 			•	•	•
Check the rim run-out. 		○	•	•	•
Check the spoke tension.  (p. 109)		○	•	•	•
Check the chain, rear sprocket, engine sprocket, and chain guide.  (p. 84)		○	•	•	•
Check the chain tension.  (p. 83)		○	•	•	•
Grease all moving parts (e.g., hand lever, chain, etc.) and check for smooth operation. 		○	•	•	•
Check the basic setting of the throttle position sensor. 			○	•	•
Change the spark plug and spark plug connector. 			•	•	•
Change the fuel filter. 					•
Check the clutch. 			•	•	•
Clean the air filter and air filter box.   (p. 75)			•	•	•
Change the glass fiber yarn filling in the main silencer.   (p. 78)				•	•
Carry out fork service. 				•	•
Service the shock absorber. 				•	•
Check all screws, nuts, and hose clamps for a tight fit. 		○	•	•	•
Change the fuel screen.   (p. 130)		○	•	•	•
Check the fuel pressure. 		○		•	•
Check the frost protection and coolant level.  (p. 110)				•	•
Check the coolant level.  (p. 111)		○	•		
Change the coolant.   (p. 114)					•
Check the steering head bearing play.  (p. 63)		○	•		
Lubricate the steering head bearing.   (p. 65)				•	•
Check the starter drive. 				•	•
Check the reed valve housing, diaphragm, and intake manifold. 			•	•	•
Perform minor engine service. (Change the piston. Check the cylinder head. Change the O-rings of the manifold and the cylinder head. Check the cylinder and Z-dimension. Clean the exhaust control. Check the exhaust control for function and smooth operation. Program the exhaust control end positions. Check the pressure sensor flange for cracks and damage. Remove combustion residues from the exhaust port. Change the bracket for the crankshaft position sensor.) 			•	•	•
Perform major engine service including removing and re-installing the engine. (Change the connecting rod, big (bottom) end bearing and crankshaft pin. Check the transmission and shift mechanism. Change all the engine bearings, the radial shaft seal rings, and the seals.) 				•	•
Final check: check vehicle for operating safety. 		○	•	•	•
Take a test ride. 		○	•	•	•
Read out the fault memory after the test ride using the diagnostics tool. 		○	•	•	•
Enter electronic proof of service. 		○	•	•	•

- One-time interval
- Periodic interval

10.1 Checking the basic chassis setting with the rider's weight

i Note

When adjusting the basic chassis setting, first adjust the shock absorber and then the fork.



- For optimal motorcycle riding characteristics and to avoid damage to forks, shock absorbers, swingarm, and frame, the basic settings of the suspension components must match the rider's weight.
- As delivered, KTM offroad motorcycles are adjusted for an average rider's weight (with full protective clothing).

Standard rider's weight	75 kg ... 85 kg (165.3 lb ... 187.4 lb)
-------------------------	---

- If the rider's weight is above or below this range, the basic setting of the suspension components must be adjusted accordingly.
- Small weight differences can be compensated for by adjusting the preload, but in the case of large weight differences, the springs must be replaced.

10.2 Compression damping of the shock absorber

The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed.

High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed.

The high-speed compression has an effect, for example, when landing after a jump: the rear wheel suspension compresses quickly.

The low-speed compression has an effect, for example, when riding over long bumps: the rear wheel suspension compresses slowly.

These two ranges can be adjusted separately, although the transition between high-speed and low-speed is floating. As a result, changes in the high-speed range affect the compression damping in the low-speed range and vice versa.

10.3 Adjusting the low-speed compression damping of the shock absorber




CAUTION

Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided.

i Note

The effect of the low-speed compression adjustment can be seen in slow to normal compression of the shock absorber.



- Turn adjusters ① clockwise up to the last perceptible click.
- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Low-speed compression damping (All SX models)	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks

Low-speed compression damping (XC)	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks

i Note
Turning clockwise increases damping; turning anticlockwise reduces damping.



10.4 Adjusting the high-speed compression damping of the shock absorber



CAUTION


Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided.



Note

The effect of the high-speed compression adjustment can be seen in the fast compression of the shock absorber.



- Turn adjusters ① clockwise all the way to the stop.
- Turn counterclockwise by the number of turns corresponding to the shock absorber type.

High-speed compression damping (All SX models)	
Comfort	2 turns (720°)
Standard	1.5 turns (540°)
Sport	1 turn (360°)

High-speed compression damping (XC)	
Comfort	2 turns (720°)
Standard	1.5 turns (540°)
Sport	1 turn (360°)



Note

Turning clockwise increases damping; turning anticlockwise reduces damping.


10.5 Adjusting the rebound damping of the shock absorber



CAUTION

Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided.



- Turn adjusters ① clockwise up to the last perceptible click.
- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Rebound damping (All SX models)	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks

Rebound damping (XC)	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks



Note

Turning clockwise increases damping; turning anticlockwise reduces damping on rebound.

10.6 Measuring the dimension of the unloaded rear wheel

Preparatory work


- Raise the motorcycle with a lift stand. 📖 (p. 56)

Control process

- Position the sag scale in the rear axle and measure the distance to marking **SAG** on the rear fender.

Sag scale (00029090200)

- Note the value as dimension **A**.




Reworking

- Remove the motorcycle from the lift stand. 📖 (p. 56)



10.7 Checking the static sag of the shock absorber



- Measure dimension **A** of rear wheel unloaded. (p. 45)
- Hold the motorcycle upright with aid of an assistant.
- Measure the distance again between the rear axle and marking **SAG** on the rear fender using the sag scale.
- Note the value as dimension **B**.



Note


The static sag is the difference between measurements **A** and **B**.

- Check the static sag.

Static sag (All SX models)	35 mm (1.38 in)
Static sag (XC)	35 mm (1.38 in)

- » If the static sag is more or less than the specified value:
 - Adjust the preload for the shock absorber. (p. 47)

10.8 Checking the rider sag of the shock absorber



- Measure dimension **A** of rear wheel unloaded. (p. 45)
- With another person holding the motorcycle, sit on the saddle with full protective clothing in a normal sitting position (feet on footrests) and bounce up and down a few times.
 - ✓ The rear wheel suspension levels out.
- With the help of another person, remeasure the distance between the rear axle and marking **SAG** on the rear fender using the sag scale.
- Note the value as dimension **C**.



Note

The rider sag is the difference between measurements **A** and **C**.

- Check the rider sag.

Rider sag (All SX models)	105 mm (4.13 in)
Rider sag (XC)	105 mm (4.13 in)

- » If the rider sag differs from the specified measurement:
 - Adjust the rider sag. (p. 48)

10.9 Adjusting the preload for the shock absorber



CAUTION

Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.






- Please follow the description provided.



Note

Before changing the preload, make a note of the present setting, e.g., by measuring the spring length.

Preparatory work

- Raise the motorcycle with a lift stand.  (p. 56)
- Remove the frame protector.  (p. 71)
- Remove the muffler.  (p. 77)
- Remove the shock absorber.   (p. 67)
- After removing the shock absorber, clean it thoroughly.

Adjustment procedure

- Loosen screw **1**.
- Turn adjusting ring **2** until the spring is no longer under tension.

Hook wrench (90129051000)



Note

If the spring cannot be fully released, the spring must be removed to accurately measure the spring length.

- Measure the total spring length while the spring is not under tension.
- Tension the spring by turning adjusting ring **2** to the specified degree **A**.

Preload (All SX models)	8 mm (0.31 in)
Preload (XC)	8 mm (0.31 in)



Note


Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

- Tighten screw **1**.

Screw, shock absorber adjusting ring

M5	5 Nm (3.7 ft-lb _r)
----	-----------------------------------

Make sure that the adjusting ring does not touch any other components when installed.



Reworking

- Install the shock absorber. 🛠️ 📖 (p. 68)
- Check the free travel of the brake pedal. 📖 (p. 98)
- Install the muffler. 📖 (p. 77)
- Install the frame protector. 📖 (p. 71)
- Remove the motorcycle from the lift stand. 📖 (p. 56)


10.10 Adjusting the rider sag 🛠️

Preparatory work

- Raise the motorcycle with a lift stand. 📖 (p. 56)
- Remove the frame protector. 📖 (p. 71)
- Remove the muffler. 📖 (p. 77)
- Remove the shock absorber. 🛠️ 📖 (p. 67)
- After removing the shock absorber, clean it thoroughly.

Adjustment procedure

- Select and mount a suitable spring.



Spring rate (All SX models)	
Weight of rider: 65 kg ... 75 kg (143.3 lb ... 165.3 lb)	36 N/mm (205.6 lb _f /in)
Weight of rider: 75 kg ... 85 kg (165.3 lb ... 187.4 lb)	39 N/mm (222.7 lb _f /in)
Weight of rider: 85 kg ... 95 kg (187.4 lb ... 209.4 lb)	42 N/mm (239.8 lb _f /in)

Spring rate (XC)	
Weight of rider: 65 kg ... 75 kg (143.3 lb ... 165.3 lb)	36 N/mm (205.6 lb _f /in)
Weight of rider: 75 kg ... 85 kg (165.3 lb ... 187.4 lb)	39 N/mm (222.7 lb _f /in)
Weight of rider: 85 kg ... 95 kg (187.4 lb ... 209.4 lb)	42 N/mm (239.8 lb _f /in)



Note

The spring rate is shown on the outside of the spring.


Reworking

- Install the shock absorber. 🛠️ 📖 (p. 68)
- Check the free travel of the brake pedal. 📖 (p. 98)
- Install the muffler. 📖 (p. 77)
- Install the frame protector. 📖 (p. 71)
- Remove the motorcycle from the lift stand. 📖 (p. 56)
- Check the static sag of the shock absorber. 📖 (p. 46)

- Check the rider sag of the shock absorber. 📖 (p. 46)
- Adjust the rebound damping of the shock absorber. 📖 (p. 44)



10.11 Air suspension XACT



Air suspension **WP XACT** is used in the fork.

In this system, the suspension is located in the left fork leg and damping in the right fork leg.

As fork springs are no longer required, a significant weight advantage is achieved when compared to conventional forks. The response on slightly uneven surfaces is significantly improved.

In normal driving mode, suspension is provided exclusively by an air cushion. A steel spring is located in the left fork leg as an end stop.

i Note

If the fork frequently bottoms out, then the fork air pressure must be increased to avoid damage to the fork and frame.

The air pressure in the fork can be quickly adjusted to the rider's weight, surface conditions, and the rider's preference using a fork air pump. The fork does not have to be dismantled. The time-consuming mounting of harder or softer fork springs is not required.

If the air chamber loses air due to a damaged seal, the fork will still not sag. In this case the air is retained in the fork. The suspension travel is maintained as far as possible. The damping becomes harder, and the riding comfort is reduced.

As with a conventional fork, the damping can be adjusted in rebound and compression stages.


The rebound adjustment is located at the lower end of the right fork leg.

The compression adjustment is located at the upper end of the right fork leg.

10.12 Checking the basic setting of the fork

i Note

For various reasons, no exact rider sag can be determined for the fork.



- Smaller differences in the rider's weight can be compensated for by the fork air pressure.
- However, if the fork frequently bottoms out (hard end stop on compression), the fork air pressure must be increased, within the specified values, to avoid damage to the fork and frame.
- If the fork feels unusually hard after extended periods of operation, the fork legs need to be bled.



10.13 Adjusting the fork air pressure (All SX models)



WARNING

Danger of accidents Modifications to the suspension settings that are not properly coordinated can impair the handling and overload components.


- Only make adjustments within the recommended range.
- Ride slowly to start with after making adjustments to get the feel of the new handling characteristics.



Note

Check or adjust the air pressure under the same conditions at the earliest 5 minutes after switching off the engine.

The air suspension is located in the left fork leg. The pressure and rebound damping is located in the right fork leg.



Preparatory work

- Raise the motorcycle with a lift stand. (p. 56)

Filling procedure

- Remove protection cap ①.
- Fully put fork air pump ② together.

Fork air pump (79412966100)



Note

The fork air pump is included as part of the motorcycle's accessory pack.

- Connect the fork air pump to the left fork leg.

Read the accompanying instructions.

- ✓ The fork air pump indicator switches on automatically.
- ✓ A little air escapes from the fork leg when connecting.



Note

This is due to the volume of the hose and is not due to a defect in the fork air pump or the fork.

- Adjust the air pressure as specified.

Do not set the air pressure outside the specified range.
--

Air pressure

Weight of rider: 65 kg ... 75 kg (143.3 lb ... 165.3 lb)	8.4 bar (121.8 psi)
Weight of rider: 75 kg ... 85 kg (165.3 lb ... 187.4 lb)	8.6 bar (124.7 psi)
Weight of rider: 85 kg ... 95 kg (187.4 lb ... 209.4 lb)	8.8 bar (127.6 psi)

Gradual change of the air pressure in steps by	0.2 bar (2.9 psi)
--	----------------------

Minimum air pressure	7 bar (102 psi)
----------------------	--------------------

Maximum air pressure	12 bar (174 psi)
----------------------	---------------------

- Disconnect the fork air pump from the left fork leg.
 - ✓ When disconnecting, excess pressure will escape from the hose – the fork leg itself does not lose any air.
 - ✓ The fork air pump display switches off automatically after 80 seconds.
- Mount the protection cap.

Only mount the protection cap by hand.

Reworking


- Remove the motorcycle from the lift stand. 📖 (p. 56)



10.14 Adjusting the compression damping of the fork

i Note

The hydraulic compression damping determines the fork suspension behavior.



(All SX models)

- Turn adjusters ① clockwise up to the last perceptible click.

i Note

Adjusters ① are located at the top end of the fork legs.

- Turn clockwise by the number of clicks corresponding to the fork type.

Compression damping	
Comfort	17 clicks
Standard	12 clicks
Sport	7 clicks

i Note

Turning clockwise increases damping; turning counterclockwise reduces damping during compression.


(XC)

- Turn adjusters ① clockwise up to the last perceptible click.

i Note

Adjusters ① are located at the top end of the fork legs.

- Turn clockwise by the number of clicks corresponding to the fork type.




Compression damping	
Comfort	17 clicks
Standard	12 clicks
Sport	7 clicks

i Note
Turning clockwise increases damping; turning counterclockwise reduces damping during compression.

10.15 Adjusting the rebound damping of the fork

i Note
The hydraulic rebound damping determines the fork suspension behavior.



(All SX models)


- Turn adjusting screw ① clockwise all the way.

i Note
Adjusting screw ① is located at the lower end of the right fork leg.

- Turn clockwise by the number of clicks corresponding to the fork type.

Rebound damping	
Comfort	17 clicks
Standard	12 clicks
Sport	7 clicks

i Note
Turning clockwise increases damping; turning anticlockwise reduces damping on rebound.



(XC)

- Turn adjusting screws ① clockwise all the way.


i Note
Adjusting screws ① are located at the lower end of the right fork leg.

- Turn clockwise by the number of clicks corresponding to the fork type.

Rebound damping	
Comfort	23 clicks
Standard	18 clicks
Sport	13 clicks

i Note
Turning clockwise increases damping; turning anticlockwise reduces damping on rebound.

10.16 Handlebar position



The holes on handlebar mount ① are placed at a distance of ② from the center.

Hole distance A	3.5 mm (0.138 in)
-----------------	----------------------

The handlebar can be mounted in 2 different positions. This allows the handlebar to be mounted in the most comfortable position for the rider.

Note
In addition, the handlebar can be mounted rigidly or on a rubber support.

10.17 Adjusting the handlebar position



WARNING

Danger of accidents A repaired handlebar poses a safety risk. If the handlebar is bent or straightened, the material becomes fatigued. The handlebar may break as a result.

- Change the handlebar if the handlebar is damaged or bent.




Note

The handlebar can be mounted rigidly or on a rubber bearing.

Preparatory work

- Remove the handlebar pad.



Adjustment procedure

- Remove screws **1**. Remove handlebar clamp **2**. Remove the handlebar and lay it to one side.

Protect the components against damage by covering them.

Do not kink the cables or lines.

- Remove screws **7** and bushings **6**. Remove handlebar mount **3**.

- Select one of the following alternatives.

Adjusting the handlebar position with handlebar clamp with rubber bushings

- Position the rubber bushings **4** and **5**.
- Place the handlebar mount in the required position.



Note

The handlebar mount is longer and higher on one side.

- Mount screws **7** and bushings **6** and tighten.


Screw, handlebar mount on triple clamp	
M10	40 Nm (29.5 ft·lb _f) Loctite® 243

- Position the handlebar.

Make sure the cables and wiring are positioned correctly.

- Position handlebar clamp **2**.
- Mount screws **1**, but do not tighten yet.
- First fasten the handlebar clamp with screws **1** onto the longer, higher side of the handlebar mounts.
- Tighten screws **1** evenly.

Screw, handlebar clamp on handlebar mount	
M8	20 Nm (14.8 ft·lb _f)



Adjusting the handlebar position with the rigid handlebar clamp

- Place the handlebar mount in the required position.



Note

The handlebar mount is longer and higher on one side.

- Mount screws **7** and bushings **8** and tighten.

Screw, handlebar mount on triple clamp	
M10	40 Nm (29.5 ft·lb _f) Loctite® 243

Rigid handlebar clamp bushing (A46001038010)	
--	--

✓ The conical side of the bushing faces downward.

- Position the handlebar.

Make sure the cables and wiring are positioned correctly.

- Position handlebar clamp **2**.
- Mount screws **1**, but do not tighten yet.
- First fasten the handlebar clamp with screws **1** onto the longer, higher side of the handlebar mounts.
- Tighten screws **1** evenly.

Screw, handlebar clamp on handlebar mount	
M8	20 Nm (14.8 ft·lb _f)

Reworking

- Mount the handlebar pad.



11.1 Raising the motorcycle with a lift stand




NOTE

Material damage The vehicle may be damaged if parked incorrectly.

Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Make sure that nobody sits on the vehicle when it is parked on a stand.



- Raise the motorcycle at the frame underneath the engine.

Lift stand (78129955100)

- ✓ Neither wheel is in contact with the ground.
- Secure the motorcycle against falling over.

11.2 Removing the motorcycle from the lift stand




NOTE

Material damage The vehicle may be damaged if parked incorrectly.

Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Make sure that nobody sits on the vehicle when it is parked on a stand.




(All SX models)

- Remove the motorcycle from the lift stand.
- Remove the lift stand.
- To park the motorcycle, insert plug-in stand ❶ on the left side of the wheel spindle.

Remove the plug-in stand before riding.

Plug-in stand (A46029094000)



(XC)

- Remove the motorcycle from the lift stand.
- Remove the lift stand.
- To park the motorcycle, press side stand ❶ to the ground with your foot and lean the motorcycle on it.

When you are riding, the side stand must be folded up and secured with the rubber band.

11.3 Bleeding the fork legs


Preparatory work

- Raise the motorcycle with a lift stand. 📖 (p. 56)

Operating procedure


(All SX models)

- Loosen bleeder screw ❶.
- ✓ Any excess pressure escapes from the inner fork.
- Tighten the bleeder screw.



(XC)

- Loosen bleeder screw ❶.
- ✓ Any excess pressure escapes from the inner fork.
- Tighten the bleeder screw.



Reworking

- Remove the motorcycle from the lift stand. 📖 (p. 56)

11.4 Cleaning the dust boots of the fork legs


Preparatory work

- Raise the motorcycle with a lift stand. 📖 (p. 56)
- Remove the fork protector. 📖 (p. 58)

Cleaning process

- Push dust boot ❶ downward on both fork legs.

i Note
The dust boots should remove dust and coarse dirt particles from the inner fork tubes. Over time, dirt can accumulate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.





WARNING

Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.



- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.

- Clean and oil the dust boots and the inner fork tube of both fork legs.


Universal oil spray  (p. 161)
--

- Press the dust boots back into their installation position.
- Remove excess oil.

Reworking


- Install the fork protector.  (p. 58)
- Remove the motorcycle from the lift stand.  (p. 56)

11.5 Removing the fork protector



- Remove screws **1**.
- Take off the clamp.
- Remove screws **2**.
- Take off the left fork protector.
- Remove screws **3**.
- Remove the right fork protector.

11.6 Installing the fork protector



- Position the fork protector on the left fork leg. Mount and tighten screws **1**.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb _f)

M6	10 Nm (7.4 ft·lb _f)
----	------------------------------------




- Position the brake line and the clamp. Mount and tighten screws **2**.
- Position the fork protector on the right fork leg. Mount and tighten screws **3**.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb _f)

M6	10 Nm (7.4 ft·lb _f)
----	------------------------------------

11.7 Removing the fork legs



Preparatory work

- Raise the motorcycle with a lift stand.  (p. 56)
- Remove the front wheel.   (p. 104)

Removal process

- Remove screw **1** and take off the clamp.
- Remove screws **2** and take off the brake caliper.
- Allow the brake caliper and the brake line to hang loosely to the side.

Do not actuate the hand brake lever when the front wheel is removed.




- Loosen screws **3**. Remove the left fork leg.
- Loosen screws **4**. Remove the right fork leg.

11.8 Installing the fork legs

Installation procedure

(All SX models)


- Position the fork legs.
 - ✓ Bleed screw **1** of the right fork leg is positioned to the front.
 - ✓ Valve **A** of the left fork leg faces the front.



Note

Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp.

The air suspension is located in the left fork leg. The pressure and rebound damping is located in the right fork leg.



(XC)


- Position the fork legs.
- ✓ Bleeder screws **1** of the fork legs are positioned toward the front.



Note

Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp.

The air suspension is located in the left fork leg. The pressure and rebound damping is located in the right fork leg.




- Tighten screws **2**.

Screw, top triple clamp	
M8	17 Nm (12.5 ft·lb _f)

- Tighten screws **3**.

Screw, bottom triple clamp	
M8	12 Nm (8.9 ft·lb _f)



- Position the brake caliper. Mount and tighten screws **4**.

Screw, front brake caliper	
M8	25 Nm (18.4 ft·lb _f)
Loctite® 243	

- Position the brake line and the clamp. Mount and tighten screws **5**.


Reworking

- Install the front wheel. (p. 105)

11.9 Removing the lower triple clamp

Preparatory work

- Raise the motorcycle with a lift stand. (p. 56)
- Remove the front wheel. (p. 104)
- Remove the fork legs. (p. 59)
- Remove the number plate. (p. 65)
- Remove the front top fender. (p. 66)
- Remove the handlebar pad.




Removal process

- Remove screw ①. Detach the wiring harness.
- Remove screw ②.
- Remove screw ③.
- Take off the upper triple clamp with the handlebar and place to one side.

Protect the components against damage by covering them.

Do not kink the cables or lines.




- Remove steering head seal ④.
- Remove the steering stem from the lower triple clamp.
- Remove the upper steering head bearing.


11.10 Installing the lower triple clamp

Installation procedure


- Clean the bearing and sealing elements, check for damage, and grease.

High viscosity grease  (p. 162)

- Insert the lower triple clamp with the steering stem. Mount the upper steering head bearing.
- Push on steering head seal ①.




11 Service work on the chassis




- Position the upper triple clamp and handlebar.
- Mount screw ②, but do not tighten yet.

Screw, top steering head	
M20×1.5	12 Nm (8.9 ft·lb _f)




- Position the fork legs.
 - ✓ Bleed screw ③ of the right fork leg is positioned to the front.
 - ✓ Valve A of the left fork leg faces the front.

i Note
Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp. The air suspension is located in the left fork leg. The pressure and rebound damping is located in the right fork leg.




- Tighten screws ④.

Screw, bottom triple clamp	
M8	12 Nm (8.9 ft·lb _f)




- Tighten screw ②.

Screw, top steering head	
M20×1.5	12 Nm (8.9 ft·lb _f)



- Mount and tighten screw ⑤.

Screw, upper steering stem	
M8	20 Nm (14.8 ft·lb _f) Loctite® 243




- Using a plastic hammer, tap lightly on the upper triple clamp to avoid stresses.
- Tighten screws 6.

Screw, top triple clamp	
M8	17 Nm (12.5 ft·lb _f)

- Secure the wiring harness with the left cable bracket. Mount and tighten screw 7.

Remaining screws on chassis	
M5	5 Nm (3.7 ft·lb _f)



- Position the brake caliper. Mount and tighten screws 8.

Screw, front brake caliper	
M8	25 Nm (18.4 ft·lb _f) Loctite® 243

- Position the brake line and the clamp. Mount and tighten screws 9.

Remaining screws on chassis	
EJOT PT® – K60×25 – Z	2 Nm (1.5 ft·lb _f)

Reworking

- Install the front top fender. 📖 (p. 66)
- Mount the handlebar pad.
- Mount the number plate. 📖 (p. 65)
- Install the front wheel. 🛠️ 📖 (p. 105)
- Check the wiring harness, cables, and brake and clutch lines for freedom of movement and correct routing.
- Check the steering head bearing play. 📖 (p. 63)
- Remove the motorcycle from the lift stand. 📖 (p. 56)



11.11 Checking the steering head bearing play



WARNING

Danger of accidents Incorrect steering head bearing play can impair the handling characteristic and damage components.

- Correct incorrect steering head bearing play immediately.




Note

If the vehicle is operated for a lengthy period with play in the steering head bearing, the bearings and the bearing seats in the frame can become damaged.

Preparatory work

- Raise the motorcycle with a lift stand. 📖 (p. 56)



Control process

- Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

Play should not be detectable on the steering head bearing.

- » If there is detectable play:
 - Adjust the steering head bearing play. (p. 64)

- Move the handlebar back and forth over the entire steering range.

It must be possible to move the handlebar easily over the entire steering range. There should be no detectable detent positions.

- » If detent positions are detected:
 - Adjust the steering head bearing play. (p. 64)
 - Check the steering head bearing and adjust if necessary.

Reworking

- Remove the motorcycle from the lift stand. (p. 56)


11.12 Adjusting the steering head bearing play

Preparatory work

- Raise the motorcycle with a lift stand. (p. 56)
- Remove the handlebar pad.

Adjustment procedure

- Loosen screws **1**.
- Remove screw **2**.
- Loosen and retighten screw **3**.



Screw, top steering head	
M20×1.5	12 Nm (8.9 ft·lb _f)



- Using a plastic hammer, tap lightly on the upper triple clamp to avoid stresses.
- Tighten screws **1**.

Screw, top triple clamp	
M8	17 Nm (12.5 ft·lb _f)

- Mount and tighten screw **2**.


Screw, upper steering stem	
M8	20 Nm (14.8 ft·lb _f)
Loctite® 243	





Reworking

- Check the steering head bearing play.  (p. 63)
- Remove the motorcycle from the lift stand.  (p. 56)
- Mount the handlebar pad.



11.13 Lubricating the steering head bearing



- Remove the lower triple clamp.   (p. 60)
- Install the lower triple clamp.   (p. 61)




Note

The steering head bearing is cleaned and lubricated in the course of removal and installation of the lower triple clamp.




11.14 Removing the number plate



- Remove screw **1**.
- Unhook the number plate from the brake line and remove it.



11.15 Mounting the number plate



- Position the brake line in holders **A** on the number plate.
- Position the number plate. Mount and tighten screw **1**.

Remaining screws on chassis	
EJOT PT®	2 Nm (1.5 ft·lb _f)

- ✓ The holding lugs engage in the fender.




11.16 Removing the front top fender

Preparatory work

- Remove the number plate. 📖 (p. 65)

Removal process


- Remove screws ❶ and ❷. Remove the front fender.



11.17 Installing the front top fender

Installation procedure

- Position the front fender. Mount and tighten screws ❶ and ❷.



Screw, fender	
M6	12 Nm (8.9 ft·lb _f)

Reworking

- Mount the number plate. 📖 (p. 65)




11.18 Removing the shock absorber 🛠️

Preparatory work

- Raise the motorcycle with a lift stand. 📖 (p. 56)
- Remove the frame protector. 📖 (p. 71)
- Remove the muffler. 📖 (p. 77)

Removal process


- Remove screw ❶.
- Remove screw connection ❷.



Tip


Raise the swingarm slightly to be able to remove the screws more easily.

- Remove screws ❸.
- Pull brake cylinder off of the push rod.




- Remove connecting link ❹ on the chain.
- Take off the chain.


Protect the components against damage by covering them.



- Remove nut ❺ and the swingarm pivot.
- Push the swingarm back and secure it against falling over.




11 Service work on the chassis



- Hold the shock absorber and remove screw ⑥.
- Remove the shock absorber carefully at the bottom.


11.19 Installing the shock absorber

Installation procedure



- Carefully position the shock absorber into the vehicle from the bottom.
- Mount and tighten screw ①.

Top shock absorber screw	
M10	60 Nm (44.3 ft·lb _f) Loctite® 2701




- Position the swingarm and fit the swingarm pivot.

Pay attention to flat area ①.


- Mount and tighten nut ②.

Nut, swingarm pivot	
M16×1.5	100 Nm (73.8 ft·lb _f)



- Mount the chain.
- Connect the chain with connecting link ③.

The closed side of the master link clip must face in the direction of travel.



- Position the brake cylinder.


Ensure that the dust boot is properly seated.

- ✓ Push rod 4 engages in the brake cylinder.

- Mount and tighten screws 5.

Remaining screws on chassis

M6	10 Nm (7.4 ft·lb _r)
----	------------------------------------



- Position the power valve control lever and linkage lever.

- Mount and tighten screw connection 6.

Nut, linkage lever on angle lever

M16×1.5	80 Nm (59.0 ft·lb _r)
---------	-------------------------------------

Pay attention to flat area B.



Tip

Raise the swingarm slightly to be able to mount the screw more easily.

- Mount and tighten screw 7.


Bottom shock absorber screw

M10	60 Nm (44.3 ft·lb _r) Loctite® 2701
-----	---

Reworking


- Check the free travel of the brake pedal. 📖 (p. 98)
- Install the muffler. 📖 (p. 77)
- Install the frame protector. 📖 (p. 71)
- Remove the motorcycle from the lift stand. 📖 (p. 56)

11.20 Removing the seat




- Remove screw 1.

11 Service work on the chassis





- Raise seat, pull it toward the fuel tank and take it off.

11.21 Mounting the seat




- Attach the seat to the collar bushings at the front and simultaneously push it back.
 - ✓ The holding lugs engage in the recesses at the back.
- Make sure the seat is latched in place correctly.



- Mount and tighten screw ①.

Screw, seat installation	
M6	8 Nm (5.9 ft·lb _r)


11.22 Removing the frame protector



- Remove the cable ties.
- Remove screws **1** and bushings.
- Take off the left frame protector.
- Push the right frame protector to the front and take off at the bottom.



11.23 Installing the frame protector




- Position the left frame protector.
- Insert the right frame protector from below and push it to the rear.
- Mount screw **1** and bushing and tighten.

Screw, frame protector	
M5	3 Nm (2.2 ft·lb _r)

- Secure the frame protector with cable ties.




11.24 Removing the skid plate (XC)



- Remove screws **1** and bushings.
- Remove screws **2**.
- Take off the skid plate.



11.25 Installing the skid plate (XC)



- Position the skid plate on the frame.
- Mount screws **1**, but do not tighten yet.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb _r)

- Mount screws **2** with bushings, but do not tighten yet.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb _r)


- ✓ The skid plate is directed evenly toward the front.
- Tighten all the screws of the skid plate.

11.26 Removing air filter box cover

Condition: Air filter box cover secured




- Remove screw **1**.



- Pull off the air filter box cover in areas **A** and push it sideways and forward. Take off the air filter box cover.


Condition: Air filter box cover not secured




- Pull off the air filter box cover in areas **A** and push it sideways and forward. Take off the air filter box cover.

11.27 Installing air filter box cover

Condition: Air filter box cover secured




- Attach the air filter box cover in areas **A** and clip in areas **B**.



- Mount and tighten screw **1**.

Screw, air filter box cover	
EJOT PT®	3 Nm (2.2 ft·lb _r)

Condition: Air filter box cover not secured



- Attach the air filter box cover in areas **A** and clip in areas **B**.

11.28 Removing the air filter



NOTE

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.




NOTE

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

Dust and dirt can enter the engine if there is no air filter or if the air filter is mounted incorrectly.


- Only operate the vehicle if an air filter is correctly fitted.

Preparatory work

- Remove air filter box cover.  (p. 72)


Removal process




- Detach tab **1**. Remove air filter with air filter support.
- Remove the air filter with the air filter support.



11.29 Cleaning the air filter and air filter box **NOTE****Environmental hazard** Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

**Preparatory work**


- Remove air filter box cover.  (p. 72)
- Remove the air filter.   (p. 74)

Cleaning process

- Wash the air filter thoroughly in special cleaning liquid and allow it to dry properly.

Do not clean the air filter with fuel or petroleum as these substances will damage the foam rubber.

Only press the air filter to dry it, never wring it out.
--




Air filter cleaning agent  (p. 163)
--

- Oil the dry air filter with a high-grade air filter oil.

Oil for foam air filter  (p. 162)
--




- Clean the air filter box.
- Clean the intake flange and check it for damage and that it is firmly seated.

Reworking

- Install the air filter.   (p. 76)
- Install the air filter box cover.  (p. 73)



11.30 Installing the air filter




Installation procedure

- Mount the clean air filter on the air filter support.

The marking on the air filter support must face upwards.

- Grease the air filter in area **A**.

Long-life grease  (p. 161)

- Insert air filter and position retaining pin **1** in bushing **B**.

The marking on the air filter must face upwards.


- Attach tab **2**.

✓ Retaining pin **3** is secured by tab **2**.

Note


If the air filter is not mounted correctly, dust and dirt may enter the engine and result in damage.

Reworking


- Install the air filter box cover.  (p. 73)

11.31 Preparing the air filter box cover for securing

Preparatory work

- Remove air filter box cover.  (p. 72)

Installation procedure



- Drill a hole at marking **A**.

Diameter	6 mm (0.24 in)
----------	-------------------

Reworking

- Install the air filter box cover. (p. 73)


11.32 Removing the muffler



WARNING


Danger of burns The exhaust system gets hot when the vehicle is driven.

- Allow the exhaust system to cool down before performing any work on the vehicle.



- Remove screws **1** with the washers.
- Pull off the main silencer from the manifold at exhaust sleeve **2**.

11.33 Installing muffler



- Position the main silencer in exhaust sleeve **1**.
- Mount and tighten screws **2** with the washers.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb _f)

11.34 Changing the glass fiber yarn filling in the main silencer



WARNING


- Danger of burns** The exhaust system gets hot when the vehicle is driven.
- Allow the exhaust system to cool down before performing any work on the vehicle.



Note


Over time, the fibers of the damping wool escape into the air, and the muffler “burns out”. Not only does this make the noise level higher, but the performance characteristics also change.

Preparatory work

- Remove the muffler.  (p. 77)

Replacement process


- Remove screws **1**. Pull out inner tube **2** with O-ring **3**.
- Remove the glass fiber yarn filling **4** from the inner tube.
- Clean the parts that need to be reinstalled and check for damage.
- Fit the new glass fiber yarn filling **4** into the inner tube.
- Mount O-ring **3** on inner tube **2**.
- Slide outer tube **5** over the inner tube with the new glass fiber yarn filling.
- Mount and tighten all screws **1**.



Screws on muffler

M5	7 Nm (5.2 ft·lb _f)
----	-----------------------------------

Reworking

- Install the muffler.  (p. 77)

11.35 Removing the fuel tank



DANGER

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
- Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it up immediately.
- Do not overfill the fuel tank.



WARNING

Danger of poisoning Fuel is harmful to health.


- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.

Preparatory work

- Remove the seat. (p. 69)


Removal process

- Remove the cable tie of protection cap **1**.
- Remove the protection cap of the fuel line.



- Unplug socket connector **2** of the fuel pump.
- Clean quick-lock coupling **3** thoroughly with compressed air.

Dirt must not enter into the fuel line. Dirt in the fuel line clogs the injector!



- Disconnect the quick-lock coupling.




Note

Remaining fuel may flow out of the fuel hose.


- Mount wash cap set **4**.

Wash cap set (81212016100)


- Pull the fuel tank vent hose off the fuel tank cap.




11 Service work on the chassis



- Remove screw 5 with the rubber bushing.



- Remove screws 6 with collar bushings.



- Pull both spoilers laterally off the radiator and lift off the fuel tank.

11.36 Installing the fuel tank



DANGER

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
- Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it up immediately.
- Do not overfill the fuel tank.




WARNING

Danger of poisoning Fuel is harmful to health.

- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.

Installation procedure




- Check the throttle cable routing. (p. 87)
- Position the fuel tank and fit both spoilers to the side of the radiator.

Make sure that no wires or cables are trapped or damaged.

- Attach the fuel tank vent hose to the fuel tank cap.
- Mount and tighten screws **1** with the collar bushings.

Screw, fuel tank spoiler on radiator


M6	6 Nm (4.4 ft·lb _f)
----	-----------------------------------



- Mount and tighten screw **2** with the rubber bushing.

Remaining screws on chassis

M6	10 Nm (7.4 ft·lb _f)
----	------------------------------------



- Plug in fuel pump socket connector **3**.
- Remove the wash cap set and thoroughly clean the quick-lock coupling using compressed air.


Dirt must not enter into the fuel line. Dirt in the fuel line clogs the injector!

- Spray silicone spray onto a lint-free cleaning cloth and lightly lubricate the O-ring of the quick-lock coupling.

Silicone spray (p. 162)

- Join quick-lock coupling **4** of the fuel line.

Route the wire and fuel line at a safe distance from the exhaust system.




- Mount the protection cap of the fuel line.
- Mount the cable tie of protection cap **5**.

Reworking

- Mount the seat. (p. 70)

11.37 Checking the chain for dirt



- Check the chain for coarse dirt accumulation.
 - » If the chain is very dirty:
 - Clean the chain. 📖 (p. 82)

11.38 Cleaning the chain



WARNING

Danger of accidents Lubricants on the tires reduces the road grip.

- Remove lubricants from the tires using a suitable cleaning agent.



WARNING

Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.

- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.



NOTE

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.



Note

The service life of the chain depends largely on its maintenance.

Preparatory work

- Raise the motorcycle with a lift stand. 📖 (p. 56)


Cleaning process

- Rinse off the loose dirt with a gentle jet of water.
- Remove old grease residues with a chain cleaner.

Chain cleaner 📖 (p. 163)

- After drying, apply chain spray.

Off-road chain spray 📖 (p. 161)



Reworking

- Remove the motorcycle from the lift stand. 📖 (p. 56)

11.39 Checking the chain tension



WARNING

Danger of accidents Incorrect chain tension can damage components and result in an accident.

If the chain tension is too high, the chain, front sprocket, rear sprocket, transmission, and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the front sprocket or the rear sprocket. This can damage the rear wheel or the engine.


- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

Preparatory work

- Raise the motorcycle with a lift stand. (p. 56)

Control process

- Pull the chain at the end of the chain slider upward to measure chain tension **A**.



Lower chain section **1** must be taut.

Chain tension	58 mm ... 61 mm (2.28 in ... 2.40 in)
---------------	--

Chain wear is not always even, so repeat this measurement at different positions on the chain.

- » If the chain tension does not meet the specification:
 - Adjust the chain tension. (p. 83)

Reworking

- Remove the motorcycle from the lift stand. (p. 56)



11.40 Adjusting the chain tension



WARNING

Danger of accidents Incorrect chain tension can damage components and result in an accident.


If the chain tension is too high, the chain, front sprocket, rear sprocket, transmission, and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the front sprocket or the rear sprocket. This can damage the rear wheel or the engine.

- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

Preparatory work

- Raise the motorcycle with a lift stand. (p. 56)
- Check the chain tension. (p. 83)



Adjustment procedure

- Loosen nut ①.
- Loosen nuts ②.
- Adjust the chain tension by turning adjusting screws ③ on the left and right.

Chain tension	58 mm ... 61 mm (2.28 in ... 2.40 in)
---------------	--

In order for the rear wheel to be correctly aligned, the markings on the left and right chain adjusters must be in the same position relative to reference markings A.

- Tighten nuts ②.
- Make sure that chain tension adjusters ④ are fitted correctly on adjusting screws ③.
- Tighten nut ①.

Nut, wheel spindle, rear	
M22×1.5	80 Nm (59.0 ft·lb _f)

Note
The wide range of adjustment of the chain tension adjusters (32 mm) enables different secondary transmissions with the same chain length.
Chain tension adjusters ④ can be turned by 180°.

Reworking

- Remove the motorcycle from the lift stand. 📖 (p. 56)

11.41 Checking the chain, rear sprocket, front sprocket, and chain guide


Preparatory work


- Raise the motorcycle with a lift stand. 📖 (p. 56)

Control process

- Shift the transmission into the neutral position.
- Check the chain, rear sprocket, and front sprocket for wear.
 - » If the chain, rear sprocket, or front sprocket is worn:
 - Change the drivetrain kit. 🛠️

The front sprocket, rear sprocket, and chain should always be replaced together.





- Pull on the top section of the chain with the specified weight **A**.

Weight, chain wear measurement	10 kg ... 15 kg (22.0 lb ... 33.1 lb)
--------------------------------	--

- Measure distance **B** of chain rollers in the lower chain section.


Maximum distance B of chain rollers at the longest chain section	272 mm (10.71 in)
---	----------------------

Chain wear is not always even, so repeat this measurement at different positions on the chain.

- » If distance **B** is greater than the specified measurement:
 - Change the drivetrain kit. 🛠️

When you replace the chain, you should also replace the rear sprocket and front sprocket.


i Note
New chains wear out faster on old, worn front or rear sprockets.



- Check the chain slider at the top for wear.
 - » If the lower edge of the chain pins is in line with, or below, the chain slider:
 - Change the chain slider. 🛠️
- Check that the chain slider is firmly seated.
 - » If the chain slider is loose:
 - Tighten the screws of the chain slider.


Screw, chain slider guard	
M6	6 Nm (4.4 ft·lb _r) Loctite® 243

11 Service work on the chassis



- Check the chain slider for wear.
 - » If the lower edge of the chain pins is in line with or below the chain slider:
 - Change the chain slider. 🛠️
- Check that the chain slider is firmly seated.
 - » If the chain slider is loose:
 - Tighten the screws of the chain slider.

Screw, chain slider	
M8	15 Nm (11.1 ft·lb _f)



- Check the chain guide with a slide gage for dimension **C**.

Minimum thickness C of the chain guide	6 mm (0.24 in)
---	-------------------

- » If the specifications have not been met:
 - Change the chain guide. 🛠️




- Check that the chain guide is firmly seated.
 - » If the chain guide is loose:
 - Tighten the screws on the chain guide.


Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb _f)
Remaining nuts on chassis	
M6	10 Nm (7.4 ft·lb _f)


Reworking

- Remove the motorcycle from the lift stand. 📖 (p. 56)

11.42 Checking the frame





- Check the frame for damage, cracks, and deformation.
 - » If the frame shows signs of damage, cracks, or deformation:
 - Change the frame. 

Repairs on the frame are not permitted. 

11.43 Checking the swingarm



- Check the swingarm for damage, cracks, and deformation.
 - » If the swingarm shows signs of damage, cracks, or deformation:
 - Change the swingarm. 

Repairs on the swingarm are not permitted. 

11.44 Checking the throttle cable routing






WARNING

Danger of accidents The throttle cable can become kinked, jammed, or blocked if it has been routed incorrectly.

If the throttle cable is kinked, jammed or blocked, the speed can no longer be controlled.

- Make sure that the throttle cable routing and the play in the throttle cable complies with the specification.

Preparatory work

- Remove the seat.  (p. 69)
- Remove the fuel tank.   (p. 78)

11 Service work on the chassis






Control process

- Check the throttle cable routing.


Both throttle cables must be routed, side by side, on the back of the handlebars, above the fuel tank bearing on the right of the frame to the throttle body. The throttle cable must be secured on the fuel tank bearing with a rubber band.

- » If the throttle cable routing is not as specified:
 - Correct the throttle cable routing.

Reworking

- Install the fuel tank.   (p. 80)
- Mount the seat.  (p. 70)

11.45 Checking the hand grip




- Check the hand grips on the handlebar for damage, wear, and that they are firmly seated.

Note

The hand grips are vulcanized onto a sleeve on the left and onto the grip tube of the throttle grip on the right. The left sleeve is clamped onto the handlebar. The hand grip can only be replaced with the sleeve or the gas pipe.

- » If a hand grip is damaged or worn:
 - Replace the hand grip.


- Check that screw **1** is firmly seated.



Screw, fixed grip	
M4	5 Nm (3.7 ft·lb _f)
Loctite® 243	

Diamond **A** must be located at the top.

11.46 Adjusting the basic position of the clutch lever



- Adjust the basic position of the clutch lever to your hand size by turning adjusting screw ①.

Only turn the adjusting screw by hand, and do not use force.

Do not make any adjustments while riding.



Note

When the adjusting screw is turned counterclockwise, the clutch lever moves closer to the handlebar.

When the adjusting screw is turned clockwise, the clutch lever moves away from the handlebar.

The range of adjustment is limited.

11.47 Checking/correcting the fluid level of hydraulic clutch



WARNING

Health hazard Brake fluid is a harmful substance.


- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
- Consult a doctor immediately if brake fluid has been ingested.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Note

The fluid level rises with increasing wear of the friction plates.


Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.



- Move the hydraulic clutch fluid reservoir mounted on the handlebar into a horizontal position.
- Remove screws ①.
- Take off cover ② with diaphragm ③.
- Check the fluid level.

Fluid level below reservoir rim	4 mm (0.16 in)
---------------------------------	-------------------

- » If the fluid level does not meet the specifications:
 - Correct the fluid level of the hydraulic clutch.

Brake fluid DOT 4 / DOT 5.1  (p. 162)

- Position the cover with diaphragm. Mount and tighten the screws.

Immediately clean up any brake fluid that has overflowed or spilled with water.

11.48 Changing the hydraulic clutch fluid



WARNING

Health hazard Brake fluid is a harmful substance.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
- Consult a doctor immediately if brake fluid has been ingested.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



NOTE


Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.




Note

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.




- Move the hydraulic clutch fluid reservoir mounted on the handlebar into a horizontal position.
- Remove screws **1**.
- Take off cover **2** with diaphragm **3**.




- Fill bleeding syringe **4** with the appropriate hydraulic fluid.

Syringe (50329050000)

Brake fluid DOT 4 / DOT 5.1  (p. 162)
--

- Remove the protection cap.
- On the clutch slave cylinder, release bleed screw **5** and mount bleeding syringe **4**.



- Inject the liquid into the system until it escapes from bore **6** of the master cylinder without bubbles.
- Occasionally extract the fluid from the master cylinder reservoir to prevent overflowing.
- Remove the bleeding syringe. Tighten bleed screw **5**.
- Mount the protection cap.
- Correct the fluid level of the hydraulic clutch.

Fluid level below reservoir rim	4 mm
	(0.16 in)

- Position the cover with diaphragm. Mount and tighten the screws.

Immediately clean up any brake fluid that has overflowed or spilled with water.




12.1 Checking the free travel on the hand brake lever



WARNING

- Danger of accidents** The brake system fails in the event of overheating.
If there is no free travel on the brake lever, pressure builds up in the brake system.
- Set the free travel on the brake lever as specified.




- Push the hand brake lever forward and check free travel **A**.

Free travel of hand brake lever	$\geq 3 \text{ mm}$ ($\geq 0.12 \text{ in}$)
---------------------------------	---

- » If the free travel does not meet the specifications:
 - Inspect the brake system for damage and dirt.

12.2 Adjusting the basic position of the hand brake lever



- Check the free travel on the hand brake lever. (p. 92)
- Adjust the basic position of the hand brake lever to your hand size by turning adjusting screw **1**.

Only turn the adjusting screw by hand, and do not use force.

Do not make any adjustments while riding.

Note

Turn the adjusting screw clockwise to increase the distance between the hand brake lever and the handlebar.

Turn the adjusting screw counterclockwise to decrease the distance between the hand brake lever and the handlebar.


The range of adjustment is limited.

12.3 Checking the brake discs



WARNING

- Danger of accidents** Worn-out brake discs reduce the braking action.
- Make sure that worn-out brake discs are replaced immediately.



- Check the brake disc thickness of the front and rear brake disc at several places on the disc to see if they conform to measurement **A**.

Brake disc wear limit	
front	2.5 mm (0.098 in)
rear	3.5 mm (0.138 in)

i Note
Wear reduces the thickness of the brake discs at the contact surface of the brake pads.

- » If the brake disc thickness is less than the specified value:
 - Change the brake discs of the front brake. 🛠️
 - Change the brake discs on the rear brake. 🛠️
- Check the front and rear brake discs for damage, cracks, and deformation.
 - » If the brake disc shows signs of damage, cracks, or deformation:
 - Change the brake discs of the front brake. 🛠️
 - Change the brake discs on the rear brake. 🛠️

12.4 Checking the brake fluid level for the front brake



WARNING

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.

- Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.




WARNING

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.



- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
- Make sure that only clean, approved brake fluid from a tightly sealed container is used.

Preparatory work

- Check that the brake pads of the front brake are secured. 📖 (p. 95)



Control process

- Move the brake reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in sight glass 1.
 - » If the brake fluid level has fallen below marking A:
 - Add brake fluid for the front brake.   (p. 94)

12.5 Adding brake fluid for the front brake



WARNING

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.

- Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.



WARNING

Health hazard Brake fluid is a harmful substance.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
- Consult a doctor immediately if brake fluid has been ingested.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



WARNING

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
- Make sure that only clean, approved brake fluid from a tightly sealed container is used.



NOTE

Environmental hazard Hazardous substances cause environmental damage.


- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.




Note

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work

- Check that the brake pads of the front brake are secured.  (p. 95)

Filling procedure



- Move the brake reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Take off cover ② with diaphragm ③.
- Add brake fluid up to level A.

Level A (brake fluid level below reservoir rim)	5 mm (0.20 in)
---	-------------------

Brake fluid DOT 4 / DOT 5.1 (p. 162)

- Position cover ② with diaphragm ③. Mount and tighten screws ①.

Immediately clean up any brake fluid that has overflowed or spilled with water.


12.6 Checking that the brake pads of the front brake are secured



WARNING

Danger of accidents Worn brake pads reduce the brake action.

- Make sure that worn brake pads are replaced immediately.



- Check all brake pads on both brake calipers for their lining thickness A.

Minimum pad thickness A	≥ 1 mm (≥ 0.04 in)
-------------------------	----------------------------------

- » If it is less than the minimum thickness:
 - Change the front brake pads. (p. 96)
- Check the brake pads for damage and cracking.
 - » If there is damage or cracking:
 - Change the front brake pads. (p. 96)
- Check that the brake pads are secured.
 - » If the brake pads are not secured correctly:
 - Secure brake pads, replace with new parts if necessary.

12.7 Changing the brake pads of the front brake



WARNING

- Danger of accidents** Incorrect servicing will cause the brake system to fail.
- Ensure that service work and repairs are performed professionally.



WARNING

- Health hazard** Brake fluid is a harmful substance.
- Keep brake fluid out of the reach of children.
 - Wear suitable protective clothing and safety glasses.
 - Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
 - Consult a doctor immediately if brake fluid has been ingested.
 - Rinse the affected area with plenty of water in the event of contact with the skin.
 - Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
 - If brake fluid spills on to your clothing, change the clothing.



WARNING

- Danger of accidents** Brake fluid which is too old or of the wrong type impairs the function of the brake system.
- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
 - Make sure that only clean, approved brake fluid from a tightly sealed container is used.



WARNING

- Danger of accidents** Oil, grease or wax on the brake discs reduces the brake action.
- Always keep the brake discs free of oil, fat and wax.
 - Clean the brake discs with brake cleaner when necessary.



WARNING

- Danger of accidents** Brake pads which have not been approved alter the braking action.
- Only use brake pads approved and recommended by the vehicle manufacturer.




NOTE

- Environmental hazard** Hazardous substances cause environmental damage.
- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.




Note

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.




- Move the brake reservoir mounted on the handlebar to a horizontal position.
- Remove screws **1**.
- Take off cover **2** with diaphragm **3**.




- Remove screws ④.
- Press the brake pads back by slightly tilting the brake caliper laterally on the brake disc. Carefully pull the brake caliper up and off the brake disc.
- Press the brake piston back to its basic position and make sure that no brake fluid overflows from the brake reservoir, extract some brake fluid if necessary.


Do not operate the hand brake lever if the brake caliper has been removed.



- Remove cotter pin ⑤, pull out stud ⑥, and remove the brake pads.
- Clean brake caliper and brake caliper support.



- Check that spring steel clip ⑦ in the brake caliper and brake pad guide plate ⑧ in the brake caliper support are properly seated.



- Insert the new brake pads, mount stud ⑥ and cotter pins ⑤.

Make sure the brake pads and retaining spring are properly seated.


Mount the outer cotter pins from the front to the rear. Mount the inner cotter pins from the rear to the front.

Always replace brake pads in sets.



Tip


To make it easier to mount the stud, push the brake pads upward against the retaining spring.



- Position the brake caliper.
- Mount and tighten screws ④.

Screw, front brake caliper	
M8	25 Nm (18.4 ft-lb.)
	Loctite® 243

- Operate the hand brake lever repeatedly until the brake pads are in contact with the brake disc and a pressure point is reached.



- Add brake fluid to level **A**.

Level A (brake fluid level below reservoir rim)	5 mm (0.20 in)
--	-------------------

Brake fluid DOT 4 / DOT 5.1 (p. 162)

- Position cover **2** with diaphragm **3**.
- Mount and tighten screws **1**.

Immediately clean up any brake fluid that has overflowed or spilled with water.

12.8 Checking the free travel of the brake pedal




WARNING

Danger of accidents The brake system fails in the event of overheating.

If there is no free travel on the brake lever, pressure builds up in the brake system.

- Set the free travel on the brake lever as specified.



- Detach spring **1**.
- Move the brake pedal back and forth between the end stop and the brake pedal cylinder piston actuation and check free travel **A**.

Free travel of brake pedal	3 mm ... 5 mm (0.12 in ... 0.20 in)
----------------------------	--

- » If the free travel does not meet the specifications:
 - Adjust the basic position of the brake pedal. (p. 98)
- Attach spring **1**.

12.9 Adjusting the basic position of the brake pedal




WARNING

Danger of accidents The brake system fails in the event of overheating.

If there is no free travel on the brake lever, pressure builds up in the brake system.

- Set the free travel on the brake lever as specified.



- Detach spring ①.
- Loosen nut ② and unscrew it with push rod ③ until you have maximum free travel.
- To adjust the basic position of the brake pedal to individual requirements, loosen nut ④ and turn screw ⑤ accordingly.



Note

The range of adjustment is limited.

- Turn push rod ③ accordingly until you have free travel A. If necessary, adjust the basic position of the brake pedal.

Free travel of brake pedal	3 mm ... 5 mm (0.12 in ... 0.20 in)
----------------------------	--

- Hold screw ⑤ and tighten nut ④.

Nut, brake pedal stop	
M8	20 Nm (14.8 ft·lb _f)

- Hold push rod ③ and tighten nut ②.

Remaining nuts on chassis	
M6	10 Nm (7.4 ft·lb _f)

- Attach spring ①.



12.10 Checking the brake fluid level for the rear brake



WARNING

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.

- Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.





WARNING

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.



- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
- Make sure that only clean, approved brake fluid from a tightly sealed container is used.

Preparatory work

- Check that the brake pads of the rear brake are secured.
 (p. 101)



Control process

- Stand the vehicle upright.
- Check the brake fluid level in sight glass 1.
 - » If the brake fluid level has fallen below marking A:
 - Add brake fluid for the rear brake.   (p. 100)

12.11 Adding brake fluid for the rear brake



WARNING

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.

- Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.



WARNING

Health hazard Brake fluid is a harmful substance.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
- Consult a doctor immediately if brake fluid has been ingested.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



WARNING

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
- Make sure that only clean, approved brake fluid from a tightly sealed container is used.



NOTE

Environmental hazard Hazardous substances cause environmental damage.



- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.




Note

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work

- Check that the brake pads of the rear brake are secured.  (p. 101)
- Remove the frame protector.  (p. 71)



Filling procedure

- Stand the vehicle upright.
- Remove screw cap ① with diaphragm ② and the O-ring.
- Add brake fluid to mark A.

Brake fluid DOT 4 / DOT 5.1 (p. 162)

- Mount and tighten the screw cap with the membrane and O-ring.

Immediately clean up any brake fluid that has overflowed or spilled using water.

Reworking

- Install the frame protector. (p. 71)




12.12 Checking that the brake pads of the rear brake are secured



WARNING

Danger of accidents Worn brake pads reduce the brake action.

- Make sure that worn brake pads are replaced immediately.



- Check all brake pads on both brake calipers for their lining thickness A.

Minimum pad thickness A	≥ 1 mm (≥ 0.04 in)
-------------------------	-----------------------

- » If it is less than the minimum thickness:
 - Change the rear brake pads. (p. 101)
- Check the brake pads for damage and cracking.
 - » If there is damage or cracking:
 - Change the rear brake pads. (p. 101)
- Check that the brake pads are secured.
 - » If the brake pads are not secured correctly:
 - Secure brake pads, replace with new parts if necessary.



12.13 Changing the rear brake pads



WARNING

Danger of accidents Incorrect servicing will cause the brake system to fail.

- Ensure that service work and repairs are performed professionally.



WARNING

Health hazard Brake fluid is a harmful substance.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
- Consult a doctor immediately if brake fluid has been ingested.
- Rinse the affected area with plenty of water in the event of contact with the skin.

- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



WARNING

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
- Make sure that only clean, approved brake fluid from a tightly sealed container is used.



WARNING

Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.

- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.



WARNING

Danger of accidents Brake pads which have not been approved alter the braking action.

- Only use brake pads approved and recommended by the vehicle manufacturer.



NOTE

Environmental hazard Hazardous substances cause environmental damage.


- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.



Note



Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work


- Remove the frame protector.  (p. 71)

Replacement process


- Stand the vehicle upright.
- Remove screw cap **1** with diaphragm **2** and the O-ring.



- Manually press the brake caliper toward the brake disc to push back the brake piston. Ensure that brake fluid does not flow out of the brake reservoir, and siphon off excess if required.
- Remove cotter pin **3**, pull out stud **4**, and remove the brake pads.
- Clean brake caliper and brake caliper support.



- Check that spring steel clip **5** in the brake caliper and brake pad guide plate **6** in the brake caliper support are properly seated.
- ✓ The arrow on the spring steel clip points in the rotation direction of the brake disc.




- Insert the new brake pads, mount stud **4** and cotter pins **3**.

Always replace brake pads in sets.

Make sure that decoupling plate **7** is mounted on the piston side of the brake pad.

- Actuate the brake disc repeatedly until the brake pads are in contact with the brake disc and a pressure point is achieved.




- Correct the brake fluid level to mark **A**.

Brake fluid DOT 4 / DOT 5.1  (p. 162)

- Mount and tighten screw cap **1** with diaphragm **2** and the O-ring.

Immediately clean up any brake fluid that has overflowed or spilled with water.

Reworking

- Install the frame protector.  (p. 71)


13.1 Removing the front wheel

Preparatory work


- Raise the motorcycle with a lift stand.  (p. 56)

Removal process

- Manually press the brake caliper toward the brake disc to push back the brake pistons.



- Loosen screw **1** by four turns.
- Loosen screws **2**.
- Press on screw **1** to push the wheel spindle out of the fork shoe.
- Remove screw **1**.




WARNING

Danger of accidents Damaged brake discs reduce the braking action.


- Always lay the wheel down in such a way that the brake disc is not damaged.

- Hold front wheel and remove wheel spindle. Take the front wheel out of the fork.

Do not actuate the hand brake lever when the front wheel is removed.



- Remove spacers **3**.


13.2 Installing the front wheel 





WARNING

Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.


- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.




- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the front wheel bearing. 
- Clean and grease radial shaft seal **1** and contact surfaces **A** on the spacers.

Long-life grease  (p. 161)


- Insert spacers.
- Clean and lightly grease the wheel spindle.

Long-life grease  (p. 161)



- Position the front wheel and insert the wheel spindle.
 - ✓ The brake pads are positioned correctly.
- Mount and tighten screw **2**.

Screw, wheel spindle, front	
M20×1.5	35 Nm (25.8 ft·lb _r)


- Operate the hand brake lever several times until the brake pads are in contact with the brake disc.
- Remove the motorcycle from the lift stand.  (p. 56)
- Operate the front brake and compress the fork a few times firmly.
 - ✓ The fork legs straighten.
- Tighten screws **3**.

Screw, fork shoe	
M8	15 Nm (11.1 ft·lb _r)


13.3 Removing the rear wheel 

Preparatory work

- Raise the motorcycle with a lift stand.  (p. 56)



H04989-10



F03727-10

Removal process

- Manually press the brake caliper toward the brake disc to push back the brake pistons.
- Remove nut ①.
- Remove chain tension adjuster ②. Pull out wheel spindle ③ far enough to allow the rear wheel to be pushed forward.
- Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.

Protect the components against damage by covering them.



WARNING

Danger of accidents Damaged brake discs reduce the braking action.

- Always lay the wheel down in such a way that the brake disc is not damaged.

- Hold the rear wheel and remove wheel spindle. Take the rear wheel out of the swingarm.

Do not actuate the brake pedal when the rear wheel is removed.

- Remove spacers ④.


13.4 Installing the rear wheel



WARNING

Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.

- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.



F03728-10


Installation procedure

- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the rear wheel bearing.
- Clean and grease radial shaft seal ① and contact surfaces A on the spacers.


Long-life grease (p. 161)

- Insert spacers.
- Clean and lightly grease the wheel spindle.

Long-life grease (p. 161)




- Position the rear wheel and insert wheel spindle ②.
 - ✓ The brake pads are positioned correctly.
- Attach the chain.



- Position chain tension adjuster ③. Mount nut ④ but do not tighten yet.
- Make sure that chain tension adjusters ③ are fitted correctly on adjusting screws ⑤.
- Check the chain tension. 📖 (p. 83)
- Tighten nut ④.

Nut, wheel spindle, rear	
M22×1.5	80 Nm (59.0 ft·lb _r)



i Note
 The wide range of adjustment of the chain tension adjusters (32 mm) enables different secondary transmissions with the same chain length.
 Chain tension adjusters ③ can be turned by 180°.


- Actuate the brake disc repeatedly until the brake pads are in contact with the brake disc and a pressure point is achieved.

Reworking


- Remove the motorcycle from the lift stand. 📖 (p. 56)

13.5 Checking the tire condition

i Note
 Only mount tires approved and/or recommended by KTM.
 Other tires could have a negative effect on handling characteristics.
 The type, condition, and pressure of the tires all have a major impact on the handling of the motorcycle.
 The tires mounted on the front and rear wheels must have a similar profile.
 Worn tires have a negative effect on handling characteristics, especially on wet surfaces.



- Check the front and rear tires for cuts, embedded objects, and other damage.
 - » If the tires have cuts, run-in objects, or other damage:
 - Change the tires. 🛠️



- Check the tire age.



Note

The tire date of manufacture is usually contained in the tire label and is indicated by the last four digits of the **DOT** number. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.

KTM recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.

- » If the tires are older than five years:
 - Change the tires. 🛠️


13.6 Checking the tire pressure



Note

Low tire pressure leads to abnormal wear and the tire overheating.

Correct tire pressure ensures optimal riding comfort and maximum tire service life.



- Remove the protection cap.
- Check the tire pressure when the tires are cold.

Off-road tire pressure	
front	1.0 bar (14.5 psi)
rear	1.0 bar (14.5 psi)

- » If the tire pressure does not meet specifications:
 - Correct tire pressure.
- Mount the protection cap.

13.7 Checking the spoke tension




WARNING

Danger of accidents Incorrectly tensioned spokes impair the handling characteristic and can result in secondary damage.

If the spokes are too tight, they can break due to being overloaded.

Loose spokes can cause lateral or radial run-out in the wheel and other spokes will loosen as a result.

- Check the spoke tension regularly, especially on a new vehicle.



- Briefly tap each spoke with a screwdriver.

You should hear a high-pitched sound.



Note

The frequency of the sound depends on the spoke length and spoke diameter.


If spokes of the same length and diameter vibrate with a different tone, this is an indication that the spoke tensions differ.

- » If the spoke tension differs:
 - Correct the spoke tension.

- Check the spoke torque.

Spoke nipple, front wheel	
M4,5	6 Nm (4.4 ft·lb _f)
Spoke nipple, rear wheel	
M4,5	6 Nm (4.4 ft·lb _f)
Torque wrench kit (58429094000)	

14.1 Cooling system



Water pump ① in the engine circulates the coolant. The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ②. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

120 °C (248.0 °F)

The coolant is cooled by the air stream. The lower the vehicle speed, the lower the cooling effect. Dirty cooling fins also reduce the cooling effect.

14.2 Checking the frost protection and coolant level



WARNING

Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.

- Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.




WARNING

Health hazard Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.

Condition: The engine is cold



- Stand the motorcycle upright on a level surface.
- Take off the radiator cap.
- Check the frost protection in the coolant.

-45 °C ... -25 °C (-49.0 °F ... -13.0 °F)
--

» If the frost protection in the coolant does not match the specified value:

- Correct the frost protection in the coolant.

- Check the coolant level in the radiator.

Coolant level ① above the radiator fins	10 mm (0.39 in)
---	--------------------

- » If the coolant level does not meet the specifications:
 - Correct the coolant level.

coolant	
Coolant (p. 162) Antifreeze protection to at least: -25 °C (-13.0 °F)	1.2 l (0.32 liq. gal _{US})

- Mount the radiator cap.



14.3 Checking the coolant level



WARNING

Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.

- Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.




WARNING

Health hazard Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.

Condition: The engine is cold



- Stand the motorcycle upright on a level surface.
- Take off the radiator cap.
- Check the coolant level in the radiator.

Coolant level A above the radiator fins	10 mm (0.39 in)
--	--------------------

- » If the coolant level does not meet the specifications:
 - Correct the coolant level.

coolant	
Coolant (p. 162) Antifreeze protection to at least: -25 °C (-13.0 °F)	1.2 l (0.32 liq. gal _{US})

- Mount the radiator cap.



14.4 Draining the coolant



WARNING

Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.

- Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.




WARNING

Health hazard Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.

Condition: The engine is cold



- Stand the motorcycle upright.
- Place an appropriate container under the water pump cover.
- Remove screw **1**. Take off radiator cap **2**.
- Completely drain the coolant.
- Mount screw **1** with the new sealing ring and tighten.

Coolant drain plug	
M6	10 Nm (7.4 ft·lb _f)

14.5 Refilling the coolant




WARNING

Health hazard Coolant is harmful to health.


- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.

Filling procedure

- Make sure that screw **1** is tightened.
- Stand the motorcycle upright.




S05546-10




400243-10

- Pour coolant in up to level **A** above the radiator fins.

10 mm (0.39 in)


coolant	
Coolant  (p. 162) Antifreeze protection to at least: -25 °C (-13.0 °F)	1.2 l (0.32 liq. gal _{US})



W00102-10

- Remove screw **2** and wait until coolant emerges without bubbles.
- Mount and tighten screw **2**.


Cylinder head bleed screw	
M6	8 Nm (5.9 ft·lb _r)




400243-10

- Pour coolant in up to level **A** above the radiator fins.

10 mm (0.39 in)

coolant	
Coolant  (p. 162) Antifreeze protection to at least: -25 °C (-13.0 °F)	1.2 l (0.32 liq. gal _{US})



- Mount radiator cap ③.



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

- Allow the engine to warm up and cool down again.
- Check the transmission and cooling system for leaks.

Reworking

- Check the coolant level. 📖 (p. 111)

14.6 Changing the coolant 🛠️



WARNING

Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.

- Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



WARNING


Health hazard Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.

Condition: The engine is cold


Replacement process

- Stand the motorcycle upright.
- Place an appropriate container under the water pump cover.





- Remove screw ①. Take off radiator cap ②.
- Completely drain the coolant.
- Mount screw ① with the new sealing ring and tighten.

Coolant drain plug	
M6	10 Nm (7.4 ft·lb _f)




- Pour coolant in up to level A above the radiator fins.

10 mm (0.39 in)	
coolant	
Coolant  (p. 162) Antifreeze protection to at least: -25 °C (-13.0 °F)	1.2 l (0.32 liq. gal _{US})





- Remove screw ③ and wait until coolant emerges without bubbles.
- Mount and tighten screw ③.

Cylinder head bleed screw	
M6	8 Nm (5.9 ft·lb _f)




- Pour coolant in up to level A above the radiator fins.

10 mm (0.39 in)	
coolant	
Coolant  (p. 162) Antifreeze protection to at least: -25 °C (-13.0 °F)	1.2 l (0.32 liq. gal _{US})




- Mount radiator cap ②.

 **DANGER**
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.


- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

- Allow the engine to warm up and cool down again.
- Check the transmission and cooling system for leaks.

Reworking

- Check the coolant level.  (p. 111)



15.1 Removing the 12 V battery 



CAUTION




Danger of burns The regulator rectifier gets very hot when the vehicle is operated.
 – Allow the regulator rectifier to cool down before performing any work.



NOTE


Environmental hazard 12-V batteries contain environmentally-hazardous materials.
 – Do not dispose of 12-V batteries as household waste.
 – Dispose of 12-V batteries at a collection point for used batteries.

Preparatory work


- Remove the seat.  (p. 69)
- Remove the fuel tank.   (p. 78)

Removal process


- Disconnect negative cable **1** from the 12 V battery.
- Pull back positive terminal cover **2** and disconnect positive cable **3** from the 12-V battery.



- Remove screw **4**.
- Pull starter relay **5** off the holder and hang to the side.




- Pull up battery holding bracket **6** and remove the 12-V battery to the front.



Pay attention to the wiring harness.

15.2 Installing the 12 V battery


Installation procedure



- Pull up battery holding bracket **1**, insert the 12-V battery into the battery compartment with the terminals facing upwards and secure with battery holding bracket **1**.

Ensure that the cable is routed correctly.

12-V battery (HJTZ5S-FP-C)




- Mount and tighten screw **2**.

Screw, battery holding bracket

M6	6 Nm (4.4 ft·lb _f)
----	-----------------------------------

- Mount starter relay **3** onto the bracket and route the cable.



- Connect positive cable **4** to the 12 V battery.

Screw, battery terminal

M5	2.5 Nm (1.84 ft·lb _f)
----	--------------------------------------


- Connect negative cable **5** to the 12 V battery.

Screw, battery terminal




M5	2.5 Nm (1.84 ft·lb _f)
----	--------------------------------------

Contact disks **A** must be mounted under screws **6** and cable lug **7** with the claws toward the battery terminal.

- Slide positive terminal cover **8** over the positive terminal.



Reworking

- Install the fuel tank.   (p. 80)
- Mount the seat.  (p. 70)

15.3 Charging the 12 V battery



WARNING

Risk of injury 12-V batteries contain harmful substances.

- Keep 12-V batteries out of the reach of children.
- Keep the battery away from sparks or open flames.
- Only charge batteries in well-ventilated rooms.
- Maintain a minimum distance from flammable materials when charging 12-V batteries.

Minimum distance	1 m (3 ft – 3 in)
------------------	----------------------

- Do not charge deeply discharged 12-V batteries if the charge is already below the minimum voltage.

Minimum voltage before starting charging	9 V
--	-----

- Dispose of 12 V batteries correctly if they have less than the minimum voltage.



NOTE

Environmental hazard 12-V batteries contain environmentally-hazardous materials.

- Do not dispose of 12-V batteries as household waste.
- Dispose of 12-V batteries at a collection point for used batteries.



NOTE

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.



Note

Even when there is no load on the 12-V battery, it discharges steadily each day.

The state of charge and the method of charging are very important for the service life of the 12 V battery.






Rapid recharging with a high charging current shortens the service life of the battery.

If the charging current, charging voltage, or charging time is exceeded, the 12-V battery will be destroyed.

If the 12 V battery is left in a discharged state for an extended period, it will become deeply discharged and suffer a loss of capacity, destroying the battery.

The 12 V battery is maintenance-free.

Preparatory work

- Remove the seat.  (p. 69)
- Remove the fuel tank.   (p. 78)
- Remove the 12 V battery.   (p. 117)



Filling procedure

- Do not remove cover ❶.
- Check the battery voltage.
 - » Battery voltage:
 - < 9 V
 - Do not charge the 12 V battery.
 - Replace the 12 V battery and dispose of the old 12 V battery properly.
 - » If the specifications have been met:
 - Battery voltage:
 - ≥ 9 V
 - Charge the 12 V battery.

Read the accompanying instructions.	
Maximum charging voltage	14.4 V
Minimum charging voltage	3.0 A
Maximum charging time	24 h
The charging current, charging voltage, and charging time must not be exceeded.	
Recharge the 12 V battery regularly when the motorcycle is not being used.	3 months
If the 12 V battery is depleted from starting the vehicle repeatedly, the battery must be charged immediately.	
Battery charger and tester (A54029974000)	



Note

This battery charger tests whether the 12 V battery retains its voltage. It is also impossible to overcharge the 12 V battery with this battery charger. The charging time may be longer at low temperatures.

This battery charger is only suitable for lithium iron phosphate batteries.

- Switch off the charger after charging and disconnect from the 12 V battery.

Reworking

- Install the 12 V battery. 🛠️ 📖 (p. 118)
- Install the fuel tank. 🛠️ 📖 (p. 80)
- Mount the seat. 📖 (p. 70)

15.4 Changing the main fuse



WARNING

Fire hazard Incorrect fuses overload the electrical system.





- Use only fuses with the prescribed amperage.
- Do not bypass or repair fuses.



Note



The main fuse protects all electrical power loads of the vehicle. It is located in the starter relay housing under the seat.

Preparatory work

- Press kill button  when the engine is at idle speed until the engine stops.
- Remove the seat.  (p. 69)
- Remove the fuel tank.   (p. 78)

Replacement process

- Pull starter relay **1** off of the bracket.



- Remove protection caps **2**.
- Remove faulty main fuse **3**.



Note

A faulty fuse has a burned-out fuse wire **A**.
A spare fuse **4** is located in the starter relay.

- Insert the main fuse.
- Fuse (58011109110)
- Check that the electrical equipment is functioning properly.





Tip

Insert a new spare fuse so that it is available if needed.

- Mount the protection caps.
- Mount the starter relay onto the holder and route the cable.



Reworking

- Install the fuel tank.  (p. 80)
- Mount the seat.  (p. 70)

15.5 Changing the fuse of the fuel pump



WARNING

Fire hazard Incorrect fuses overload the electrical system.

- Use only fuses with the prescribed amperage.
- Do not bypass or repair fuses.



CAUTION

Danger of burns The regulator rectifier gets very hot when the vehicle is operated.


- Allow the regulator rectifier to cool down before performing any work.



Note

The fuel pump is protected by the fuel pump fuse. This is located under the seat.

Preparatory work

- Remove the seat.  (p. 69)

Replacement process


- Remove protection cap **1**.
- Remove faulty main fuse **2**.




Note

A faulty fuse has a burned-out fuse wire **A**.


- Put in the new fuse for the fuel pump.
- Fuse (58011109105)
- Check that the electrical equipment is functioning properly.
 - Attach the protection cap.



Reworking

- Mount the seat.  (p. 70)

15.6 Diagnostic connector



Diagnostics connector ① is located under the seat.

i **Note**

As soon as the diagnostics tool is connected, the hourmeter starts running.

Before longer diagnostic sessions, unplug the hourmeter behind the number plate.


16.1 Programming the end positions of the exhaust control

i Note

If work has been carried out on the exhaust control, the end positions must be reprogrammed.


Condition: Engine is off

Preparatory work


- Remove the seat.  (p. 69)

Adjustment procedure

- Pull diagnostics connector **1** off the holder.



- Move throttle twist grip **2** to where it is half open and hold in position.




- Plug wake-up connector **A** into diagnostics connector **1**.

i Note


Wake-up connector **A** is in the motorcycle's accessory pack.

- Wait for at least five seconds.
 - ✓ The end positions of the exhaust control are read. The procedure is clearly audible.
 - ✓ The dashboard illumination is activated, the combination switch lights up green.
- Release the fixing from the throttle grip.
 - ✓ The end positions of the exhaust control are programmed.
- Wait until you can no longer hear the exhaust control engine operating.
- Disconnect wake-up connector **A** from diagnostic connector **1**.



- Mount diagnostics connector ① on the holder.

Reworking

- Mount the seat.  (p. 70)



17.1 Changing the mapping

i Note

The desired engine characteristic can be altered using the combination switch. Changing the mapping also affects the response of the exhaust control. The setting most recently selected is activated again when restarting. The mapping can also be changed during the ride.


- Select one of the following alternatives.

Activating STANDARD mapping

- Press button **1**.

Engine speed	< 4,000 rpm (< 66.67 Hz)
--------------	-----------------------------

- ✓ Indicator light **A** lights up.
- ✓ STANDARD: balanced response




Activating ADVANCED mapping


- Press button **2**.

Engine speed	< 4,000 rpm (< 66.67 Hz)
--------------	-----------------------------

- ✓ Indicator light **B** lights up.
- ✓ ADVANCED: direct response



17.2 Checking the play in the throttle cable



- Check the throttle grip for smooth operation.
- Move the handlebar to the straight-ahead position. Turn the throttle twist grip back and forth slightly and determine the play in throttle cable **A**.

Throttle cable play	2 mm ... 3 mm (0.08 in ... 0.12 in)
---------------------	--

- » If the throttle cable play does not meet the specified value:
 - Adjust the throttle cable play. (p. 127)
- Press the cold start button in all the way to the stop.
 - ✓ When the throttle twist grip is turned forward, the cold start button jumps back to the start position.
 - » If the cold start button does not return to its original position:
 - Adjust the throttle cable play. (p. 127)



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

- Start the engine and let it run at idle speed. Move the handlebar back and forth over the entire steering range.

The idle speed must not change.

- » If the idle speed changes:
 - Adjust the throttle cable play. (p. 127)



17.3 Adjusting the throttle cable play



Note

If the correct routing of the throttle cables has already been secured, the fuel tank does not need to be removed.

Preparatory work


- Remove the seat. (p. 69)
- Remove the fuel tank. (p. 78)
- Check the throttle cable routing. (p. 87)

Adjustment procedure

- Move the handlebar to the straight-ahead position.
- Push back boot **1**.
- Loosen nut **2**.
- Screw adjusting screw **3** in as far as possible.
- Loosen nut **4**.
- Press cold start button **6** all the way to the stop.
- Turn adjusting screw **5** so that the cold start button moves to the basic position when the throttle twist grip is turned forward.
- Tighten nut **4**.
- Turn adjusting screw **3** so that there is play in the throttle cable at the throttle twist grip.

Throttle cable play	2 mm ... 3 mm (0.08 in ... 0.12 in)
---------------------	--

- Tighten nut **2**.
- Slide on boot **1**.
- Check the throttle grip for smooth operation.



Reworking


- Check the play in the throttle cable. 📖 (p. 126)
- Install the fuel tank. 🛠️ 📖 (p. 80)
- Mount the seat. 📖 (p. 70)

17.4 Adjusting the idle speed 🛠️



WARNING

- Danger of accidents** The engine may suddenly come to a halt if the idle speed is set too low.
- Set the idle speed to the specified value.



S05514-10

- Run the engine until warm.
- Check whether the cold start button has returned to its basic position.



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

- Adjust the idle speed by turning idle speed adjusting screw ❶ using a suitable rpm gauge.

Make the adjustment in small steps.

Idle speed	1,400 rpm ... 1,500 rpm (23.33 Hz ... 25.00 Hz)
------------	--



Note


Turning counterclockwise lowers the idle speed.
Turning clockwise increases the idle speed.
An incorrect idle speed can have a negative impact on overall engine running.

17.5 Checking the basic position of the gear shift lever





Note

When driving, the gear shift lever must not touch the rider's boot when in the basic position.
When the gear shift lever keeps touching the boot, the transmission will be subject to an excessive load.




- Sit on the vehicle in the riding position and measure the distance **A** between the upper edge of your boot and the shift lever.


Distance between the gear shift lever and upper edge of boot	10 mm ... 20 mm (0.39 in ... 0.79 in)
--	--

- » If the distance does not meet the specifications:
 - Adjust the basic position of the gear shift lever. 
 -  (p. 129)

17.6 Adjusting the basic position of the gear shift lever



- Remove screw **1** with the washer and remove the shift lever **2**.



- Clean tooting **A** of the gear shift lever and shift shaft.
- Mount the gear shift lever on the shift shaft in the desired position and engage the tooting.

The gear shift lever must not come into contact with any other vehicle components during the shift procedure.

i Note
The range of adjustment is limited.

- Mount and tighten screw **1** with the washer.

Screw, shift lever	
M6	14 Nm (10.3 ft-lb.) Loctite® 243

18.1 Changing the fuel screen



DANGER

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
- Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it up immediately.
- Do not overfill the fuel tank.



WARNING

Danger of poisoning Fuel is harmful to health.


- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.




NOTE

Environmental hazard Improper handling of fuel is dangerous to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Remove the cable tie of protection cap ❶.
- Remove the protection cap of the fuel line.



- Clean quick-lock coupling ② thoroughly with compressed air.

Dirt must not enter into the fuel line. Dirt in the fuel line clogs the injector!

- Disconnect the quick-lock coupling.

i Note
Remaining fuel may flow out of the fuel hose.

- Pull fuel screen ③ out of the connecting piece.
- Slide the new fuel screen all the way into the connecting piece.
- Spray silicone spray onto a lint-free cleaning cloth and lightly lubricate the O-ring of the quick-lock coupling.

Silicone spray  (p. 162)

- Join quick-lock couplings.



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.


- Start the engine and check the response.
- Mount the protection cap of the fuel line.
- Mount the cable tie of protection cap ④.



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.




- Start the engine and check the response.

18.2 Checking the gear oil level

Condition: The engine is cold

Preparatory work

- Stand the motorcycle upright on a level surface.



Control process

- Remove gear oil level check screw ①.
- Check the gear oil level.

A small amount of gear oil should run out of the bore.

- » If no gear oil runs out:
 - Add gear oil. (p. 133)

- Mount and tighten the gear oil level check screw.

Screw, gear oil level check

M6

8 Nm
(5.9 ft·lb_r)

18.3 Changing the gear oil



WARNING

Danger of scalding Engine and gear oil heat up when the motorcycle is operated.

- Wear suitable protective clothing and safety gloves.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



NOTE

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.


Condition: Engine is at operating temperature

Preparatory work

- Park the motorcycle on a level surface.
- Position an appropriate container under the engine.

(XC)

- Remove the skid plate. (p. 71)



Replacement process

- Remove gear oil drain plug ① with magnet.
- Remove oil plug ② with O-ring.
- Let the gear oil drain fully.
- Thoroughly clean the gear oil drain plug with a magnet.
- Clean the sealing area on the engine.
- Mount oil drain plug ① with the magnet and a new sealing ring and tighten it.

Transmission drain plug with magnet	
M12×1.5	20 Nm (14.8 ft·lb _f)

- Add gear oil.

gear oil	
Engine oil (15W/50) 📖 (p. 161) Partially synthetic	0.80 l (0.211 liq. gal _{US})

- Mount and tighten oil plug ② with O-ring.



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

- Start the engine and check it for leaks.

Reworking

- Check the gear oil level. 📖 (p. 131)

(XC)

- Install the skid plate. 📖 (p. 72)



18.4 Adding gear oil 🛠️




Note

Too little gear oil or poor-quality oil results in premature wear to the transmission.


Condition: The engine is cold

Preparatory work

- Park the motorcycle on a level surface.



S05549-10




401955-11

Filling procedure

- Remove gear oil level check screw ①.

- Remove filler plug ② with the O-ring.
- Add gear oil until it emerges from the bore of the gear oil level check screw.

Engine oil (15W/50)  (p. 161) Partially synthetic

- Mount and tighten the gear oil level check screw.

Screw, gear oil level check	
M6	8 Nm (5.9 ft·lb _r)

M6	8 Nm (5.9 ft·lb _r)
----	-----------------------------------

- Mount and tighten oil plug ② with O-ring.

Reworking



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

- Start the engine and check it for leaks.

19.1 Cleaning the motorcycle



NOTE

Material damage Components can be damaged or destroyed if a high-pressure cleaner is used incorrectly. The high pressure forces water into the electrical components, socket connectors, clutch cables, and bearings, etc.

Too high a pressure can cause malfunctions and destroy components.

- Do not direct the water jet directly on to electrical components, socket connectors, clutch cables, or bearings.
- Maintain a minimum distance between the nozzle of the high-pressure cleaner and the component.

Minimum distance	60 cm (23.6 in)
------------------	--------------------



NOTE


Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.



Note

To maintain the value and appearance of the motorcycle over a long period, clean it regularly. Avoid direct sunshine when cleaning the motorcycle.



- Seal the exhaust system to prevent water from entering into it.
- Remove the coarse dirt particles with a gentle water jet.
- Spray the heavily soiled parts with a standard commercial motorcycle cleaner and clean using a brush.

Never apply motorcycle cleaner to a dry vehicle; always rinse the vehicle with water first.

Environmentally neutral universal cleaning agent
 (p. 163)



Note

Use warm water containing standard motorcycle cleaner and a soft sponge.

- After rinsing the motorcycle with a gentle spray of water, allow it to dry thoroughly.
- Remove the cover from the exhaust system.



WARNING


Danger of accidents Moisture and dirt impair the brake system.


- Brake carefully several times to dry out and remove dirt from the brake pads and the brake discs.

- After cleaning, ride the vehicle a short distance until the engine warms up.


i Note

The heat produced causes water to evaporate at inaccessible locations in the engine and on the brake system.

- After the motorcycle has cooled off, lubricate all moving parts and pivot points.
- Clean the chain.  (p. 82)
- Treat bare metal (except for brake discs and the exhaust system) with an anticorrosive.

Preserving materials  (p. 163)

- Treat all plastic parts and powder-coated parts with a mild cleaning and care product.

Cleaning agents for plastics, glass, lacquers, metals, windshields and visors  (p. 163)

20.1 Storage


**WARNING**

Danger of poisoning Fuel is harmful to health.

- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.

**Note**

If you plan to garage the motorcycle for a longer period, perform the following steps or have them performed. Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (workshops less busy). In this way, you can avoid long workshop waiting times at the start of the new season.



- When refueling for the last time before taking the motorcycle out of service, add fuel additive.

Fuel additive (p. 160)

- Refuel. (p. 37)

**Tip**

Fill the fuel tank completely as specified, using fuel with the lowest possible ethanol content.

- Clean the motorcycle. (p. 135)
- Change the gear oil. (p. 132)
- Check the frost protection and coolant level. (p. 110)
- Check the tire pressure. (p. 108)
- Remove the 12 V battery. (p. 117)
- Charge the 12 V battery. (p. 119)

Ideal charging and storage temperature of the lithium-ion battery	10 °C ... 20 °C (50.0 °F ... 68.0 °F)
---	--

- Store the vehicle in a dry location that is not subject to large fluctuations in temperature.

**Note**

KTM recommends jacking up the motorcycle.

- Raise the motorcycle with a lift stand. (p. 56)

Cover the motorcycle with a tarp or cover that is permeable to air.


Do not use any non-porous materials, as moisture cannot escape and corrosion can occur.



Note



























Avoid running the engine of a motorcycle in storage for a short time only. Because the engine will not warm up sufficiently, the water vapor produced during combustion will condense, causing engine parts and the exhaust system to rust.

20.2 Preparing for use after storage












- Remove the motorcycle from the lift stand. (p. 56)
- Perform checks and maintenance measures when preparing for use. (p. 33)
- Take a test ride.

21.1 troubleshooting

Cause	Finding	Remedy		
The engine does not turn over when the start button is actuated	Operating error 12 V battery discharged Main fuse blown Starter relay defective Starter motor defective	<ul style="list-style-type: none"> – Carry out the starting procedure.  (p. 33) – Charge the 12 V battery.  – Check the charging voltage.  – Check the open-circuit current.  – Check the alternator.  – Change the main fuse.  (p. 121) – Check the starter relay.  – Check the starter motor.  		
The engine turns but does not start	Operating error Quick-lock coupling not joined Idle speed is not set correctly Fuel supply interrupted Fuel screen in the quick-lock coupling is clogged Spark plug sooty or wet Plug gap of spark plug too wide Fault in ignition system Short-circuit cable in wiring harness frayed, kill switch faulty Connector or ignition coil loose or oxidized Malfunction in the electronic fuel injection	<ul style="list-style-type: none"> – Carry out the starting procedure.  (p. 33) – Join quick-lock couplings. – Adjust the idle speed.   (p. 128) – Check the fuel tank vent. – Change the fuel screen.  – Clean and dry the spark plug and spark plug connector, or change if necessary.  (p. 130) – Adjust plug gap. <table border="1" style="margin-left: 20px; margin-bottom: 10px;"> <tr> <td>Plug gap of spark plug</td> <td>0.80 mm (0.0315 in)</td> </tr> </table> <ul style="list-style-type: none"> – Check the ignition system.  – Check the kill button.  – Clean the connector and treat with contact spray. – Read out the fault memory using the diagnostics tool.  	Plug gap of spark plug	0.80 mm (0.0315 in)
Plug gap of spark plug	0.80 mm (0.0315 in)			
Engine does not speed up	Malfunction in the electronic fuel injection	<ul style="list-style-type: none"> – Read out the fault memory using the diagnostics tool.  		
Engine has too little power	Air filter is very dirty Fuel filter is very dirty Fuel screen is very dirty Malfunction in the electronic fuel injection Fuel supply interrupted Exhaust system leaks, deformed or too little glass fiber filling in the silencer Damaged membrane or reed valve housing	<ul style="list-style-type: none"> – Clean the air filter and air filter box.   (p. 75) – Change the fuel filter.  – Change the fuel screen.  – Read out the fault memory using the diagnostics tool.  (p. 130) – Read out the fault memory using the diagnostics tool.  – Check the fuel tank vent. – Check exhaust system for damage. – Change the glass fiber yarn filling in the main silencer.   (p. 78) – Check the membrane and reed valve housing. 		
The engine dies during the trip	Lack of fuel The engine takes in false air	<ul style="list-style-type: none"> – Refuel.  (p. 37) 		

21 Troubleshooting

Cause	Finding	Remedy		
	Connector or ignition coil loose or oxidized	<ul style="list-style-type: none"> – Check that the intake manifold is firmly seated. – Clean the connector and treat with contact spray. 		
Engine overheats	Too little coolant in cooling system Too little air stream Radiator fins very dirty Foam formation in the cooling system Damaged cylinder head or cylinder head gasket Bent radiator hose Thermostat defective	<ul style="list-style-type: none"> – Check the transmission and cooling system for leaks. – Check the coolant level.  (p. 111) – Switch off the engine when standing. – Clean the radiator fins. – Drain the coolant.   (p. 112) – Refill the coolant.   (p. 112) – Check the cylinder head and cylinder head gasket. – Change the radiator hose.  – Check the thermostat.  <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Opening temperature</td> <td>70 °C (158.0 °F)</td> </tr> </table>	Opening temperature	70 °C (158.0 °F)
Opening temperature	70 °C (158.0 °F)			
Malfunction indicator lamp lights up or flashes	Malfunction in the electronic fuel injection	<ul style="list-style-type: none"> – Check the wiring for damage and the electrical plug-in connections for corrosion and damage. – Read out the fault memory using the diagnostics tool.  		
White smoke development (steam in the exhaust gas)	Damaged cylinder head or cylinder head gasket	<ul style="list-style-type: none"> – Check the cylinder head and cylinder head gasket. 		
Gear oil emerges from the vent hose	Too much gear oil added	<ul style="list-style-type: none"> – Check the gear oil level.  (p. 131) 		
Water in the gear oil	Damaged radial shaft seal ring or water pump	<ul style="list-style-type: none"> – Check the radial shaft seal ring and the water pump. 		

22.1 Flash codes

Blink code for malfunction indicator light	Fi Malfunction indicator light lights up
Error level condition	Tilt sensor – input signal too low Signal voltage: ≤ 0.2 V Signal voltage: 3.7 V ... 4.6 V Tilt sensor – input signal too high Voltage: ≥ 4.8 V
Blink code for malfunction indicator light	Fi 02: Malfunction indicator light flashes 2x short
Error level condition	Crankshaft speed sensor – synchronization faulty Time: ≥ 1 s Crankshaft position sensor - too many impulses Time: ≥ 0.1 s
Blink code for malfunction indicator light	Fi 06: Malfunction indicator light flashes 6x short
Error level condition	Throttle valve position sensor circuit A – input signal too low Voltage: ≤ 0.2 V Time: ≥ 0.08 s Throttle valve position sensor circuit A – input signal too high Voltage: ≥ 4.7 V Time: ≥ 0.08 s
Blink code for malfunction indicator light	Fi 09: Malfunction indicator light flashes 9x short
Error level condition	Crankcase pressure sensor - short circuit to ground Voltage: ≤ 0.4 V Time: ≥ 0.1 s Crankcase pressure sensor - open/short circuit to plus Voltage: ≥ 4.6 V Time: ≥ 0.1 s Ambient air pressure sensor - short circuit to ground Ambient air pressure sensor voltage: ≤ 0.4 V Time: ≥ 1 s Ambient air pressure sensor voltage: ≥ 4.6 V Time: ≥ 0.1 s
Blink code for malfunction indicator light	Fi 12: Malfunction indicator light flashes 1x long, 2x short
Error level condition	Coolant temperature sensor – input signal too low Voltage: ≤ 0.1 V

	<p>Time: ≥ 3 s Coolant temperature sensor – input signal too high Voltage: ≥ 4.8 V Time: ≥ 3 s</p>
Blink code for malfunction indicator light	<p>Fi 13: Malfunction indicator light flashes 1x long, 3x short</p>
Error level condition	<p>Intake air temperature sensor – input signal too low Voltage: ≤ 0.2 V Time: ≥ 3 s Intake air temperature sensor – input signal too high Voltage: ≥ 4.8 V Time: ≥ 3 s</p>
Blink code for malfunction indicator light	<p>Fi 14: Malfunction indicator light flashes 1x long, 4x short</p>
Error level condition	<p>Crankcase pressure sensor – difference too high between sensor and engine control unit</p>
Blink code for malfunction indicator light	<p>Fi 21: Malfunction indicator light flashes 2x long, 1x short</p>
Error level condition	<p>Battery voltage - input voltage too low Engine control unit power supply: ≤ 9.9 V Time: ≥ 1 s Battery voltage – input voltage too high Engine control unit power supply: ≥ 16.10 V Time: ≥ 1 s</p>
Blink code for malfunction indicator light	<p>Fi 33: Malfunction indicator lamp flashes 3x long, 3x short</p>
Error level condition	<p>Injection valve 1, cylinder 1 – input signal too low Time: ≥ 1 s Injection valve 1, cylinder 1 – input signal too high Time: ≥ 1 s</p>
Blink code for malfunction indicator light	<p>Fi 34: Malfunction indicator lamp flashes 3x long, 4x short</p>
Error level condition	<p>Injection valve 2, cylinder 1 – input signal too low Time: ≥ 1 s Injection valve 2, cylinder 1 – input signal too high Time: ≥ 1 s</p>



Blink code for malfunction indicator light	Fi 37: Malfunction indicator light flashes 3x long, 7x short
Error level condition	Ignition coil – circuit fault Time: ≥ 2.0 s
Blink code for malfunction indicator light	Fi 41: Malfunction indicator light flashes 4x long, 1x short
Error level condition	Fuel pump - short circuit to ground/open circuit The engine is switched off: ≥ 0.4 s Fuel pump – short circuit to plus The engine is switched off: ≥ 0.4 s
Blink code for malfunction indicator light	Fi 50: Malfunction indicator light flashes 5x long
Error level condition	Exhaust control actuator – no signal Exhaust control actuator – temperature too high Exhaust control actuator – incorrect setting Exhaust control actuator – setpoint value signal faulty Exhaust control actuator – input signal too low Exhaust control actuator – input signal too high Exhaust control actuator – mechanical error in the lower position Exhaust control actuator – mechanical error in the upper position Exhaust control actuator – mechanical error
Blink code for malfunction indicator light	Fi 53: Malfunction indicator light flashes 5x long, 3x short
Error level condition	Sensor voltage 1 – open circuit/short circuit to ground Sensor voltage 1 – short circuit to plus
Blink code for malfunction indicator light	Fi 54: Malfunction indicator light flashes 5x long, 4x short
Error level condition	Sensor voltage 2 – open circuit/short circuit to ground Sensor voltage 2 – short circuit to plus

23.1 Engine

23.1.1 Technical data - engine

Design	Single-cylinder 2-stroke engine, liquid-cooled, with diaphragm intake and exhaust control
Displacement	124.8 cm ³ (7.616 in ³)
Stroke	54.5 mm (2.146 in)
Bore	54 mm (2.13 in)
Idle speed	1,400 rpm ... 1,500 rpm (23.33 Hz ... 25.00 Hz)
Exhaust control - beginning of adjustment	7,200 rpm (120.00 Hz)
Crankshaft bearing	1 grooved ball bearing, 1 roller bearing
Big (bottom) end bearing	Needle bearing
Wrist pin bearing	Needle bearing
Piston	Aluminum
Piston rings	2 half keystone rings
Engine lubrication	Mixture lubrication
X-dimension (upper edge of piston to upper edge of cylinder)	0 mm ... 0.10 mm (0 in ... 0.0039 in)
Z dimension (height of control flap)	36.5 mm ... 36.6 mm (1.437 in ... 1.441 in)
Primary transmission	23:73
Clutch	Multi-disc wet clutch / hydraulically activated
Transmission	6 speed transmission, claw shift
Gear ratios	
1st gear	14:32
2nd Gear	15:30
3rd Gear	17:28
4th Gear	19:27
5th Gear	19:23
6th Gear	22:24
Gear ratios	
Ignition system	Electronic ignition
Spark plug	NGK BR10 ECMVX
Plug gap of spark plug	0.80 mm (0.0315 in)
Cooling	Liquid cooling, permanent circulation of coolant by water pump
Starting aid	Electric starter

23.1.1.1 Capacities - engine

gear oil	
Engine oil (15W/50)  (p. 161) Partially synthetic	0.80 l (0.211 liq. gal _{US})
coolant	
Coolant  (p. 162) Antifreeze protection to at least: -25 °C (-13.0 °F)	1.2 l (0.32 liq. gal _{US})

23.2 Chassis

23.2.1 Technical data - chassis

Frame	Central tube frame made of chrome molybdenum steel tubing
Fork (All SX models)	WP XACT AER
Fork (XC)	WP XPLOR CC
Suspension travel: (All SX models)	
front	310 mm (12.20 in)
rear	300 mm (11.81 in)
Suspension travel: (XC)	
front	300 mm (11.81 in)
rear	300 mm (11.81 in)
Triple clamp offset	22 mm (0.87 in)
Shock absorber (All SX models)	WP XACT LDS
Shock absorber (XC)	WP XACT LDS
Brake system	Disc brakes, floating brake calipers
Brake discs - diameter	
front	260 mm (10.24 in)
rear	220 mm (8.66 in)
Brake disc wear limit	
front	2.5 mm (0.098 in)
rear	3.5 mm (0.138 in)
Off-road tire pressure	
front	1.0 bar (14.5 psi)
rear	1.0 bar (14.5 psi)

23 Technical specifications


Final drive	
(All SX models)	13:50
(XC)	13:51
Chain	5/8 x 1/4"
Rear sprockets available	<ul style="list-style-type: none"> • 50 • 51
Steering head angle	63.9° (1.115 rad)
Wheelbase	1,493 ±10 mm (58.78 ±0.39 in)
Seat Height unloaded	958 mm (37.72 in)
Ground clearance unloaded	
(All SX models)	359 mm (14.13 in)
(XC)	359 mm (14.13 in)
Weight without fuel approx.	
(All SX models)	92 kg (202.8 lb)
(XC)	95.5 kg (210.54 lb)
Maximum permissible front axle load	145 kg (319.7 lb)
Maximum permissible rear axle load	190 kg (418.9 lb)
Maximum permissible total weight	335 kg (738.5 lb)


23.2.2 Technical data - tires

Validity	Tire front	Rear tire
(All SX models)	80/100 - 21 TT Dunlop MX34 F	100/90 - 19 TT Dunlop MX34
(XC)	80/100 - 21 TT Dunlop Geomax AT82F	110/100 - 18 M+S TT Dunlop Geomax AT82

The tires specified represent one of the possible series production tires. For alternative manufacturers, if any, contact an authorized dealer or qualified tire dealership. If local road approval regulations apply, these and the respective technical specifications must be observed.

23.2.3 Capacities - vehicle

Total fuel tank capacity, approx.	
(All SX models)	
Super unleaded (98 octane) mixed with 2-stroke engine oil  (p. 160) Mixture ratio: 1:40	7.2 l (1.90 liq. gal _{US})

Total fuel tank capacity, approx.	
(XC)	
Super unleaded (98 octane) mixed with 2-stroke engine oil  (p. 160) Mixture ratio: 1:40	8.5 l (2.25 liq. gal _{US})

23.3 Electrics

23.3.1 Battery

12-V battery	HJTZ5S-FP-C	Lithium-ion battery Battery voltage: 12 V Nominal capacity: 2.0 Ah Maintenance-free
--------------	-------------	--

23.3.2 Fuses




Fuse	58011109105	5 A
Fuse	58011109110	10 A

23.4 Fork

23.4.1 Technical data - fork (All SX models)

Fork part number	A460C101Y406000
Fork	WP XACT AER
Compression damping	
Comfort	17 clicks
Standard	12 clicks
Sport	7 clicks
Rebound damping	
Comfort	17 clicks
Standard	12 clicks
Sport	7 clicks
Air pressure	
Weight of rider: 65 kg ... 75 kg (143.3 lb ... 165.3 lb)	8.4 bar (121.8 psi)
Weight of rider: 75 kg ... 85 kg (165.3 lb ... 187.4 lb)	8.6 bar (124.7 psi)
Weight of rider: 85 kg ... 95 kg (187.4 lb ... 209.4 lb)	8.8 bar (127.6 psi)
Fork length	950 mm (37.40 in)



23.4.2 Capacities - fork (All SX models)

Oil capacity, left outer assembly	
Fork oil (48601166S1) (SAE 4)  (p. 161)	240 ml (8.12 fl. oz _{US})
Oil capacity, right outer assembly	
Fork oil (48601166S1) (SAE 4)  (p. 161)	240 ml (8.12 fl. oz _{US})
Oil capacity, right cartridge	
Fork oil (48601166S1) (SAE 4)  (p. 161)	380 ml (12.85 fl. oz _{US})

23.4.3 Technical data - fork (XC)

Fork part number	A590C171Y402000
Fork	WP XPLOR CC
Compression damping	
Comfort	17 clicks
Standard	12 clicks
Sport	7 clicks
Rebound damping	
Comfort	23 clicks
Standard	18 clicks
Sport	13 clicks
Fork length	940 mm (37.01 in)
Spring rate	
Rider's weight: 65 kg ... 75 kg (143.3 lb ... 165.3 lb)	40 N/mm (228.4 lb _f /in)
Rider's weight: 75 kg ... 85 kg (165.3 lb ... 187.4 lb)	42 N/mm (239.8 lb _f /in)
Rider's weight: 85 kg ... 95 kg (187.4 lb ... 209.4 lb)	44 N/mm (251.2 lb _f /in)

23.4.4 Capacities - fork (XC)

Oil capacity, outer assembly	
Fork oil (48601166S1) (SAE 4)  (p. 161)	390 ml (13.19 fl. oz _{US})
Oil capacity, cartridge	
Fork oil (48601166S1) (SAE 4)  (p. 161)	175 ml (5.92 fl. oz _{US})

23.5 Shock absorber

23.5.1 Technical data - shock absorber (All SX models)

Shock absorber part number	A460C401Y408000
Shock absorber	WP XACT LDS
Low-speed compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
High-speed compression damping	
Comfort	2 turns (720°)
Standard	1.5 turns (540°)
Sport	1 turn (360°)
Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Preload	8 mm (0.31 in)
Spring rate	
Weight of rider: 65 kg ... 75 kg (143.3 lb ... 165.3 lb)	36 N/mm (205.6 lb _f /in)
Weight of rider: 75 kg ... 85 kg (165.3 lb ... 187.4 lb)	39 N/mm (222.7 lb _f /in)
Weight of rider: 85 kg ... 95 kg (187.4 lb ... 209.4 lb)	42 N/mm (239.8 lb _f /in)
Spring length	240 mm (9.45 in)
Gas assisted	10 bar (145 psi)
Static sag	35 mm (1.38 in)
Rider sag	105 mm (4.13 in)
Installation position	456.3 mm (17.965 in)

23.5.2 Technical data - shock absorber (XC)

Shock absorber part number	A460C471Y408000
Shock absorber	WP XACT LDS
Low-speed compression damping	

23 Technical specifications

Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
High-speed compression damping	
Comfort	2 turns (720°)
Standard	1.5 turns (540°)
Sport	1 turn (360°)
Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Preload	8 mm (0.31 in)
Spring rate	
Weight of rider: 65 kg ... 75 kg (143.3 lb ... 165.3 lb)	36 N/mm (205.6 lb _f /in)
Weight of rider: 75 kg ... 85 kg (165.3 lb ... 187.4 lb)	39 N/mm (222.7 lb _f /in)
Weight of rider: 85 kg ... 95 kg (187.4 lb ... 209.4 lb)	42 N/mm (239.8 lb _f /in)
Spring length	240 mm (9.45 in)
Gas assisted	10 bar (145 psi)
Static sag	35 mm (1.38 in)
Rider sag	105 mm (4.13 in)
Installation position	456.3 mm (17.965 in)

23.6 Tightening torque

23.6.1 engine tightening torques

Screw, outer reed petals	EJOT DELTA PT® – 3×6	1 Nm (0.7 ft·lb _f)
Screw, reed valve support plate	EJOT DELTA PT® – M3×12	1 Nm (0.7 ft·lb _f)
Detent arm screw	M5	6 Nm (4.4 ft·lb _f) Loctite® 243
Control lever locknut adjusting screw	M5	6 Nm (4.4 ft·lb _f) Loctite® 243

Screw, control lever, exhaust control	M5	8 Nm (5.9 ft·lb _f) Loctite® 243
Screw, power valve retaining bracket	M5	6 Nm (4.4 ft·lb _f) Loctite® 2701
Screw, shift drum bearing clamping plate	M5	6 Nm (4.4 ft·lb _f) Loctite® 243
Screw, main shaft bearing clamping plate	M5	6 Nm (4.4 ft·lb _f) Loctite® 243
Screw, exhaust control cover	M5	6 Nm (4.4 ft·lb _f)
Screw, clutch spring retainer	M5	6 Nm (4.4 ft·lb _f)
Stator screw	M5	6 Nm (4.4 ft·lb _f) Loctite® 243
Screw, control flap lever, exhaust control	M5	8 Nm (5.9 ft·lb _f) Loctite® 243
Screw, control gate, exhaust control	M5	8 Nm (5.9 ft·lb _f) Loctite® 243
Screw, actuator cover	M5	6 Nm (4.4 ft·lb _f)
Screw, actuator exhaust control	M5	6 Nm (4.4 ft·lb _f) Loctite® 243
Screw, crankshaft position sensor	M5	6 Nm (4.4 ft·lb _f) Loctite® 243
Coolant drain plug	M6	10 Nm (7.4 ft·lb _f)
Screw, water pump cover	M6×50	10 Nm (7.4 ft·lb _f)
Screw, water pump cover	M6×60	10 Nm (7.4 ft·lb _f)
Screw, intake manifold / diaphragm housing	M6	6 Nm (4.4 ft·lb _f)
Exhaust flange screw	M6	10 Nm (7.4 ft·lb _f)
Screw, gear oil level check	M6	8 Nm (5.9 ft·lb _f)
Shift star screw	M6	10 Nm (7.4 ft·lb _f) Loctite® 243

23 Technical specifications

Screw, shift lever	M6	14 Nm (10.3 ft·lb _f) Loctite® 243
Bleed screw, water pump cover	M6	8 Nm (5.9 ft·lb _f)
Screw, ignition cover	M6	8 Nm (5.9 ft·lb _f)
Vacuum fitting, housing vent	M6	2 Nm (1.5 ft·lb _f) Loctite® 243
Screw, water pump impeller	M6	6 Nm (4.4 ft·lb _f) Loctite® 243
Screw, inner clutch cover	M6	10 Nm (7.4 ft·lb _f)
Screw, outer clutch cover	M6	8 Nm (5.9 ft·lb _f)
Screw, starter motor	M6	8 Nm (5.9 ft·lb _f)
Screw, starter motor cover	M6	8 Nm (5.9 ft·lb _f)
Screw, engine case	M6×50	10 Nm (7.4 ft·lb _f)
Screw, engine case	M6×60	10 Nm (7.4 ft·lb _f)
Screw, cylinder head	M7	18 Nm (13.3 ft·lb _f)
Screw, cylinder base	M8	10 Nm (7.4 ft·lb _f)
Nut, cylinder base	M8	23 Nm (17.0 ft·lb _f)
Front sprocket screw	M10	60 Nm (44.3 ft·lb _f) Loctite® 2701
Transmission drain plug with magnet	M12×1.5	20 Nm (14.8 ft·lb _f)
Nut, rotor	M12×1	50 Nm (36.9 ft·lb _f)
Spark plug	M14×1.25	25 Nm (18.4 ft·lb _f)
Nut, inner clutch hub	M18×1.5	120 Nm (88.5 ft·lb _f)
Nut, primary gear wheel	M18LH×1.5	120 Nm (88.5 ft·lb _f) Loctite® 243
Screw, inner reed petals	EJOT DELTA PT® – 3,5×25	1 Nm (0.7 ft·lb _f)

Screw, pressure sensor	EJOT PT® – K60×20 – AL	2 Nm (1.5 ft·lb _f)
------------------------	-------------------------------	-----------------------------------

23.6.2 Chassis tightening torques

Radiator hose clamp		2.4 Nm (1.77 ft·lb _f)
Combination switch screw	EJOT PT®	2 Nm (1.5 ft·lb _f)
Screw, intake air temperature sensor	EJOT PT®	0.7 Nm (0.52 ft·lb _f)
Hose clip, inlet sleeve to throttle valve body		2.8 Nm (2.07 ft·lb _f)
Screw, air filter box, on subframe	EJOT PT®	5 Nm (3.7 ft·lb _f)
Screw, fuel pump on fuel tank	EJOT PT®	2.5 Nm (1.84 ft·lb _f)
Screw, seat installation	EJOT PT®	2.5 Nm (1.84 ft·lb _f)
Screw, start button/kill switch	EJOT PT®	2 Nm (1.5 ft·lb _f)
Screw, fixed grip	M4	5 Nm (3.7 ft·lb _f) Loctite® 243
Screw, hose clamp, throttle body	M4	5 Nm (3.7 ft·lb _f)
Air boot screw connection to throttle body	M4	5 Nm (3.7 ft·lb _f)
Screw, hose clamp, throttle body	M4	2.8 Nm (2.07 ft·lb _f)
Remaining screws on chassis	M5	5 Nm (3.7 ft·lb _f)
Remaining nuts on chassis	M5	5 Nm (3.7 ft·lb _f)
Screw, battery terminal	M5	2.5 Nm (1.84 ft·lb _f)
Screw, shock absorber adjusting ring	M5	5 Nm (3.7 ft·lb _f)
Screws on muffler	M5	7 Nm (5.2 ft·lb _f)
Screw, frame protector	M5	3 Nm (2.2 ft·lb _f)
Screw, throttle body cover	M5	2.6 Nm (1.92 ft·lb _f)
Screw, brake pedal stub	M5	6 Nm (4.4 ft·lb _f) Loctite® 243

23 Technical specifications

Nut, cable on starter motor	M6	4 Nm (3.0 ft·lb _f)
Nut, throttle cable on throttle body	M6	3 Nm (2.2 ft·lb _f)
Remaining nuts on chassis	M6	10 Nm (7.4 ft·lb _f)
Remaining screws on chassis	M6	10 Nm (7.4 ft·lb _f)
Screw, rear brake disc	M6	14 Nm (10.3 ft·lb _f) Loctite® 243
Screw, front brake disc	M6	14 Nm (10.3 ft·lb _f) Loctite® 243
Screw, throttle twist grip	M6	5 Nm (3.7 ft·lb _f)
Screw, chain slider guard	M6	6 Nm (4.4 ft·lb _f) Loctite® 243
Screw, ball joint of push rod on brake cylinder	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, fuel tank spoiler on radiator	M6	6 Nm (4.4 ft·lb _f)
Screw, clutch lever	M6	5 Nm (3.7 ft·lb _f)
Front brake lever screw	M6	5 Nm (3.7 ft·lb _f)
Screw, chain guide on swingarm, rear	M6×45	10 Nm (7.4 ft·lb _f)
Screw, chain guide on swingarm, front	M6×16	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, fender	M6	12 Nm (8.9 ft·lb _f)
Screw, connector support incl. dashboard	M6	5 Nm (3.7 ft·lb _f)
Brake line guide screw on swingarm	M6	4.5 Nm (3.32 ft·lb _f) Loctite® 243
Screw, seat installation	M6	8 Nm (5.9 ft·lb _f)
Screw, battery holding bracket	M6	6 Nm (4.4 ft·lb _f)
Screw, ground wire on frame	M6	10 Nm (7.4 ft·lb _f)
Screw, starter cable to starter relay	M6	6 Nm (4.4 ft·lb _f)

Screw, battery cable to starter relay	M6	6 Nm (4.4 ft·lb _f)
Nut, starter cable on starter motor	M6	4 Nm (3.0 ft·lb _f)
Screw, front brake disc	M6	14 Nm (10.3 ft·lb _f) Loctite® 243
Screw, hand lever	M6	5 Nm (3.7 ft·lb _f)
Screw, chain guide on swingarm, rear	M6×16	10 Nm (7.4 ft·lb _f) Loctite® 243
Nut, rear sprocket screw	M8	35 Nm (25.8 ft·lb _f) Loctite® 2701
Nut, rim lock	M8	12 Nm (8.9 ft·lb _f)
Remaining nuts on chassis	M8	25 Nm (18.4 ft·lb _f)
Remaining screws on chassis	M8	25 Nm (18.4 ft·lb _f)
Screw, front brake caliper	M8	25 Nm (18.4 ft·lb _f) Loctite® 243
Screw, top triple clamp	M8	17 Nm (12.5 ft·lb _f)
Screw, bottom triple clamp	M8	12 Nm (8.9 ft·lb _f)
Screw, fork shoe	M8	15 Nm (11.1 ft·lb _f)
Screw, upper steering stem	M8	20 Nm (14.8 ft·lb _f) Loctite® 243
Screw, chain slider	M8	15 Nm (11.1 ft·lb _f)
Screw, manifold	M8	15 Nm (11.1 ft·lb _f)
Screw, handlebar clamp on handlebar mount	M8	20 Nm (14.8 ft·lb _f)
Screw, subframe, top	M8×15	35 Nm (25.8 ft·lb _f) Loctite® 243
Screw, subframe, bottom	M8×18	30 Nm (22.1 ft·lb _f) Loctite® 2701
(XC) Screw, side stand attachment	M8	33 Nm (24.3 ft·lb _f) Loctite® 2701

23 Technical specifications

Screw, front sprocket cover on swingarm	M8	15 Nm (11.1 ft·lb _f)
Nut, brake pedal stop	M8	20 Nm (14.8 ft·lb _f)
Screw, manifold	M8	15 Nm (11.1 ft·lb _f)
Screw of chain pinion cover on frame	M8	15 Nm (11.1 ft·lb _f)
Screw, front sprocket cover	M8	20 Nm (14.8 ft·lb _f)
Screw, manifold on engine brace	M8	15 Nm (11.1 ft·lb _f)
Screw, subframe, bottom	M8	30 Nm (22.1 ft·lb _f) Loctite® 2701
Screw, subframe, bottom	M8	35 Nm (25.8 ft·lb _f) Loctite® 2701
Engine bracket screw	M10	60 Nm (44.3 ft·lb _f)
Remaining nuts on chassis	M10	45 Nm (33.2 ft·lb _f)
Remaining screws on chassis	M10	45 Nm (33.2 ft·lb _f)
Top shock absorber screw	M10	60 Nm (44.3 ft·lb _f) Loctite® 2701
Bottom shock absorber screw	M10	60 Nm (44.3 ft·lb _f) Loctite® 2701
Screw, handlebar mount on triple clamp	M10	40 Nm (29.5 ft·lb _f) Loctite® 243
Coolant temperature sensor	M10×1.25	10 Nm (7.4 ft·lb _f)
Screw, brake pedal on frame	M10	45 Nm (33.2 ft·lb _f)
Screw, sprocket	M10	60 Nm (44.3 ft·lb _f) Loctite® 2701
Nut, frame on linkage lever	M14×1.5	60 Nm (44.3 ft·lb _f)
Nut, angle lever to link fork	M14×1.5	60 Nm (44.3 ft·lb _f)
Nut, swingarm pivot	M16×1.5	100 Nm (73.8 ft·lb _f)
Nut, linkage lever on angle lever	M16×1.5	80 Nm (59.0 ft·lb _f)

Screw, wheel spindle, front	M20×1.5	35 Nm (25.8 ft·lb _f)
Screw, top steering head	M20×1.5	12 Nm (8.9 ft·lb _f)
Nut, wheel spindle, rear	M22×1.5	80 Nm (59.0 ft·lb _f)
Screw-in nozzle, cooling system	M24×1.5	7.5 Nm (5.53 ft·lb _f)
Screw, t-junction and thermostat	M24	7.5 Nm (5.53 ft·lb _f)
Spoke nipple, rear wheel	M4,5	6 Nm (4.4 ft·lb _f)
Spoke nipple, front wheel	M4,5	6 Nm (4.4 ft·lb _f)

A Technical terms

OBD	On-board diagnosis	Vehicle system, which monitors the specified parameters of the vehicle electronics
-----	--------------------	--

B Fuels

Super unleaded (98 octane) mixed with 2-stroke engine oil

Standards

→ DIN EN 228

→ JASO FD

Properties

- Mixture ratio 1:40

Mixture ratio

- Super unleaded 10 l
- 2-stroke engine oil (2.6 liq. gal_{US})
250 ml
(8.45 fl. oz_{US})

Fuel additive

Recommended supplier

MOTOREX®

- FUEL STABILIZER

C Operating supplies

Off-road chain spray

Recommended supplier

MOTOREX®

- CHAINLUBE OFF ROAD

Fork oil

Order details

- 48601166S1

Standards

- SAE 4 → SAE

Universal oil spray

Recommended supplier

MOTOREX®

- JOKER 440 SYNTHETIC

Long-life grease

Recommended supplier

MOTOREX®

- Bike Grease 2000

Engine oil

Recommended supplier

MOTOREX®

- TOP SPEED 4T

Standards

→ JASO T903 MA2

- 15W/50 → SAE

Properties

- Partially synthetic

2-stroke engine oil

Recommended supplier

MOTOREX®

- CROSS POWER 2T

Standards

→ JASO FD

Properties

- fully synthetic

High viscosity grease

Recommended supplier

SKF®

- LGHB 2

Silicone spray

Recommended supplier

MOTOREX®

- SILICONE SPRAY

Oil for foam air filter

Recommended supplier

MOTOREX®

- RACING BIO AIR FILTER OIL

Brake fluid DOT 4 / DOT 5.1

Recommended supplier

Castrol

- REACT PERFORMANCE DOT 4

MOTOREX®

- BRAKE FLUID DOT 5.1

Standards

→ DOT

Coolant

Recommended supplier

MOTOREX®

- COOLANT M3.0

Properties

- Antifreeze protection to at least -25 °C
(-13.0 °F)

D Cleaning agents**Chain cleaner**

Recommended supplier

MOTOREX®

- CHAIN CLEAN

Preserving materials

Recommended supplier

MOTOREX®

- MOTO PROTECT

Air filter cleaning agent

Recommended supplier

MOTOREX®

- RACING BIO AIR FILTER CLEANER

Cleaning agents for plastics, glass, lacquers, metals, windshields and visors

Recommended supplier

MOTOREX®

- QUICK CLEANER

Environmentally neutral universal cleaning agent

Recommended supplier

MOTOREX®


- MOTO CLEAN UNIVERSAL

E Icons

E.1 Symbol colors



E.1.1 Yellow and orange symbols

Yellow and orange symbols indicate a malfunction status that requires prompt intervention. Active driving aids are also represented by yellow or orange symbols.

	Failure indicator lamp lights up or flashes red
---	---

E.1.2 Green and white symbols

Green and white symbols convey information.

	Indicator light A lights up white
	Indicator light B lights up green

1**12 V battery**

charging	119
installation	118
removing	117
starting power	29

A**Accessories 14****Air filter**

cleaning	75
installing	76
removing	74

Air filter box

cleaning	75
--------------------	----

Air filter box cover

installing	73
preparing for securing	76
removing	72

Air suspension XACT 49**Auxiliary substances 14****B****Brake discs**

checking	92
--------------------	----

Brake fluid

adding front brake	94
adding to rear brake	100

Brake fluid level

checking on front brake	93
checking on rear brake	99

Brake lining retainers

checking on front brake	95
checking on rear brake	101

Brake pad

checking on front brake	95
-----------------------------------	----

Brake pads

changing on the rear brake	101
checking on rear brake	101
of the front brake, changing	96

Brake pedal 26

adjusting the basic position	98
checking the free travel	98

C**Chain**

checking	84
cleaning	82

Chain guide

checking	84
--------------------	----

Chain tension

adjusting	83
checking	83

Checking basic chassis setting with

rider's weight	42
--------------------------	----

Clothing 11**Clutch**

changing fluid	90
checking/correcting fluid level	89

Clutch lever 19

adjusting the basic position	89
--	----

Cold start button 24**Compression damping**

adjusting the fork	51
------------------------------	----

Coolant

changing	114
draining	112
refilling	112

Coolant level

checking	110...111
--------------------	-----------

Cooling system 110**Customer service 14****D****Dashboard 23****Defined use 12****Diagnostic connector 123****Difficult operating conditions 29**

dry sand	30
high temperatures	31
low temperature	32
muddy surfaces	31
slow speed	31
snow	32
wet sand	30
wet surfaces	31

E**Electric starter 21****Engine**

running in	28
----------------------	----

Engine number 17**Environment 12****Exhaust control**

end positions, programming	124
--------------------------------------	-----

F**Figures 14****Fork**

adjusting the air pressure	50
--------------------------------------	----

checking basic setting	49	Hand grip	
Fork legs		checking	88
bleeding	57	Handbrake lever	
cleaning the dust boots	57	adjusting the basic position	92
installing	59	checking the free travel	92
removing	59	Handlebar position	53
Fork protector		adjusting	53
installation	58	High-speed compression damping	
removing	58	adjusting the shock absorber	43
Frame		I	
checking	87	Idle speed	
Frame protector		adjusting	128
installation	71	Idle speed adjustment screw	25
removing	71	Implied warranty	14
Front fender		Improper use	13
installation	66	Intended use	12
removing	66	K	
Front sprocket		Kill button	20
checking	84	L	
Front wheel		Lower triple clamp	
installing	105	installation	61
removing	104	removing	60
Frost protection		Low-speed compression damping	
checking	110	adjusting the shock absorber	42
Fuel screen		M	
changing	130	Main fuse	
Fuel tank		changing	121
installation	80	Manufacturer's warranty	14
removing	78	Mapping	
Fuel tank cap		changing	126
closing	24	Motorcycle	
opening	23	cleaning	135
Fuse		raising with lift stand	56
changing the main fuse	121	removing from lift stand	56
of the fuel pump, changing	122	Muffler	
G		glass fiber filling, changing	78
Gear oil		installation	77
adding	133	removing	77
changing	132	N	
Gear oil level		Number plate	
checking	131	installation	65
Gear shift lever	25	removing	65
adjusting the basic position	129	O	
checking the basic position	128	Owner's manual	12
H			
Hand brake lever	19		

P	
Plug-in stand	26
Preparing for use	
after storage	138
checks and maintenance measures when preparing for use	33
notes on preparing for first use	27
Protective clothing	11
R	
Rear sprocket	
checking	84
Rear wheel	
installation	106
removing	105
Rebound damping	
adjusting the fork	52
adjusting the shock absorber	44
Refueling	
fuel	37
Resources	
Rider sag	
adjusting	48
S	
Safe use	
Seat	
mounting	70
removing	69
Service	
Shock absorber	
adjusting the spring preload	47
checking static sag	46
checking the rider sag	46
compression damping, general	42
installation	68
removing	67
Side stand	
Skid plate	
installation	72
removing	71
Spare parts	
Spoke tension	
checking	109
Starting	
Starting performance of lithium-ion batteries at low temperatures	
29	
Steering head bearing	
lubricating	65
Steering head bearing play	
adjusting	64
checking	63
Storage	
Swingarm	
checking	87
T	
Tampering	
Throttle cable play	
adjusting	127
checking	126
Throttle cable routing	
checking	87
Throttle twist grip	
20	
Tire condition	
checking	107
Tire pressure	
checking	108
Transportation	
36	
V	
Vehicle identification number	
17	
VIN	
17	
W	
Work rules	
11	



3240232en

08/07/2025

