

# OWNER'S MANUAL 2010

**525 XC ATV EU**

Art. no. 3211487en



**KTM**



# DEAR KTM CUSTOMER

Congratulations on your decision to buy a KTM ATV. You are now the owner of a state-of-the-art sports ATV that will give you enormous pleasure if you service and maintain it accordingly.

We wish you a lot of enjoyment in riding this vehicle!

Enter the serial numbers of your vehicle below.

|                          |                |
|--------------------------|----------------|
| Chassis number (☛ p. 16) | Dealer's stamp |
| Engine number (☛ p. 17)  |                |
| Key number (☛ p. 17)     |                |

The owner's manual corresponded to the latest state of this series at the time of printing. Slight deviations resulting from continuing development and design can however not be completely excluded.

All specifications are non-binding. KTM Sportmotorcycle AG specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. KTM accepts no liability for delivery options, deviations from illustrations and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of delivery.

© 2009 by KTM-Sportmotorcycle AG, Mattighofen Austria

All rights reserved

Reproduction, even in part, is permitted only with the express written permission of the copyright owner.



ISO 9001(12 100 6061)

According to the international quality management standard ISO 9001, KTM uses quality assurance processes that lead to the maximum possible quality of the products.

Issued by: TÜV Management Service

REG.NO. 12 100 6061

KTM-Sportmotorcycle AG  
5230 Mattighofen, Austria

|  |    |   |    |
|--|----|---|----|
| MEANS OF REPRESENTATION .....                              | 7  | Tripmaster switch .....                                   | 29 |
| IMPORTANT INFORMATION .....                                | 8  | Setting kilometers or miles .....                         | 29 |
| VIEW OF VEHICLE .....                                      | 12 | Setting the clock .....                                   | 30 |
| View of the vehicle from the left front (example) .....    | 12 | Adjusting the speedometer functions .....                 | 31 |
| View of the vehicle from the right rear (example) .....    | 14 | Querying the lap time .....                               | 32 |
| LOCATION OF SERIAL NUMBERS .....                           | 16 | Display mode SPEED (speed) .....                          | 33 |
| Chassis number .....                                       | 16 | Display mode SPEED/H (operating hours) .....              | 34 |
| Type label .....   | 16 | Display mode SPEED/CLK (clock) .....                      | 35 |
| Key number .....   | 17 | Display mode SPEED/LAP (lap time) .....                   | 35 |
| Engine number .....  | 17 | Display mode SPEED/ODO (odometer) .....                   | 36 |
| Front shock absorber part number .....                     | 18 | Display mode SPEED/TR1 (trip master 1) .....              | 36 |
| Rear shock absorber part number .....                      | 18 | Display mode SPEED/TR2 (trip master 2) .....              | 37 |
| CONTROLS .....   | 19 | Display mode SPEED/A1 (average speed 1) .....             | 38 |
| Clutch lever .....   | 19 | Display mode SPEED/A2 (average speed 2) .....             | 38 |
| Hand brake lever, front parking brake .....                | 20 | Display mode SPEED/S1 (stop watch 1) .....                | 39 |
| Steering lock .....  | 21 | Display mode SPEED/S2 (stop watch 2) .....                | 40 |
| Parking brake lever .....                                  | 22 | Opening filler cap .....                                  | 42 |
| Throttle lever .....                                       | 23 | Closing filler cap .....                                  | 42 |
| Light switch .....   | 23 | Locking the steering .....                                | 43 |
| Turn signal switch .....                                   | 24 | Unlocking the steering .....                              | 43 |
| Kill switch .....  | 24 | Fuel tap .....  | 44 |
| Horn button .....  | 25 | Choke .....   | 45 |
| Ignition switch .....                                      | 25 | Hot start button .....                                    | 45 |
| Electric starter button .....                              | 26 | Shift lever .....   | 46 |
| Hazard warning flasher switch/hazard warning flasher ..... | 26 | Foot brake lever .....                                    | 47 |
| Indicator lamp overview .....                              | 27 | GENERAL TIPS AND HINTS ON PUTTING INTO<br>OPERATION ..... | 48 |
| Emergency OFF switch with rip cord .....                   | 27 | advice on first use .....                                 | 48 |
| Speedometer .....  | 28 | Running in the engine .....                               | 50 |
| Speedometer activation and test .....                      | 28 |   |    |

|   |    |   |     |
|---|----|---|-----|
| RIDING INSTRUCTIONS .....   | 51 | Front shock absorber - adjusting the cross over.....        | 75  |
| Checks before putting into operation .....  | 51 | Front shock absorber - adjusting the spring preload .....   | 77  |
| Starting .....  | 52 | Rear shock absorber - adjusting the compression damping ... | 79  |
| Starting up .....   | 54 | Rear shock absorber - adjusting the rebound damping.....    | 80  |
| Shifting .....  | 54 | Rear shock absorber - adjusting the spring preload 🛠️ ..... | 81  |
| Braking .....   | 55 | Removing the rear shock absorber 🛠️ .....                   | 83  |
| Riding .....  | 56 | Installing the rear shock absorber 🛠️ .....                 | 85  |
| Riding in bends.....  | 57 | Checking the toe 🛠️ .....                                   | 85  |
| Riding downhill .....   | 58 | Adjusting the toe 🛠️ .....                                  | 88  |
| Riding uphill .....   | 59 | Checking/adjusting the camber 🛠️ .....                      | 90  |
| Riding perpendicular to the slope.....  | 60 | Handlebar position .....                                    | 93  |
| Turning on slopes .....   | 60 | Adjusting the handlebar position 🛠️ .....                   | 94  |
| Riding through water .....  | 62 | Checking the play in the throttle cable.....                | 96  |
| Switching off the engine .....  | 62 | Adjusting play in throttle cable .....                      | 97  |
| Stopping, parking .....   | 64 | Checking the basic setting of the shift lever .....         | 97  |
| Refueling.....  | 65 | Adjusting the basic position of the shift lever 🛠️ .....    | 98  |
| SERVICE SCHEDULE.....   | 67 | Checking chain dirt .....                                   | 99  |
| Important maintenance work to be carried out by an authorized KTM workshop .....                          | 67 | Cleaning the chain.....                                     | 99  |
| Important maintenance work to be carried out by an authorized KTM workshop (as an additional order) ..... | 69 | Checking the chain tension .....                            | 100 |
| Important checks and maintenance work to be carried out by the rider .....                                | 71 | Checking rear sprocket / engine sprocket for wear .....     | 101 |
| MAINTENANCE ON CHASSIS AND ENGINE .....   | 72 | Checking chain wear .....                                   | 102 |
| Jacking up the vehicle .....  | 72 | Adjusting chain tension.....                                | 103 |
| Removing the vehicle from the work stand .....  | 72 | Greasing the rear wheel eccentric element .....             | 105 |
| Basic information on changing the chassis settings.....   | 72 | Checking brake discs .....                                  | 105 |
| Front shock absorber - adjusting the compression damping .....  | 73 | Checking the free travel of the hand brake lever .....      | 106 |
| Front shock absorber - adjusting the rebound damping.....   | 74 | Adjusting basic position of hand brake lever.....           | 107 |
|   |    | Checking front brake fluid level.....                       | 107 |
|   |    | Topping up the front brake fluid 🛠️ .....                   | 108 |
|   |    | Checking the front brake linings.....                       | 110 |

|  |     |   |     |
|--|-----|---|-----|
| Removing front brake linings                  | 111 | Installing the front trim .....   | 142 |
| Mounting front brake linings                  | 112 | Removing the rear fender .....  | 142 |
| Changing the front brake linings              | 113 | Installing the rear fender .....  | 144 |
| Checking free travel of foot brake lever .....   | 115 | Removing the engine guard .....   | 146 |
| Adjusting basic position of foot brake lever  | 116 | Installing the engine guard .....   | 146 |
| Checking rear brake fluid level .....  | 117 | Removing the air filter                                    | 147 |
| Adding rear brake fluid                       | 118 | Installing the air filter                                  | 149 |
| Checking rear brake linings .....  | 120 | Cleaning air filter                                        | 150 |
| Removing rear brake linings                   | 121 | Adjusting basic position of clutch lever .....  | 151 |
| Mounting rear brake linings                   | 122 | Checking fluid level of hydraulic clutch .....  | 151 |
| Changing rear brake linings                   | 124 | Cooling system .....  | 152 |
| Removing wheel/wheels .....  | 125 | Radiator fan .....  | 152 |
| Mounting wheel/wheels .....  | 126 | Checking the antifreeze and coolant level .....   | 153 |
| Checking the tire condition .....  | 127 | Checking the coolant level .....  | 154 |
| Checking the tire air pressure .....   | 128 | Draining coolant   | 155 |
| Removing the battery .....   | 129 | Filling coolant / bleeding cooling system                  | 157 |
| Installing the battery .....   | 130 | Carburetor - idle .....   | 159 |
| Recharging the battery                        | 130 | Carburetor - adjusting idle                                | 160 |
| Changing the main fuse .....   | 132 | Emptying the carburetor float chamber                      | 162 |
| Changing the fuses of individual power consumers .....   | 133 | Checking the engine oil level .....   | 163 |
| Checking the headlight setting .....   | 135 | Changing engine oil and oil filter, cleaning oil<br>screens  | 164 |
| Adjusting the headlight range of the headlight .....   | 136 | Draining engine oil, cleaning oil screens                  | 164 |
| Removing the seat .....  | 136 | Removing the oil filter                                    | 168 |
| Mounting the seat .....  | 137 | Installing the oil filter                                  | 170 |
| Removing the radiator spoiler .....  | 137 | Filling up with engine oil                                 | 170 |
| Installing the radiator spoiler .....  | 138 | Adding engine oil .....   | 171 |
| Removing the front cover .....   | 140 | TROUBLESHOOTING .....   | 173 |
| Installing the front cover .....   | 140 |   |     |
| Removing the front trim .....  | 141 |   |     |

|   |     |
|---|-----|
| CLEANING.....   | 178 |
| Cleaning the vehicle .....                              | 178 |
| STORAGE .....   | 180 |
| Storage.....  | 180 |
| Putting the vehicle into operation after storage.....   | 181 |
| TECHNICAL DATA - ENGINE .....                           | 182 |
| Capacity - engine oil .....                             | 183 |
| Capacity - coolant.....                                 | 183 |
| TECHNICAL DATA - ENGINE TIGHTENING TORQUES.....         | 184 |
| TECHNICAL DATA - CARBURETOR.....                        | 187 |
| TECHNICAL DATA - CHASSIS .....                          | 188 |
| Lighting equipment .....                                | 190 |
| Tires .....   | 190 |
| Capacity - fuel.....                                    | 191 |
| TECHNICAL DATA - FRONT SHOCK ABSORBER .....             | 192 |
| TECHNICAL DATA - REAR SHOCK ABSORBER .....              | 193 |
| TECHNICAL DATA - TIGHTENING TORQUES FOR<br>CHASSIS..... | 194 |
| SUBSTANCES.....   | 196 |
| AUXILIARY SUBSTANCES.....                               | 200 |
| STANDARDS.....  | 203 |
| INDEX .....   | 204 |

## Symbols used

The symbols used are explained in the following.



Indicates an expected reaction (e.g. of a work step or a function).



Indicates an unexpected reaction (e.g. of a work step or a function).



All work marked with this symbol requires specialist knowledge and technical understanding. In the interest of your own safety, have these jobs performed at an authorized KTM workshop! There, your vehicle will be serviced optimally by specially trained experts using the specialist tools required.



Identifies a page reference (more information is provided on the specified page).

## Formats used

The typographical and other formats used are explained below.

**Specific name**

Identifies a proprietary name.

**Name®**

Identifies a protected name.

**Brand™**

Identifies a brand in merchandise traffic.

## Use definition

The vehicle is designed and constructed to withstand the usual demands of regular traffic and use on gentle terrain (unpaved roads), but not for use on race tracks.



### Info

The ATV is authorized for public road traffic in the homologous version only.

---

## Maintenance

A prerequisite for trouble-free operation and prevention of wear is that the engine and chassis maintenance and adjustment work described in the owner's manual are properly carried out. Poor adjustment and tuning of the engine and chassis can lead to damage and breakage of components.

Using the vehicle in extreme conditions such as very muddy or wet roads can lead to above-average wear of components such as the transmission train or the brakes. For this reason, it may be necessary to service or replace worn parts before the limit specified in the service schedule is reached.

Pay careful attention to the prescribed running-in period, inspection and maintenance intervals. If you observe these exactly, you will ensure a much longer service life for your vehicle.

## Fuel, oils, etc.

You should use the fuels, oils and greases according to specifications as listed in the owner's manual.

## Spare parts, accessories

For your own safety, only use spare parts and accessories that have been approved and/or recommended by KTM and have them installed by an authorized KTM workshop. KTM accepts no liability for other products and any resulting damage or loss.

Certain spare parts and accessories are specified in parentheses in the descriptions. Your KTM dealer will be glad to advise you.

The current **KTM PowerParts** for your vehicle can be found on the KTM website.  
International KTM Website: <http://www.ktm.com>

## Work rules

Special tools are needed for certain tasks. They are not included with the vehicle but can be ordered under the number in parentheses.  
E.g.: valve spring mounter (59029019000)

When assembling the equipment, non-reusable parts (e.g. self-locking screws and nuts, seals, seal rings, O-rings, pins, lock washers) must be replaced with new parts.

If a thread locker (e.g. **Loctite**®) is used for screw connections, follow the instructions for use from the manufacturer.

Parts that are to be reused after being disassembled should be cleaned and checked for damage and wear. Replace damaged or worn parts.

After finishing the repair and maintenance work, ensure that the vehicle is roadworthy.

## Transport

### Note

**Danger of damage** Danger of damage from accidental rolling of vehicle.

- Park the vehicle on a surface that is as horizontal as possible and apply the parking brakes.

### Note

**Fire hazard** Some vehicle components become very hot when the vehicle is operated.

- Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being run. Always let the vehicle cool first.

- 
- Switch off the engine.
  - Turn the handle ❶ of the fuel tap to **OFF**. (Figure 100013-10  p. 44)
  - Use straps or other suitable devices to secure the vehicle against accidents or falling over.
  - Fold down the parking brake lever ❶. (Figure 601044-10  p. 22)

- Pull the hand brake lever, push the locking pawl  down and release the hand brake lever. (Figure 100006-10  p. 20)

## Environment

ATV riding is a wonderful sport and we naturally hope that you will be able to enjoy it to the fullest. However, it is a potential problem for the environment and can lead to conflicts with other persons. If you use your ATV responsibly, you can ensure that such problems and conflicts do not have to occur. Make sure that you use your ATV legally, display environmental consciousness, and respect the rights of others.

## Rider training

If you have never ridden an ATV before, it is important that you participate in a driver training course before you ride the vehicle for the first time.

A professional trainer will show you how to handle your ATV safely in various riding situations and on different terrain.

Your KTM dealer will be glad to advise you.

## Warning notes

Be sure to pay attention to the notes and warnings given here.



### Info

Various notes and warning stickers are attached to the vehicle. Do not remove any warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

## Grades of risks

---



### **Danger**

Danger that leads immediately and certainly to severe and permanent injury or death.



### **Warning**

Danger that will probably lead to severe and permanent injury or death.

### **Note**

Danger of serious damage to machine or material.



### **Warning**

Risk of environmental damage.

---

## Owner's manual

- It is important that you read this owner's manual carefully and completely before making your first trip. It contains a lot of information and tips to help you operate and handle your vehicle. Only then will you find out how to customize the vehicle ideally for your own use and how you can protect yourself from injury. The owner's manual also contains important information on servicing the vehicle.
- The owner's manual is an important component of the vehicle and should be handed over to the new owner if the vehicle is sold.

## View of the vehicle from the left front (example)



# VIEW OF VEHICLE

|    |                                    |
|----|------------------------------------|
| 1  | Hand brake lever                   |
| 2  | Fuse box                           |
| 3  | Headlight                          |
| 4  | Front left turn signal             |
| 5  | Front bumper                       |
| 6  | Steering lock                      |
| 7  | Front left shock absorber          |
| 8  | Clutch lever                       |
| 9  | Emergency OFF switch with rip cord |
| 10 | Heel protector                     |
| 11 | Left footrest                      |
| 12 | Shift lever                        |
| 13 | Outside brake disk guard           |

## View of the vehicle from the right rear (example)




---

|    |  |
|----|--|
| 1  | Light switch, turn signal switch, kill switch, horn button |
| 2  | Electric starter button                                    |
| 3  | Parking brake lever  |
| 4  | Filler cap   |
| 5  | Main silencer  |
| 6  | License plate holder                                       |
| 7  | Rear shock absorber  |
| 8  | Rear sprocket with chain                                   |
| 9  | Rear brake   |
| 10 | Foot brake lever   |
| 11 | Oil level viewer   |
| 12 | Fuel tap   |
| 13 | Throttle lever   |
| 14 | Ignition switch  |


---

## Chassis number



The chassis number ❶ is stamped on the right side of the frame in the vicinity of the upper control arm.

## Type label



The type label ❶ is located on the frame tube on the right in front of the radiator.

## Key number




The key number ❶ is indicated on the **KEYCODECARD**.



### Info


You need the key number to order a replacement key. Keep the **KEYCODECARD** in a safe place.

## Engine number



The engine number ❶ is stamped on the left side of the engine under the engine sprocket.

## Front shock absorber part number




The shock absorber part number ❶ is stamped on the top part of the shock absorber.

## Rear shock absorber part number



The shock absorber part number ❶ is stamped on the top part of the shock absorber.

## Clutch lever




The clutch lever ❶ is fitted on the left side of the handlebar.

### Possible states

- Clutch lever in neutral position – In this position, the engine is force-locked with the gear and the starting circuit is interrupted. The electric starter does not turn over when the electric starter button is pressed.
- Clutch lever pulled – In this position, the force lock between the engine and the gear is broken and the starting circuit is closed. The electric starter turns over when the electric starter button is pressed.

The clutch is hydraulically operated and self-adjusting.

## Hand brake lever, front parking brake



The hand brake lever ❶ is located on the right side of the handlebar and operates the front brakes.


The hand brake lever is combined with the front parking brake, which locks the front wheels to prevent the vehicle from rolling away.

To apply the parking brake, pull the hand brake lever, push the locking pawl ❷ down and release the hand brake lever.

### Possible states


- Hand brake lever in basic position – The front wheels are not locked.
- Hand brake lever pulled and locked in position – The front wheels are locked.

## Steering lock



The steering lock ❶ is fitted on the steering column.  
The steering lock can be used to lock the steering. This makes steering impossible and the vehicle cannot be ridden.

## Parking brake lever



The parking brake lever ❶ is located on the left side of the handlebar and operates the rear brakes.


The parking brake lever is combined with the parking brake, which locks the rear wheels to prevent the vehicle from rolling away.

To apply the parking brake, fold down the parking brake lever.

### Possible states


- A Parking brake lever ❶ in basic position – The rear wheels are not locked.
- B Parking brake lever ❶ pulled – The rear wheels are locked.

## Throttle lever



The throttle lever ❶ is fitted on the right side of the handlebar. The throttle lever is used to control the engine speed.

## Light switch



The light switch ❶ is fitted on the left side of the handlebar.

### Possible states

|   |  |
|---|--|
|  | Lights off – The light switch is rocked to the right. In this position, the light is switched off.                         |
|  | Low beam on – Light switch in the middle position. In this position, the low beam and tail lights are switched on.         |
|  | High beam on – The light switch is rocked to the left. In this position, the high beam and the tail light are switched on. |

## Turn signal switch




The turn signal switch ❶ is fitted on the left side of the handlebar.

### Possible states

|   |   |
|---|---|
|   | Turn signal off – The turn signal switch is in the central position.  |
| ← | Left turn signal on – The turn signal switch is rocked to the left.   |
| → | Right turn signal on – The turn signal switch is rocked to the right. |

## Kill switch




The kill switch ❶ is fitted on the left side of the handlebar.

### Possible states

- Kill switch ☒ in basic position – In this position, the ignition circuit is closed and the engine can be started.
- Kill switch ☒ pressed – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.

## Horn button



601030-10

The horn button ❶ is fitted on the left side of the handlebar.

### Possible states

- Horn button  in basic position
- Horn button  pressed – In this position, the horn is actuated.

## Ignition switch



601032-10

The ignition switch ❶ is located to the right of the speedometer.

### Possible states

|   |   |
|---|---|
|  | <p>Ignition off – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.</p> |
|  | <p>Ignition on – In this position, the ignition circuit is closed and the engine can be started.</p>  |

## Electric starter button



The electric starter button ❶ is fitted on the left side of the handlebar.

### Possible states

- Electric starter button in basic position
- Electric starter button pressed – In this position, the electric starter is actuated.

## Hazard warning flasher switch/hazard warning flasher



The hazard warning flasher switch ❶ is fitted centrally below the indicator lamps. The hazard warning flasher is used to indicate emergency situations.



### Info


The hazard warning flasher can be activated or deactivated while the ignition is switched on or up to 30 seconds after it is switched off.

Only activate the hazard warning flasher as long as absolutely necessary to avoid discharging the battery.

### Possible states

|  |   |
|--|---|
|  | Hazard warning flasher off  |
|  | Hazard warning flasher on – All four turn signals, the hazard warning flasher switch and the green turn signal indicator light in the combination instrument flash. |

## Indicator lamp overview




601033-10

### Possible states

|  |  |
|--|--|
|  | Reverse gear indicator lamp ❶ – No function.   |
|  | Turn signal indicator light ❷ flashes green with the flashing rhythm – The turn signal is switched on. |
|  | High beam indicator lamp ❸ lights up blue – The high beam is switched on.                              |
|  | Idling speed indicator lamp ❹ lights up green – The transmission is switched to idle.                  |

## Emergency OFF switch with rip cord




601084-10

The emergency OFF switch ❶ is mounted on the left in front of the fuel tank. The emergency OFF switch shuts the engine off if the rider falls off the vehicle. Clip ❷ is attached to a rip cord that can be attached to the clothing of the rider by means of a carabiner ❸.

### Possible states

- Clip is pulled off – The ignition circuit is interrupted, a running engine stops and a non-running engine will not start.
- Clip is mounted – The ignition circuit is closed and the engine can be started.

## Speedometer



400312-01


- Press the key  to change the display mode or change to one of the Setup menus.
- Press the key  to control different functions.
- Press the key  to control different functions.



### Info

When the vehicle is delivered, only the **SPEED/H** and **SPEED/ODO** display modes are activated.

## Speedometer activation and test




400313-01

To activate the speedometer:

The speedometer is activated when one of the buttons is activated or a pulse arrives from the wheel speed sensor.

Display test

To test the display function, all display segments light up briefly.



## **WS** (wheel size)

After the display function test, the wheel size **WS** is displayed briefly.



### **Info**

1735 mm corresponds to a circumference of 10" for the front wheels with series tires.

After this, the display changes to the mode selected last.

## Tripmaster switch

You can use the trip master switch to control the functions of the speedometer from the handlebar.



### **Info**

The trip master is an optional accessory.

## Setting kilometers or miles




### **Info**

If you change the unit, the value **ODO** is retained and converted accordingly.  
The values **TR1**, **TR2**, **A1**, **A2** and **S1** are cleared when the unit of measure is changed.

### **Condition**

The vehicle is stationary.



- Press the button  briefly and repeatedly until **H** appears at the bottom right of the display.
- Press the button  for 3 - 5 seconds.
  - ✓ The setup menu is displayed and the active functions shown.
- Press the button  repeatedly until the **Km/h/Mph** display flashes.

### **Km/h adjusting**

- Press the button .

### **Mph adjusting**

- Press the button .
- Press the button  for 3 - 5 seconds.

- ✓ The settings are stored and the setup menu is closed.



### **Info**

If no button is actuated for 20 seconds or there is no signal from the wheel speed sensor, then the settings are automatically stored and the setup menu closed.

---

## **Setting the clock**

### **Condition**

The vehicle is stationary.



- Press the button  briefly and repeatedly until **CLK** appears at the bottom right of the display.
- Press the button  for 3 - 5 seconds.
  - ✓ The hour display flashes.
- Set the hour display with the button  and/or button .
- Press the button  briefly.
  - ✓ The next segment of the display flashes and can be set.
- You can set the following segments in the same way as the hours by pressing the button  and the button .



### Info

The seconds can only be set to zero.

- Press the button  for 3 - 5 seconds.
  - ✓ The settings are stored and the Setup menu is closed.



### Info

If no button is pressed for 20 seconds, or if a pulse arrives from the wheel speed sensor, the settings are stored automatically and the Setup menu is closed.

## Adjusting the speedometer functions




### Info

When the vehicle is delivered, only the **SPEED/H** and **SPEED/ODO** display modes are activated.

### Condition

The vehicle is stationary.



- Press the button  briefly and repeatedly until **H** appears at the bottom right of the display.
- Press the button  for 3 - 5 seconds.
  - ✓ The Setup menu is displayed and the activated functions are shown.
- Change to the desired function by pressing the button  briefly.
  - ✓ The selected function flashes.

### Activating a function

- Press the button .
  - ✓ The symbol remains on the screen and the display changes to the next function.

### Deactivating the function

- Press the button .
  - ✓ The symbol on the screen goes out and the display changes to the next function.
- All desired functions are activated or deactivated accordingly.
- Press the button  for 3 - 5 seconds.
  - ✓ The settings are stored and the Setup menu is closed.



### Info

If no button is pressed for 20 seconds, or if a pulse arrives from the wheel speed sensor, the settings are stored automatically and the Setup menu is closed.

## Querying the lap time



### Info

This function can be called only if lap times are measured.

## Condition

The vehicle is stationary.

- Press the button  briefly and repeatedly until **LAP** appears at the bottom right of the display.
- Press the button  briefly.
- ✓ **LAP 1** appears on the left side of the display.
- Laps 1-10 can be displayed by pressing the button .
- The  button has no function
- Press the button  briefly.
- ✓ Next display mode

## Info

If an impulse is received from the wheel speed sensor, the left side of the display changes back to the **SPEED** mode.



## Display mode SPEED (speed)

- Press the button  briefly and repeatedly until **SPEED** appears on the left side of the display.

The current speed is displayed in the **SPEED** display mode.

The current speed can be displayed in **Km/h** or **Mph**.

## Info

Making the setting according to the country.

When an impulse comes from the front wheel, the left side of the speedometer display changes to the **SPEED** mode and the current speed is shown.



## Display mode SPEED/H (operating hours)



### Condition

- The vehicle is stationary.
- Press the button  briefly and repeatedly until **H** appears at the bottom right of the display.

In display mode **H**, the operating hours of the engine are displayed. The service hour counter stores the total riding time.

### Info

The service hour counter is necessary for adhering to the maintenance schedule. If the speedometer is in display mode **H** when the vehicle starts moving, it automatically changes to display mode **ODO**. Display mode **H** is suppressed during the trip.

|   |   |
|---|---|
| Press the button  .                  | No function   |
| Press the button  .                  | No function   |
| Press the button  for 3 - 5 seconds. | The display changes to the Setup menu of the speedometer functions. |
| Press the button  briefly.           | Next display mode   |

## Display mode SPEED/CLK (clock)



- Press the button briefly and repeatedly until **CLK** appears at the bottom right of the display.

The time is displayed in **CLK** display mode.

|                                      |   |
|--------------------------------------|---|
| Press the button .                   | No function   |
| Press the button .                   | No function   |
| Press the button  for 3 - 5 seconds. | The display changes to the Setup menu of the clock. |
| Press the button  briefly.           | Next display mode                                   |

## Display mode SPEED/LAP (lap time)



- Press the button briefly and repeatedly until **LAP** appears at the bottom right of the display.

In the **LAP** display mode, up to 10 lap times can be timed with the stop watch.

**Info**  
 If the lap time continues after you press the button , 9 memory locations are already occupied.  
 Lap 10 must be timed with the button .

|                                      |  |
|--------------------------------------|--|
| Press the button .                   | Starts or stops the clock.   |
| Press the button .                   | Stops the current lap time and saves it, and the stop watch starts the next lap. |
| Press the button  for 3 - 5 seconds. | The stop watch and the lap time are reset.                                       |

|   |                   |
|---|-------------------|
| Press the button  briefly. | Next display mode |
|---|-------------------|

## Display mode SPEED/ODO (odometer)



- Press the button  briefly and repeatedly until **ODO** appears at the bottom right of the display.

In **ODO** display mode, the total number of kilometers ridden is displayed.

|   |                   |
|---|-------------------|
| Press the button  .                  | No function       |
| Press the button  .                  | No function       |
| Press the button  for 3 - 5 seconds. | –                 |
| Press the button  briefly.           | Next display mode |

## Display mode SPEED/TR1 (trip master 1)



- Press the button  briefly and repeatedly until **TR1** appears at the top right of the display.

**TR1** (trip master 1) runs constantly and counts to 999.9.

You can use it to measure trips or the distance between refueling stops.

**TR1** is coupled with **A1** (average speed 1) and **S1** (stop watch 1).

---


 **Info**  
If 999.9 is exceeded, the values of **TR1**, **A1** and **S1** are automatically reset to 0.0.

---

|  |             |
|--|-------------|
| Press the button  .  | No function |
| Press the button  . | No function |

|   |   |
|---|---|
| Press the button  for 3 - 5 seconds. | The <b>TR1</b> , <b>A1</b> and <b>S1</b> displays are reset to 0.0. |
| Press the button  briefly.           | Next display mode   |

## Display mode SPEED/TR2 (trip master 2)



- Press the button  briefly and repeatedly until **TR2** appears at the top right of the display.

**TR2** (trip master 2) runs constantly and counts up to 999.9.

The displayed value can be set manually with the button  and the button . A very practical function when riding using the road book.

**i Info**  
The **TR2** value can also be corrected manually during the journey with the button  and the button . If 999.9 is exceeded, the value of **TR2** is automatically reset to 0.0.

|   |                                 |
|---|---------------------------------|
| Press the button  .                  | Increases value of <b>TR2</b> . |
| Press the button  .                  | Reduces value of <b>TR2</b> .   |
| Press the button  for 3 - 5 seconds. | Deletes value of <b>TR2</b> .   |
| Press the button  briefly.           | Next display mode               |

## Display mode SPEED/A1 (average speed 1)



- Press the button  briefly and repeatedly until **A1** appears at the top right of the display.

**A1** (average speed 1) shows the average speed calculated on the basis of **TR1** (trip master 1) and **S1** (stop watch 1).

The calculation of this value is activated by the first impulse of the wheel speed sensor and ends 3 seconds after the last impulse.

|   |   |
|---|---|
| Press the button  .                  | No function   |
| Press the button  .                  | No function   |
| Press the button  for 3 - 5 seconds. | The <b>TR1</b> , <b>A1</b> and <b>S1</b> displays are reset to 0.0. |
| Press the button  briefly.           | Next display mode   |

## Display mode SPEED/A2 (average speed 2)



- Press the button  briefly and repeatedly until **A2** appears at the top right of the display.

**A2** (average speed 2) shows the average speed on the basis of the current speed if the stop watch **S2** (stop watch 2) is running.

**Info**  
The displayed value can differ from the actual average speed if **S2** was not timed after the ride.

|  |             |
|--|-------------|
| Press the button  .   | No function |
| Press the button  . | No function |

|   |                   |
|---|-------------------|
| Press the button  for 3 - 5 seconds. | –                 |
| Press the button  briefly.           | Next display mode |

## Display mode SPEED/S1 (stop watch 1)



- Press the button  briefly and repeatedly until **S1** appears at the top right of the display.

**S1** (stop watch 1) displays the journey time on the basis of **TR1** and continues when an impulse is received from the wheel speed sensor.

The calculation of this value starts with the first impulse of the wheel speed sensor and ends 3 seconds after the last impulse.

|   |  |
|---|--|
| Press the button  .                  | No function  |
| Press the button  .                  | No function  |
| Press the button  for 3 - 5 seconds. | Displays of <b>TR1</b> , <b>A1</b> and <b>S1</b> are reset to 0.0. |
| Press the button  briefly.           | Next display mode  |

## Display mode SPEED/S2 (stop watch 2)



- Press the button briefly and repeatedly until **S2** appears at the top right of the display.

**S2** (stop watch 2) is a manual stop watch.

If **S2** is running in the background, the **S2** display flashes in the speedometer display.

|                                      |   |
|--------------------------------------|---|
| Press the button .                   | Starts or stops <b>S2</b> .                           |
| Press the button .                   | No function   |
| Press the button  for 3 - 5 seconds. | Displays of <b>S2</b> and <b>A2</b> are reset to 0.0. |
| Press the button  briefly.           | Next display mode                                     |


| Table of functions                            |                            |  |   |                            |
|---|----------------------------|--|---|----------------------------|
| Display                                       | Press the button .         | Press the button .   | Press the button  for 3 - 5 seconds.                                | Press the button  briefly. |
| Display mode <b>SPEED/H</b> (operating hours) | No function                | No function  | The display changes to the Setup menu of the speedometer functions. | Next display mode          |
| Display mode <b>SPEED/CLK</b> (clock)         | No function                | No function  | The display changes to the Setup menu of the clock.                 | Next display mode          |
| Display mode <b>SPEED/LAP</b> (lap time)      | Starts or stops the clock. | Stops the current lap time and saves it, and the stop watch starts the next lap. | The stop watch and the lap time are reset.                          | Next display mode          |
| Display mode <b>SPEED/ODO</b> (odometer)      | No function                | No function  | –   | Next display mode          |

| <b>Table of functions</b>                         |   |  |   |   |
|---|---|--|---|---|
| <b>Display</b>                                    | <b>Press the button <math>\pm</math>.</b> | <b>Press the button <math>\equiv</math>.</b> | <b>Press the button <math>\odot</math> for 3 - 5 seconds.</b>       | <b>Press the button <math>\odot</math> briefly.</b> |
| Display mode <b>SPEED/TR1</b><br>(trip master 1)  | No function                               | No function                                  | The <b>TR1</b> , <b>A1</b> and <b>S1</b> displays are reset to 0.0. | Next display mode                                   |
| Display mode <b>SPEED/TR2</b><br>(trip master 2)  | Increases value of <b>TR2</b> .           | Reduces value of <b>TR2</b> .                | Deletes value of <b>TR2</b> .                                       | Next display mode                                   |
| Display mode <b>SPEED/A1</b><br>(average speed 1) | No function                               | No function                                  | The <b>TR1</b> , <b>A1</b> and <b>S1</b> displays are reset to 0.0. | Next display mode                                   |
| Display mode <b>SPEED/A2</b><br>(average speed 2) | No function                               | No function                                  | –   | Next display mode                                   |
| Display mode <b>SPEED/S1</b><br>(stop watch 1)    | No function                               | No function                                  | Displays of <b>TR1</b> , <b>A1</b> and <b>S1</b> are reset to 0.0.  | Next display mode                                   |
| Display mode <b>SPEED/S2</b><br>(stop watch 2)    | Starts or stops <b>S2</b> .               | No function                                  | Displays of <b>S2</b> and <b>A2</b> are reset to 0.0.               | Next display mode                                   |

| <b>Table of conditions and menu activation</b> |                                   |                              |
|--|-----------------------------------|------------------------------|
| <b>Display</b>                                 | <b>The vehicle is stationary.</b> | <b>Menu can be activated</b> |
| Display mode <b>SPEED/H</b> (operating hours)  | •                                 |                              |
| Display mode <b>SPEED/CLK</b> (clock)          |                                   | •                            |
| Display mode <b>SPEED/LAP</b> (lap time)       |                                   | •                            |
| Display mode <b>SPEED/TR1</b> (trip master 1)  |                                   | •                            |
| Display mode <b>SPEED/TR2</b> (trip master 2)  |                                   | •                            |
| Display mode <b>SPEED/A1</b> (average speed 1) |                                   | •                            |
| Display mode <b>SPEED/A2</b> (average speed 2) |                                   | •                            |
| Display mode <b>SPEED/S1</b> (stop watch 1)    |                                   | •                            |

| Table of conditions and menu activation     |                            |                       |
|---|----------------------------|-----------------------|
| Display                                     | The vehicle is stationary. | Menu can be activated |
| Display mode <b>SPEED/S2</b> (stop watch 2) |                            | •                     |


## Opening filler cap



100012-10

- Press release button ❶, turn filler cap counterclockwise and lift it free.

## Closing filler cap



100012-11

- Replace the filler cap and turn clockwise until the release button ❶ locks in place.
- Check the fuel tank breather ❷ to ensure it is properly seated.
  - » If the fuel tank breather is at an angle or loose:
    - Correctly mount the fuel tank breather.

## Locking the steering

### Note

**Danger of damage** The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.




- Park the vehicle.
  - Turn the handlebar all the way to the left.
  - Insert the key into the steering lock, turn it to the left, press it in and turn it to the right. Pull out the key.
- ✓ Steering is no longer possible.



### Info

Never leave the key in the steering lock.

## Unlocking the steering



- Insert the key into the steering lock, turn it to the left, pull it out and turn it to the right. Pull out the key.
- ✓ The vehicle can be steered again.



### Info

Never leave the key in the steering lock.

## Fuel tap



The fuel tap is on the right of the fuel tank.

With the tap handle ❶ on the fuel tap, you can open or close the supply of fuel to the carburetor.

### Possible states

- Fuel supply off **OFF** – No fuel can flow from the tank to the carburetor.
- Fuel supply on **ON** – Fuel can flow from the tank to the carburetor. The fuel tank empties down to the reserve.
- Reserve fuel supply on **RES** – Fuel can flow from the tank to the carburetor. The fuel tank empties completely.


**OFF**



**ON**




**RES**



100013-10

## Choke



The choke ❶ is fitted on the left side of the carburetor. Activating the choke function frees an opening through which the engine can draw extra fuel. This gives a richer fuel-air mixture, which is needed for a cold start.




### Info

If the engine is warm, the choke function must be deactivated.

### Possible states

- Choke function activated – The choke lever is pulled out to the stop.
- Choke function deactivated – The choke lever is pushed in to the stop.

## Hot start button



The hot start button (red) ❶ is fitted on the left side of the carburetor. Activating the hot start function frees an opening in the carburetor through which the engine can draw extra air. This gives a leaner fuel-air mixture, which is needed for a hot start.




### Info

If the engine is cold, the hot start function must be deactivated.


### Possible states

- Hot start function activated – The hot start button is pulled out to the stop.
- Hot start function deactivated – The hot start button is pushed in as far as possible.

## Shift lever




The shift lever ❶ is mounted on the left side of the engine.



The gear positions can be seen in the photograph.  
The neutral or idle position is between the first and second gears.

## Foot brake lever



The foot brake lever ❶ is located in front of the right footrest.  
The foot brake lever activates the brakes of all four wheels.

## advice on first use



### **Danger**

**Danger of accidents** Danger arising from the rider's judgement being impaired.

- Do not use the vehicle if you are inexperienced or if you have consumed alcohol or drugs.



### **Warning**

**Danger of accidents** Unaccustomed handling of the ATV.

- If you have never ridden an ATV before, it is important that you participate in a driver training course before you ride the vehicle for the first time.
- A professional trainer will show you how to handle your ATV safely in various riding situations and on different terrain. Your KTM dealer will be glad to advise you.



### **Warning**

**Risk of injury** Missing or poor protective clothing present an increased safety risk.

- Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear protective clothing, which must be undamaged and meet legal requirements.



### **Warning**

**Danger of crashing** Poor vehicle handling due to different tire tread patterns on front and rear wheels.

- The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.



### **Warning**

**Danger of accidents** Critical riding behavior due to inappropriate riding.

- Adapt your riding speed to the road conditions and your riding ability.



### **Warning**

**Danger of accidents** Accident risk caused by presence of a passenger.

- Your vehicle is not designed to carry passengers. Do not ride with a passenger.



## Warning

**Danger of accidents** Unstable riding behavior.

- Do not exceed the maximum permissible weight and axle loads.



## Warning

**Risk of misappropriation** Usage by unauthorized persons.

- Never leave the vehicle unattended while the engine is running. Secure the vehicle against use by unauthorized persons. Switch off the engine, pull out the ignition key and lock the steering lock.



## Warning

**Danger of accidents** Instable handling from loaded luggage.

- The vehicle is not designed to carry luggage. Do not attach luggage to the vehicle.



## Info

When using your vehicle, remember that others may feel disturbed by excessive noise.

- Make sure that the pre-delivery inspection work has been carried out by an authorized KTM workshop. You receive a delivery certificate and the service record at vehicle handover.
- Before your first trip, read the entire owner's manual thoroughly.
- Get to know the controls.
- Adjust the basic position of the clutch lever. (☞ p. 151)
- Adjust the basic position of hand brake lever. (☞ p. 107)
- Adjust the basic position of the foot brake lever. ☞ (☞ p. 116)
- Become accustomed to handling the vehicle on a suitable piece of land before making a longer trip.
- Do not use the vehicle in ways that demands skills beyond your ability and experience.
- Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.

- Do not exceed the overall maximum permitted weight and the axle loads.

Guideline

|                                    |                  |
|------------------------------------|------------------|
| Maximum permissible overall weight | 335 kg (739 lb.) |
| Maximum allowable axle load        |                  |
| Front                              | 160 kg (353 lb.) |
| Rear                               | 190 kg (419 lb.) |

- Run the engine in.

## Running in the engine

- During the running-in phase, do not exceed the specified engine speed and engine performance.

Guideline

|                                  |           |
|----------------------------------|-----------|
| Maximum engine speed             |           |
| During the first 3 service hours | 7,000 rpm |
| Maximum engine performance       |           |
| During the first 3 service hours | ≤ 50 %    |
| During the next 12 service hours | ≤ 75 %    |

- Avoid fully opening the throttle!

## Checks before putting into operation



### Info

Make sure that the vehicle is roadworthy before use.



### Info

In the interests of riding safety, make a habit of making a general check before you ride.

- Check the engine oil level. (☛ p. 163)
- Check the engine for oil loss.
- Check the fuel supply.
- Check the chain tension. (☛ p. 100)
- Check the chain dirt accumulation. (☛ p. 99)
- Check the tire condition. (☛ p. 127)
- Check the tire air pressure. (☛ p. 128)
- Check the front brake fluid level. (☛ p. 107)
- Check the rear brake fluid level. (☛ p. 117)
- Check the front brake linings. (☛ p. 110)
- Check the rear brake linings. (☛ p. 120)
- Check brake system function.
- Check that the rear hubs are tight.
- Check that the footrests are tight.
- Check the handlebar bridge bearing for excessive play.
- Check the handlebar for smooth operation and play.
- Check the coolant level. (☛ p. 154)
- Check the cooling system for leakage.

- Check that all controls are correctly adjusted and free to move.
- Check that the electrical equipment is functioning properly.

## Starting



### Danger

**Danger of poisoning** Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

### Note

**Engine failure** High engine speeds in cold engines have a negative effect on the service life of the engine.

- Always warm up the engine at low engine speeds.



### Info

If the engine is unwilling to start, the cause can be old fuel in the float chamber. The flammable elements of the fuel evaporate if the fuel stands for an extended period.


If the float chamber is filled with fresh fuel, the engine starts immediately.

Press the starter for a maximum of 5 seconds. Wait for a least 5 seconds until trying again.

### Condition

Vehicle has not been operated:  $\geq 1$  week

- Empty the carburetor float chamber.  (p. 162)
- Turn the handle ❶ of the fuel tap to **ON**. (Figure 100013-10  p. 44)
- ✓ Fuel can flow from the tank to the carburetor.



- Mount the vehicle.
- Insert the clip ② into the emergency OFF switch and fasten the rip cord to the clothing of the rider. (Figure 601084-10 p. 27)
- Turn the key in the ignition switch to the position ○.
- ✓ The yellow ignition indicator lamp **ON** lights up.



### Info

Under no circumstances should you open the throttle when switching on the ignition!

The vehicle is equipped with a safety system that switches off the engine in case of a malfunction in the throttle lever, throttle cable or carburetor. When the ignition is switched on, a system check is performed during which the throttle lever must be in its basic position. If not, the safety system detects a malfunction and blocks the ignition current. When the electric starter button is activated, the electric starter turns over the engine, but the engine does not start because there is no ignition spark.

- Shift gear to neutral.
- ✓ The green idling speed indicator lamp **N** light up.

### Condition

The engine is cold

- Pull choke lever out as far as possible.

### Condition

The engine is hot

- Pull the hot start button (red) all the way out.
- Pull the clutch lever.
- Press the electric starter button.

**Info**

When the clutch lever is not pulled, the starting circuit is not closed. The electric starter does not turn over when the electric starter button is pressed. Do not open the throttle.

- Release the clutch lever.

**Condition**

The engine is hot and running

- Push the hot start button in as far as possible when the engine is running.

## Starting up

**Info**

Switch on the light before riding the vehicle. You will then be seen earlier by other motorists.


- Move the parking brake lever  to the basic position. (Figure 601044-10  p. 22)
  - ✓ The parking brake in the rear is deactivated.
- Pull the hand brake lever and release it again.
  - ✓ Locking pawl moves into its basic position; front parking brake is deactivated.
- Pull the clutch lever, engage 1st gear, release the clutch lever slowly and simultaneously open the throttle carefully.

## Shifting

**Warning**

**Danger of accidents** If you change down at high engine speed, the rear wheels can lock.

- Do not change into a low gear at high engine speed. The engine races and the rear wheels can lock.



## Condition

When conditions allow (incline, road situation, etc.), you can shift into a higher gear.

- Release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch and open the throttle.

## Info

The position of the 5 forward gears can be seen in the illustration. First gear is used for starting off or for steep inclines.

- To shift down, brake if necessary and close the throttle at the same time.
- Pull the clutch lever and shift into a lower gear, release the clutch lever slowly and open the throttle or shift again.

## Braking



### Warning

**Danger of accidents** If you brake too hard, the wheels can lock. When the front wheels lock, the vehicle can no longer be steered.

- Adapt your braking to the traffic situation and the road conditions.



### Warning

**Danger of accidents** Reduced braking efficiency caused by spongy pressure point of front or rear brake.

- Check the brake system and do not continue riding. (Your authorized KTM workshop will be glad to help.)



### Warning

**Danger of accidents** Reduced braking efficiency due to wet or dirty brakes.

- Clean or dry dirty or wet brakes by riding and braking gently.



## Info

Use the hand brake lever to activate the front brakes and the foot brake lever to activate the brakes of all four wheels.

- When braking, release the throttle and apply the front and foot brakes at the same time.
- Shift the transmission to lower gears according to the vehicle's speed.
- Braking should always be completed before you go into a bend.
- On long downhill stretches, use the braking effect of the engine. Change down one or two gears, but do not overstress the engine. In this way, you will need to apply the brakes less often and the brakes will not overheat.

## Riding



### Info

If you hear unusual noises while riding, stop immediately, switch off the engine and contact an authorized KTM workshop. If the vehicle goes out of control and you fall off the vehicle, the clip of the emergency OFF switch is pulled off by the rip cord attached to your clothing. This short-circuits the ignition circuit and the engine switches off.

- During normal operation, you sit erect on the vehicle with both hands on the handlebar and both feet on the footrests.
- If the choke function was activated, deactivate it after the engine has warmed up.
- After reaching maximum speed by fully opening the throttle, close the throttle so it is 3/4 open.
  - ✓ This barely reduces vehicle speed but lowers fuel consumption considerably.
- Always open the throttle only as much as the engine can handle – abrupt pressure on the throttle increases fuel consumption.
- Switch off the engine if you expect to be standing for a long time.

### Guideline

≥ 2 min


- Avoid slipping the clutch frequently and for prolonged periods. This heats the engine oil, the engine and the cooling system.
- Ride with a lower engine speed instead of with a high engine speed and a slipping clutch.

## Riding in bends



### Info

When riding in bends, the outer wheels cover a greater distance than the inner wheels. Because the rear axle of the ATV is rigid in design, the rear wheels turn at the same speed. The difference in distance is compensated by slippage of the tires.




### Warning

**Danger of accidents** Excessive speed and turning at sharp angles can cause the vehicle to roll over.

- Decrease your speed before entering into bends.
- 
- Handling of the ATV is strongly influenced by shifts in the position of your body weight. Always shift your body weight toward the inside of the bend and forward.
  - The faster you ride and the tighter the bend, the more you need to shift your body weight.
  - Always exert pressure on the footrest on the inside of the bend.
  - Look in the direction of the bend while you are riding.
  - The farther back you are sitting, the more the vehicle has the tendency to move straight ahead. The farther forward you shift your weight, the more pressure is applied to the front axle and the more easily the vehicle can take the bend.

## Riding downhill



### Warning

**Danger of accidents** Danger of accidents when riding uphill and downhill.

- Always check the terrain before riding uphill or downhill.
- Never ride on a road or path with an uphill or downhill inclination of more than 25°.
- Never ride on a road or path that exceeds your riding skills.
- When you come to a standstill, always dismount from the vehicle and turn it.
- Never ride on a road or path with a slippery surface. The vehicle can easily go out of control and roll over.


### Note

**Material damage** Damage to vehicle after fall or rollover.

- Perform a vehicle check as is done every time before you start to ride.

- 
- Always ride straight up or down a slope and never at a slant.
  - Engage a gear with which you can ride all the way down the slope without shifting.
  - Shift your body weight to the rear and ride cautiously without opening the throttle.
  - Keep your vehicle speed and engine speed as constant as possible.
  - Brake by mainly applying the foot brake; the rear wheels should not become locked.

## Riding uphill




### Warning

**Danger of accidents** Danger of accidents when riding uphill and downhill.

- Always check the terrain before riding uphill or downhill.
  - Never ride on a road or path with an uphill or downhill inclination of more than 25°.
  - Never ride on a road or path that exceeds your riding skills.
  - When you come to a standstill, always dismount from the vehicle and turn it.
  - Never ride on a road or path with a slippery surface. The vehicle can easily go out of control and roll over.
- 
- Always ride straight up or down a slope and never at a slant.
  - Engage a gear with which you can ride all the way up the slope without shifting. Shifting on the slope can cause the vehicle to roll over.
  - Shift your body weight to the front and ride cautiously.
  - Keep your vehicle speed and engine speed as constant as possible.
  - Drive slowly over hilltops to give yourself the opportunity to react to obstacles and changes in terrain.
  - If the vehicle comes to a stop, immediately activate both brakes to prevent the vehicle from rolling backward. Dismount from the vehicle and turn it.

## Riding perpendicular to the slope



### Warning

**Danger of accidents** When riding perpendicular to a slope, the vehicle can tip easily and roll over.

- Avoid riding perpendicular to the slope if possible.
  - Ride slowly and shift your weight toward the slope.
- 
- When the vehicle first begins tipping, steer the vehicle downhill and immediately dismount on the uphill side.


## Turning on slopes



### Warning

**Danger of accidents** Danger of accidents from turning the vehicle on a slope.

- Never ride down a slope backward. The vehicle can roll over easily.
- Always position yourself next to the vehicle in a location where you cannot be caught by a wheel.
- When turning on a slope, always stand on the uphill side of the vehicle to avoid injury should the vehicle tip.
- If the slope is too steep or slippery to turn the vehicle, you should leave it where it is and get assistance in retrieving it.



- If you come to a stop on a slope with your vehicle, dismount from the vehicle and turn it.
- Switch off the engine and apply the parking brakes.

---


**i** **Info**

A gear must be engaged.

---

- Dismount from the vehicle on the uphill side.
- Grasp the handlebar with both hands, release the parking brakes and carefully pull the clutch.
- Let the vehicle roll downhill carefully until you reach a location where you can turn it. Control its speed using the clutch.
- To turn the vehicle, steer it to the side. When doing so, you should always stand on the uphill side and apply pressure to the footrest on the uphill side.
- When the vehicle is standing perpendicular to the slope or slightly downhill, apply the parking brakes.
- Mount the vehicle, start the engine, pull the clutch lever and engage 1st gear. Cautiously release the parking brakes and ride downhill in 1st gear.
- Ride downhill. (🔍 p. 58)
- If you lose control over the vehicle, you should get away from the vehicle as fast as possible.

## Riding through water



### Warning

**Danger of accidents** The vehicle can roll over when riding through deep water with a strong current.

- Avoid riding through deep water with a strong current.



### Warning

**Danger of accidents** Reduced braking efficiency due to wet or dirty brakes.

- Clean or dry dirty or wet brakes by riding and braking gently.

### Note

**Engine failure** When riding through deep water, water can enter into the engine through the air filter and cause engine damage.

- Only ride through water if it reaches no higher than the upper edge of the footrest.


- Before riding through water, determine the depth and current of the water.
- Ride slowly and negotiate around obstacles.
- After riding through water, dry the brakes by lightly activating both brakes until normal braking power is available again.
- If the vehicle became submerged, an authorized KTM workshop must perform a thorough check and comprehensive service. Do not start the engine.

## Switching off the engine



### Info

There are three ways to switch off the engine.



### Alternative 1

Switch off the engine using the ignition key.

- Turn the key in the ignition switch to the position ☒ while the engine is idling.



#### Info

All power consumers are switched off.

### Alternative 2

Switch off the engine using the kill switch.

- Press the kill switch ☒ at engine idle speed until the engine stops.



#### Info

When the engine is switched off using the kill switch, the power consumers are not switched off. All power consumers that are switched on (headlights, tail lights, etc.) continue consuming electricity. This uses battery power and causes it to discharge.

### Alternative 3

Switch off the engine using the emergency OFF switch with a rip cord.

- Pull off clip ②. (Figure 601084-10 p. 27)



#### Info

When the engine is switched off using the emergency OFF switch, the power consumers are not switched off. All power consumers that are switched on (headlights, tail lights, etc.) continue consuming electricity. This uses battery power and causes it to discharge.

## Stopping, parking



### Warning

**Danger of burns** Some vehicle components get very hot when the vehicle is in use.

- Do not touch hot components such as exhaust system, radiator, engine, shock absorber and brakes. Allow these components to cool down before starting work on them.

### Note


**Danger of damage** Danger of damage from accidental rolling of vehicle.

- Park the vehicle on a surface that is as horizontal as possible and apply the parking brakes.

### Note

**Fire hazard** Some vehicle components become very hot when the vehicle is operated.

- Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being run. Always let the vehicle cool first.



- Stop the vehicle and park it on a surface that is as horizontal as possible.
- Shift gear to neutral.
  - ✓ The green idling speed indicator lamp **N** light up.
- Switch off the engine. (☛ p. 62)
- Remove the ignition key and the clip from the emergency OFF switch.
- Fold down the parking brake lever ❶. (Figure 601044-10☛ p. 22)
  - ✓ The rear wheels are locked.
- Pull the hand brake lever, push the locking pawl ❷ down and release the hand brake lever. (Figure 100006-10☛ p. 20)
  - ✓ The front wheels are locked.
- Turn the handle ❶ of the fuel tap to **OFF**. (Figure 100013-10☛ p. 44)

- ✓ No more fuel flows from the tank to the carburetor.
- If the vehicle must be parked on an incline, additionally secure the rear wheels against rolling (see illustration).

## Refueling



### Danger

**Fire hazard** Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.



### Warning

**Danger of poisoning** Fuel is poisonous and a health hazard.


- Avoid contact of the fuel with skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel.



### Warning

**Environmental hazard** Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.



- Switch off the engine.
- Open the filler cap. (☛ p. 42)
- Fill the fuel tank with fuel up to measurement **A**.

Guideline

|                         |                 |
|-------------------------|-----------------|
| Measurement of <b>A</b> | 35 mm (1.38 in) |
|-------------------------|-----------------|

|                                  |                         |  |
|----------------------------------|-------------------------|--|
| Total fuel tank capacity approx. | 13.5 l<br>(3.57 US gal) | Super unleaded (ROZ 95 / RON 95 / PON 91) (☛ p. 199) |
|----------------------------------|-------------------------|--|

- Close the filler cap. (☛ p. 42)

## Important maintenance work to be carried out by an authorized KTM workshop

|             |   | S3N | S15A | S30A |
|-------------|---|-----|------|------|
| engine      | Change the engine oil and oil filter, clean the oil screens.  (☞ p. 164) | •   | •    | •    |
|             | Replace the spark plug.   |     |      | •    |
|             | Check and adjust the valve clearance.   | •   | •    | •    |
|             | Check the engine mounting screws for tightness.   | •   | •    | •    |
|             | Clean the spark plug connectors and check for tightness.  | •   | •    | •    |
|             | Check the shift lever screw for tightness.  | •   | •    | •    |
| Carburetor  | Check the carburetor connection boots for cracks and leakage.   |     | •    | •    |
|             | Check the vent hoses for damage and routing without sharp bends.  | •   | •    | •    |
|             | Check the idle.   | •   | •    | •    |
| Attachments | Check the cooling system for leakage.   | •   | •    | •    |
|             | Check the antifreeze and coolant level. (☞ p. 153)  | •   | •    | •    |
|             | Check the exhaust system for leakage and faulty attachment.   |     | •    | •    |
|             | Check the control cables for damage, smooth operation and routing without sharp bends.  | •   | •    | •    |
|             | Check the fluid level of the hydraulic clutch. (☞ p. 151)   | •   | •    | •    |
|             | Clean the air filter.  (☞ p. 150)  | •   | •    | •    |
|             | Check the cables for damage and routing without sharp bends.  |     | •    | •    |
|             | Check that the electrical equipment is functioning properly.  | •   | •    | •    |
| Brakes      | Check the headlight setting. (☞ p. 135)   |     | •    | •    |
|             | Check the front brake linings. (☞ p. 110)   | •   | •    | •    |
|             | Check the rear brake linings. (☞ p. 120)  | •   | •    | •    |
|             | Check the brake discs. (☞ p. 105)   | •   | •    | •    |
|             | Check the front brake fluid level. (☞ p. 107)   | •   | •    | •    |

|         |   | S3N | S15A | S30A |
|---------|---|-----|------|------|
| Brakes  | Check the rear brake fluid level. (☛ p. 117)                              | •   | •    | •    |
|         | Check the brake lines for damage and leakage.                             | •   | •    | •    |
|         | Check the free travel of the hand brake lever. (☛ p. 106)                 | •   | •    | •    |
|         | Check the free travel of the foot brake lever. (☛ p. 115)                 | •   | •    | •    |
|         | Check that the brake system is functioning properly.                      | •   | •    | •    |
|         | Check the screws and guide bolts of the brake system for tightness.       | •   | •    | •    |
| Chassis | Check the shock absorbers for cracks and proper functioning.              | •   | •    | •    |
|         | Check the steering column bearing for wear and smooth operation.          | •   | •    | •    |
|         | Clean and grease the bearing and sealing elements of the steering column. | •   | •    | •    |
|         | Check the handlebar for smooth operation and play.                        | •   | •    | •    |
|         | Check the handlebar bridge bearing for excessive play.                    | •   | •    | •    |
|         | Check the tie rods and tie rod ends for damage and play.                  | •   | •    | •    |
|         | Check the front wheel suspension for wear and tightness.                  | •   | •    | •    |
|         | Check that the front and rear wheel hubs are tight.                       | •   | •    | •    |
|         | Check the frame and swingarm for damage and leakage.                      |     | •    | •    |
|         | Check the swingarm bearing.   |     | •    | •    |
|         | Check the rear axle bearing for play.                                     | •   | •    | •    |
|         | Grease the rear wheel eccentric element. (☛ p. 105)                       |     | •    | •    |
|         | Check all screws to ensure that they are tight.                           | •   | •    | •    |
| Wheels  | Check for rim run-out.  | •   | •    | •    |
|         | Check the tire condition. (☛ p. 127)                                      | •   | •    | •    |
|         | Check the tire air pressure. (☛ p. 128)                                   | •   | •    | •    |
|         | Check the chain wear. (☛ p. 102)  | •   | •    | •    |

|        |   | S3N | S15A | S30A |
|--------|---|-----|------|------|
| Wheels | Check the chain tension. (☞ p. 100)     | •   | •    | •    |
|        | Clean the chain. (☞ p. 99)              | •   | •    | •    |
|        | Check the front wheel bearing for play. | •   | •    | •    |

**S3N:** Once after 3 operating hours

**S15A:** Every 15 operating hours

**S30A:** Every 30 operating hours

## Important maintenance work to be carried out by an authorized KTM workshop (as an additional order)

|   | S30A | S40A | S60A | S80A | S90A | S160A | J1A |
|---|------|------|------|------|------|-------|-----|
| Change the oil in the front shock absorber. ☞ |      |      |      | •    |      | •     |     |
| Service the front shock absorber. ☞           |      |      |      |      |      | •     |     |
| Change the oil in the rear shock absorber. ☞  |      | •    |      | •    |      | •     |     |
| Service the rear shock absorber. ☞            |      |      |      | •    |      | •     |     |
| Clean and adjust carburetor.                  |      |      |      |      |      |       | •   |
| Treat electric contacts with contact spray.   |      |      |      |      |      |       | •   |
| Change hydraulic clutch fluid.                |      |      |      |      |      |       | •   |
| Change brake fluid.                           |      |      |      |      |      |       | •   |
| Clean spark arrestor.                         |      |      |      |      |      |       | •   |
| Check for wear on the clutch discs.           | •    |      | •    |      | •    |       |     |
| Check the length of the clutch springs.       |      |      | •    |      |      |       |     |
| Check the clutch slave cylinder for dents.    |      |      | •    |      |      |       |     |
| Check the outer clutch hub for dents.         |      |      | •    |      |      |       |     |
| Check the cylinder and piston for wear.       |      |      |      |      | •    |       |     |
| Check for camshaft wear. (visual check)       |      |      |      |      | •    |       |     |

# SERVICE SCHEDULE

|  | S30A | S40A | S60A | S80A | S90A | S160A | J1A |
|--|------|------|------|------|------|-------|-----|
| Change the camshaft bearing support.   |      |      |      |      | •    |       |     |
| Check for wear of the valve spring seat.   |      |      |      |      | •    |       |     |
| Check for wear of the valve guides.  |      |      |      |      | •    |       |     |
| Check the valves.  |      |      |      |      | •    |       |     |
| Check the valve springs.   |      |      |      |      | •    |       |     |
| Check the radial clearance of the rocker arm rollers.                            |      |      |      |      | •    |       |     |
| Measure the length of the timing chain.  |      |      |      |      | •    |       |     |
| Check the timing-chain tensioner function.                                       |      |      |      |      | •    |       |     |
| Check the crankshaft and crankshaft journal for run-out.                         |      |      |      |      | •    |       |     |
| Change the conrod bearing.   |      |      |      |      | •    |       |     |
| Change the crankshaft main bearing.  |      |      |      |      | •    |       |     |
| Change the balancer bearing.   |      |      |      |      | •    |       |     |
| Check for wear of all transmission components including the shafts and bearings. |      |      |      |      | •    |       |     |
| Check the length of the bypass valve spring.                                     |      |      |      |      | •    |       |     |
| Change the glass fiber yarn filling of main silencer.                            |      |      | •    |      |      |       |     |
| Replace the foot brake cylinder seals.   |      |      | •    |      |      |       |     |
| Check the carburetor components.   |      |      | •    |      |      |       |     |

**S30A:** Every 30 operating hours

**S40A:** Every 40 operating hours

**S60A:** Every 60 operating hours

**S80A:** Every 80 operating hours

**S90A:** Every 90 operating hours

**S160A:** Every 160 operating hours

**J1A:** annually

## Important checks and maintenance work to be carried out by the rider

|   | NB1A |
|---|------|
| Check the engine oil level. (🔧 p. 163)                          | •    |
| Check the front brake fluid level. (🔧 p. 107)                   | •    |
| Check the rear brake fluid level. (🔧 p. 117)                    | •    |
| Check the front brake linings. (🔧 p. 110)                       | •    |
| Check the rear brake linings. (🔧 p. 120)                        | •    |
| Check and adjust control cables.                                | •    |
| Clean the chain. (🔧 p. 99)                                      | •    |
| Check the chain tension. (🔧 p. 100)                             | •    |
| Check the chain wear. (🔧 p. 102)                                | •    |
| Check rear sprocket / engine sprocket for wear. (🔧 p. 101)      | •    |
| Clean the air filter. 🌀 (🔧 p. 150)                              | •    |
| Check the tire air pressure. (🔧 p. 128)                         | •    |
| Check the tire condition. (🔧 p. 127)                            | •    |
| Check the coolant level. (🔧 p. 154)                             | •    |
| Check that all controls for smooth operation.                   | •    |
| Check braking force (incl. parking brake).                      | •    |
| Check all screws, nuts and hose clamps regularly for tightness. | •    |

**NB1A:** Depending on conditions of use according to requirements.

## Jacking up the vehicle



### Note

**Danger of damage** Danger of damage from tipping of vehicle.

- Jack up the vehicle on a firm and horizontal surface. Use a flex-free work stand.
- Jack up the vehicle on the frame underneath the engine. The wheels must no longer touch the ground.
- Secure the vehicle.

## Removing the vehicle from the work stand

### Note

**Danger of damage** The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.
- Lower the vehicle.
- Remove the work stand.

## Basic information on changing the chassis settings

The standard setting of the chassis is the result of many fine tuning tests. It is laid out for the weight of the average rider (with a full set of protective clothing) and for a sporty driving style.

|                      |                              |
|----------------------|------------------------------|
| Average rider weight | 70... 80 kg (154... 176 lb.) |
|----------------------|------------------------------|

By making a variety of adjustments to the chassis, you can set it to better match your body weight and riding style.

The left and right front shock absorbers should have the same settings.

If your weight is above or below the average, you have to adjust the standard setting of the suspension components accordingly.

Small weight differences can be compensated by adjusting the spring preload, but in the case of large weight differences, the springs must be replaced.



## Tip

When changing the chassis settings, always start with the standard setting.

Between test rides, always change only one setting. This will enable you to better assess the effect of the setting on vehicle handling.

Do not make radical changes to the settings; proceed in small steps instead. Even small changes can have a large impact on vehicle handling.

## Front shock absorber - adjusting the compression damping



### Danger

**Danger of accidents** Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized KTM workshop will be glad to help.)



### Warning

**Danger of accidents** Do not make any radical changes to the adjustment of the shock absorbers.

- Only make adjustments within the recommended range.



## Info

The compression damping setting has an impact on the compression of the shock absorber.



- Turn adjusting wheel ❶ clockwise up to the last perceptible click.
- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

|                     |           |
|---------------------|-----------|
| Compression damping |           |
| Comfort             | 20 clicks |
| Standard            | 15 clicks |
| Sport               | 15 clicks |

**i Tip**  
Experience has shown that settings outside of this range are detrimental to vehicle handling. When changing the chassis settings, always start with the standard setting.

**i Info**  
Turn clockwise to increase damping; turn counterclockwise to reduce damping. The left and right shock absorbers should have the same settings.

## Front shock absorber - adjusting the rebound damping

**! Danger**  
**Danger of accidents** Disassembly of pressurized parts can lead to injury.


- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized KTM workshop will be glad to help.)

**! Warning**  
**Danger of accidents** Do not make any radical changes to the adjustment of the shock absorbers.

- Only make adjustments within the recommended range.

## Info

The rebound damping setting has an impact on the compression of the shock absorber.



- Turn adjusting screw **1** clockwise up to the last perceptible click.
- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

### Guideline

| Rebound damping |           |
|-----------------|-----------|
| Comfort         | 20 clicks |
| Standard        | 15 clicks |
| Sport           | 15 clicks |

## Tip

Experience has shown that settings outside of this range are detrimental to vehicle handling. When changing the chassis settings, always start with the standard setting.

## Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping. The left and right shock absorbers should have the same settings.

## Front shock absorber - adjusting the cross over



### Danger

**Danger of accidents** Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized KTM workshop will be glad to help.)


**i** **Info**

The cross over setting is used to adjust the suspension travel of the short (soft) spring. Greater cross over makes the spring action at the front softer and the front of the vehicle lies lower. The suspension travel and the progressive part of the long (hard) spring is not fully utilized. Less cross over makes the spring action at the front harder and the front of the vehicle lies higher.

- Jack up the vehicle. (☛ p. 72)
- Clean the shock absorber thoroughly.
- Loosen adjusting ring ❶.

|                    |
|--------------------|
| Hook wrench (T304) |
|--------------------|

|                     |
|---------------------|
| Hook wrench (T157S) |
|---------------------|



601038-10

- Measure the cross over setting ❷ between sliding bushing ❷ and the collar of adjusting ring ❸.


Guideline

|            |                 |
|------------|-----------------|
| Cross over | 19 mm (0.75 in) |
|------------|-----------------|

**i** **Info**

Measured at the tension-free main spring.

- Tighten the spring by tuning adjusting rings ❶ to measurement ❷.



601091-01

**Info**

The sliding bushing is made of plastic. Therefore, do not lock it too tightly to avoid damaging the thread.  
The left and right shock absorbers should have the same settings.

- 
- Lock the adjusting rings.
  - Remove the vehicle from the work stand. (🔧 p. 72)

## Front shock absorber - adjusting the spring preload

---

**Danger**

**Danger of accidents** Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized KTM workshop will be glad to help.)

**Warning**

**Danger of accidents** Do not make any radical changes to the adjustment of the shock absorbers.

- Make adjustments in small steps only.
- 

**Info**


Increasing the spring preload raises the center of gravity of the vehicle. This can have a large impact on vehicle handling.

**Tip**

Before changing the spring preload, make a note of the present setting, e.g., by measuring the length of the spring.

---

- Jack up the vehicle. (🔧 p. 72)
- Clean the shock absorber thoroughly.



- Release counter ring ❶.

|                    |
|--------------------|
| Hook wrench (T304) |
|--------------------|

|                     |
|---------------------|
| Hook wrench (T157S) |
|---------------------|

- Turn adjusting ring ❷ until the spring pack is no longer under tension.
- Measure the overall spring pack when not under tension.

- Tighten the spring packet by turning adjusting ring ❷ to measurement Ⓐ.

### Guideline

| Spring preload |      |
|----------------|------|
| Comfort        | 4 mm |
| Standard       | 5 mm |
| Sport          | 8 mm |

### **i** Info


The spring preload Ⓐ is the difference in length between the spring pack when it is unloaded and when it is installed.

The spring pack should never be installed loosely (without preload). The comfort setting is the lowest permissible spring preload.

If you increase the spring preload, you should also slightly increase the rebound damping.

The left and right shock absorbers should have the same settings.

- Tighten the lock ring adjusting ring.
- Remove the vehicle from the work stand. (🔧 p. 72)



## Rear shock absorber - adjusting the compression damping



### Danger

**Danger of accidents** Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized KTM workshop will be glad to help.)



### Warning

**Danger of accidents** Do not make any radical changes to the adjustment of the shock absorbers.

- Only make adjustments within the recommended range.



### Info

The compression damping setting has an impact on the compression of the shock absorber.



601077-10

- Remove the rear fender. (☛ p. 142)
- Turn adjusting screw ① clockwise up to the last perceptible click.
- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

### Guideline

| Compression damping |           |
|---------------------|-----------|
| Comfort             | 20 clicks |
| Standard            | 15 clicks |
| Sport               | 15 clicks |

**Tip**

Experience has shown that settings outside of this range are detrimental to vehicle handling. When changing the chassis settings, always start with the standard setting.

**Info**

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

---

## Rear shock absorber - adjusting the rebound damping

---

**Danger**

**Danger of accidents** Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized KTM workshop will be glad to help.)

**Warning**


**Danger of accidents** Do not make any radical changes to the adjustment of the shock absorbers.

- Only make adjustments within the recommended range.
- 

**Info**

The rebound damping setting has an impact on the compression of the shock absorber.

---



601041-10

- Turn adjusting screw ❶ clockwise up to the last perceptible click.
- Turn back to the left by the number of clicks corresponding to the shock absorber type.

Guideline

| Rebound damping |           |
|-----------------|-----------|
| Comfort         | 20 clicks |
| Standard        | 15 clicks |
| Sport           | 15 clicks |



**Tip**

Experience has shown that settings outside of this range are detrimental to vehicle handling. When changing the chassis settings, always start with the standard setting.



**Info**

Turning to the right increases damping, while turning to the left lessens damping.

## Rear shock absorber - adjusting the spring preload



**Danger**

**Danger of accidents** Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized KTM workshop will be glad to help.)



**Warning**

**Danger of accidents** Do not make any radical changes to the adjustment of the shock absorbers.

- Make adjustments in small steps only.

**i Info**

Increasing the spring preload raises the center of gravity of the vehicle. This can have a large impact on vehicle handling.

**i Tip**

Before changing the spring preload, make a note of the present setting, e.g., by measuring the length of the spring.


- Remove the rear shock absorber. 🛠️ (🔧 p. 83)
- After removing the shock absorber, clean it thoroughly.
- Loosen screw ❶.


**i Info**

Do not loosen lock nut ❷ at the top of the shock absorber.

- Turn adjusting ring ❷ until the spring is fully relaxed.

Hook wrench (T157S)





- Measure the overall spring length when not under tension.

**i Info**

The spring preload **A** is the difference in length between the spring when it is unloaded and when it is installed.

- Tighten the spring to specified measurement by turning the adjusting ring.

Guideline

| Spring preload |      |
|----------------|------|
| Comfort        | 0 mm |
| Standard       | 3 mm |
| Sport          | 3 mm |

- Tighten screw **1**.

Guideline

|                                      |    |                   |
|--------------------------------------|----|-------------------|
| Screw, shock absorber adjusting ring | M6 | 5 Nm (3.7 lbf ft) |
|--------------------------------------|----|-------------------|


**i Info**

If you increase the spring preload, you should also slightly increase the rebound damping.

- Install the rear shock absorber. ( p. 85)

## Removing the rear shock absorber

- Jack up the vehicle. ( p. 72)
- Remove the rear fender. ( p. 142)



---

## Note

**Danger of damage** The chain sliding piece and frame can be damaged from incorrect handling.

- When removing the rear shock absorber, secure the swingarm with a tension belt to prevent it from swinging down further.

- 
- Attach the swingarm to the subframe with a tension belt **1** to relieve the shock absorber.
  - Remove the bottom screw of the shock absorber.


---

## i Tip

Press the screw out of the swingarm with a screw driver while moving the tension belt.

- 
- Remove the top screw **2** of the shock absorber and carefully remove the shock absorber out of the vehicle toward the rear.

## Installing the rear shock absorber ↩



- Position the shock absorber in the vehicle with the reservoir on the right. Mount and tighten the top screw ❶.

Guideline

|                                |     |                        |
|--------------------------------|-----|------------------------|
| Screw, rear top shock absorber | M12 | 60 Nm<br>(44.3 lbf ft) |
|--------------------------------|-----|------------------------|

- Position the shock absorber in the swingarm. Mount and tighten the bottom screw.

Guideline

|                                   |     |                        |
|-----------------------------------|-----|------------------------|
| Screw, rear bottom shock absorber | M12 | 70 Nm<br>(51.6 lbf ft) |
|-----------------------------------|-----|------------------------|




601075-10

- Remove the tension belt.
- Install the rear fender. (↩ p. 144)
- Remove the vehicle from the work stand. (↩ p. 72)

## Checking the toe ↩

- Park the vehicle on a horizontal surface.
- Check the tire condition. (↩ p. 127)
- Check the tire air pressure. (↩ p. 128)
- Check the chassis parts for damage, play and wear.




- Load the vehicle with the specified weight.

Guideline

|                      |                              |
|----------------------|------------------------------|
| Average rider weight | 70... 80 kg (154... 176 lb.) |
|----------------------|------------------------------|

- Move the handlebar into the straight-ahead position and fix it.

|  |
|--|
| Handlebar fixation for straight-ahead position (83019015100) |
|--|



400333-10

- Measure distances **A** and **B**.
  - » If distances **A** and **B** are not equal:
    - Adjust the toe. 🛠️ (📖 p. 88)
- Measure distances **C** and **D**.

Guideline

|       |             |
|-------|-------------|
| Toe   |             |
| Front | 0 mm (0 in) |

## **i** Info

The toe is the difference in length between distances ① and ② by which the wheels are spaced at the front or rear when driving straight ahead. The distance is measured at the height of the wheel center from rim flange to rim flange.

- » If the toe does not meet specifications:
  - Adjust the toe. 🛠️ (👉 p. 88)

## Adjusting the toe 🛠️


- Park the vehicle on a horizontal surface.
- Check the tire condition. (👉 p. 127)
- Check the tire air pressure. (👉 p. 128)
- Check the chassis parts for damage, play and wear. Replace damaged or worn parts.
- Load the vehicle with the specified weight.


### Guideline

|                      |                              |
|----------------------|------------------------------|
| Average rider weight | 70... 80 kg (154... 176 lb.) |
|----------------------|------------------------------|

- Move the handlebar into the straight-ahead position and fix it.

|  |
|--|
| Handlebar fixation for straight-ahead position (83019015100) |
|--|





- Loosen nuts ② and ③.
- Adjust the distances ① and ② to the same value by rotating the tie rods ①.
- Adjust the distances ③ and ④ to the specified value by evenly rotating the tie rods ①.

Guideline

|       |             |
|-------|-------------|
| Toe   |             |
| Front | 0 mm (0 in) |

**Info**

The toe is the difference in length between distances ① and ② by which the wheels are spaced at the front or rear when driving straight ahead. The distance is measured at the height of the wheel center from rim flange to rim flange.

- Tighten nuts ② and ③.

Guideline

|                            |            |                     |
|----------------------------|------------|---------------------|
| Lock nut, tie rod, outside | M12x1.25   | 20 Nm (14.8 lbf ft) |
| Lock nut, tie rod, inside  | M12LHx1.25 | 20 Nm (14.8 lbf ft) |

**Info**


The tie rods ① must still be freely movable.

## Checking/adjusting the camber ↩


**Info**

The left and right camber should have the same settings.  
The operations are the same on the left and right.


- Jack up the vehicle. (↩ p. 72)



- Loosen nuts **1**.




- Remove screws **2** with bushings **3**.



- Insert tool **4** in the heim joint and clip onto the A-arm.

Camber gauge (83019014000)


- Check the camber on both heim joints.
  - » If marking **5** is not aligned with the top edge of the A-arm:
    - Turn tool **4** with the heim joint in steps of 180° until the marking is in line with the top edge of the A-arm.
- Remove tool **4**.



- Position the A-arm with bushings ③. Mount and tighten screws ②.

Guideline

|                  |        |                        |
|------------------|--------|------------------------|
| Screw, A-arm top | M10x52 | 45 Nm<br>(33.2 lbf ft) |
|------------------|--------|------------------------|



- Align the heim joint at right angles to screws ② and tighten nut ①.

Guideline


|                |          |                        |
|----------------|----------|------------------------|
| Nut, A-arm top | M12x1.25 | 30 Nm<br>(22.1 lbf ft) |
|----------------|----------|------------------------|

**i Info**

All four heim joints must be checked and adjusted if necessary.

- Remove the vehicle from the work stand. (🔧 p. 72)

## Handlebar position




The handlebar position can be adjusted 4-fold by turning the handlebar support **1** and the handlebar support **2**.

The holes on the handlebar support are placed at a distance of **A** from the center.

|                                 |                   |
|---------------------------------|-------------------|
| Distance <b>A</b> between holes | 3.5 mm (0.138 in) |
|---------------------------------|-------------------|


The holes on the handlebar bridge are placed at a distance of **B** from the center.

|                                 |                   |
|---------------------------------|-------------------|
| Distance <b>B</b> between holes | 7.5 mm (0.295 in) |
|---------------------------------|-------------------|



100098-10

## Adjusting the handlebar position ↩




- Pull the instrument support off the handlebar and swing it to the side.



### Info

Protect the vehicle and its attachments from damage by covering them.  
Do not bend the cables and lines.



100099-10

- Remove the four screws ❶. Remove handlebar clamps ❷, swing the handlebar forward and set it down.
- Remove nuts ❸ and remove handlebar support ❹ with the screws.
- Remove screws ❺ and ❻.
- Remove screws ❼. Remove handlebar bridge ❽.
- Place handlebar bridge ❽ onto the steering column in the desired position. Mount and tighten screw ❻.

Guideline

|                        |    |                        |
|------------------------|----|------------------------|
| Screw, steering bridge | M8 | 20 Nm<br>(14.8 lbf ft) |
|------------------------|----|------------------------|

- Mount and tighten screw ❺.

Guideline

|                             |         |                        |
|-----------------------------|---------|------------------------|
| Screw, steering column, top | M20x1.5 | 25 Nm<br>(18.4 lbf ft) |
|-----------------------------|---------|------------------------|

- Mount and tighten screws ❼.

Guideline

|                        |    |                        |
|------------------------|----|------------------------|
| Screw, steering bridge | M8 | 20 Nm<br>(14.8 lbf ft) |
|------------------------|----|------------------------|

- Mount handlebar support ❹ in the desired position using the screws. Mount new self-locking nuts ❸ and tighten.

Guideline

|                        |     |                        |
|------------------------|-----|------------------------|
| Nut, handlebar support | M10 | 45 Nm<br>(33.2 lbf ft) |
|------------------------|-----|------------------------|

- Position the handlebar and fix it with handlebar clamps ❷. Mount and tighten screws ❶.

Guideline

|                        |    |                        |
|------------------------|----|------------------------|
| Screw, handlebar clamp | M8 | 20 Nm<br>(14.8 lbf ft) |
|------------------------|----|------------------------|




**Info**

Make sure cables and wiring are positioned correctly.

- Position the instrument support on the handlebar.

## Checking the play in the throttle cable



- Move the handlebar to the straight-ahead position. Move the throttle lever back and forth slightly to ascertain the play in the throttle cable **A**.

Guideline

|                        |                            |
|------------------------|----------------------------|
| Play in throttle cable | 3... 5 mm (0.12... 0.2 in) |
|------------------------|----------------------------|

- » If the throttle cable play does not meet specifications:
  - Adjust the play in the throttle cable. (🔧 p. 97)



**Danger**


**Danger of poisoning** Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.
- Start the engine and let it run idle. Move the handlebar to and fro over the entire steering range.

|                                 |
|---------------------------------|
| The idle speed must not change. |
|---------------------------------|

- » If the idle speed changes:
  - Adjust the play in the throttle cable. (🔧 p. 97)

## Adjusting play in throttle cable




- Check throttle cable route.
- Move the handlebar to the straight-ahead position.
- Loosen the nut ❶ and use the screw ❷ to adjust the play in the throttle cable ❸.

Guideline

|                        |                            |
|------------------------|----------------------------|
| Play in throttle cable | 3... 5 mm (0.12... 0.2 in) |
|------------------------|----------------------------|

- Tighten nut ❶.

## Checking the basic setting of the shift lever




- Sit on the vehicle in the riding position and measure the distance between the upper edge of your boot and shift lever ❶.


|   |                               |
|---|-------------------------------|
| Distance between shift lever and upper edge of boot | 10... 20 mm (0.39... 0.79 in) |
|---|-------------------------------|

- » If the distance does not meet specifications:
  - Adjust the basic position of the shift lever. (🔧 (🔧 p. 98)

## Adjusting the basic position of the shift lever



- Remove screw **1** and take off shift lever **2**.



- Clean gear teeth **A** of the shift lever and shift shaft.
- Position the shift lever in the desired position on the shift shaft and engage the gearing.

### Info

The range of adjustment is limited.


The shift lever should not come into contact with other vehicle components during shifting.

- Mount and tighten the screw.

### Guideline

|                    |    |                       |                      |
|--------------------|----|-----------------------|----------------------|
| Screw, shift lever | M6 | 10 Nm<br>(7.4 lbf ft) | <b>Loctite® 243™</b> |
|--------------------|----|-----------------------|----------------------|

## Checking chain dirt



- Check the chain for heavy soiling.
  - » If the chain is very dirty:
    - Clean the chain. (☛ p. 99)

## Cleaning the chain



### Warning


**Environmental hazard** Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



### Info

The service life of the chain depends largely on its maintenance.



- Clean the chain regularly and then treat with chain spray.

|                                    |
|------------------------------------|
| Chain cleaner (☛ p. 200)           |
| Chain lube for road use (☛ p. 200) |

## Checking the chain tension




### Warning

**Danger of accidents** Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel eccentric element) are under additional load. Apart from premature wear, in extreme transmission output shaft or the drive chain may snap. Conversely, if the chain is too loose it may jump off the engine and rear sprockets, causing the rear wheel to lock up or even leading to engine damage. Check for correct chain tension and adjust if necessary.

- Park the vehicle on a horizontal surface and shift gears to neutral.



- Push the upper chain section at the end of the chain sliding component upwards to measure the chain tension (X).



**Info**


The lower chain section must be taut.

Chain wear is not always even, so you should repeat this measurement at different chain positions.

|               |                                 |
|---------------|---------------------------------|
| Chain tension | 140... 145 mm (5.51... 5.71 in) |
|---------------|---------------------------------|

- » If the chain tension does not meet specifications:
  - Adjust the chain tension. (🔧 p. 103)

## Checking rear sprocket / engine sprocket for wear



- Check rear sprocket / engine sprocket for wear.
  - » If the rear sprocket / engine sprocket are worn:
    - Replace the rear sprocket / engine sprocket.




**Info**

When fitting the chain joint, always make sure that the closed side of the joint faces forward (riding direction).

The engine sprocket, rear sprocket and chain should always be replaced together.

- Check that the chain guides are tight.

## Checking chain wear



- Park the vehicle on a horizontal surface and shift gears to neutral.
- Pull on the lower part of the chain with the specified weight **A**.

Guideline

|                             |                            |
|-----------------------------|----------------------------|
| Chain-wear measuring weight | 10... 15 kg (22... 33 lb.) |
|-----------------------------|----------------------------|

- Measure the distance **B** of 18 chain links in the upper chain section.

### **i** Info

Chain wear is not always even, so you should repeat this measurement at different chain positions.

|  |                   |
|--|-------------------|
| Maximum distance <b>B</b> at the longest chain section | 272 mm (10.71 in) |
|--|-------------------|

- » If the distance **B** is greater than the specified measurement:
  - Replace the chain.

### **i** Info

When you replace the chain, you should also replace the rear sprocket and engine sprocket.

New chains wear out faster on old, worn sprockets.

601050-10


## Adjusting chain tension



### Warning

**Danger of accidents** Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel eccentric element) are under additional load. Apart from premature wear, in extreme transmission output shaft or the drive chain may snap. Conversely, if the chain is too loose it may jump off the engine and rear sprockets, causing the rear wheel to lock up or even leading to engine damage. Check for correct chain tension and adjust if necessary.




- Park the vehicle on a horizontal surface and shift gears to neutral.
- Push the upper chain section at the end of the chain sliding component upwards to measure the chain tension **X**.



### Info

The lower chain section must be taut.

Chain wear is not always even, so you should repeat this measurement at different chain positions.



- Loosen the screws ❶ by four turns.

**Alternative 1**

- Insert the tool ❷ from the tool set into the hole ❶ of the rear wheel eccentric element.

**Alternative 2**

- Position the special tool at the rear wheel eccentric element.

|                           |
|---------------------------|
| Hook wrench (83019011000) |
|---------------------------|

- To adjust the chain tension ❸, slowly turn at the rear wheel or the special tool to rotate the rear wheel eccentric element forward or backward.

Guideline

|               |                                 |
|---------------|---------------------------------|
| Chain tension | 140... 145 mm (5.51... 5.71 in) |
|---------------|---------------------------------|

**i** Info

Rotating the rear wheel eccentric element forward increases chain tension. Rotating the rear wheel eccentric element backward reduces chain tension. The rear wheel eccentric element should always be positioned such that the grease nipple ❷ is visible. This ensures that the vehicle has the greatest ground clearance.


- Fully tighten screws ❶.

Guideline

|                                     |    |                        |
|-------------------------------------|----|------------------------|
| Screw, rear wheel eccentric element | M8 | 20 Nm<br>(14.8 lbf ft) |
|-------------------------------------|----|------------------------|

- Remove the tool ❷.

## Greasing the rear wheel eccentric element



- Use a grease gun to fill the rear wheel eccentric element via the grease nipple ❶ until grease emerges from the left shaft seal ring ❷.

Long-life grease (👉 p. 198)


## Checking brake discs



### Warning

**Danger of accidents** Reduced braking efficiency due to worn brake disc(s).

- Change the worn brake disc(s) without delay. (Your authorized KTM workshop will be glad to help.)



- Check the thickness of the front and rear brake discs at several places on the disc to see if it conforms to measurement ❷.



### Info

Wear reduces the thickness of the brake disc around the area used by the brake linings.

| Brake discs - wear limit |                   |
|--------------------------|-------------------|
| Front                    | 3.5 mm (0.138 in) |
| Rear                     | 3.5 mm (0.138 in) |

- » If the brake disc thickness is less than the specified value:
  - Change the brake disc.
- Check the front and rear brake discs for damage, cracking and deformation.
  - » If the brake disc exhibits damage, cracking or deformation:
    - Change the brake disc.


## Checking the free travel of the hand brake lever



### Warning

**Danger of accidents** Brake system failure.

- If there is no free travel on the hand brake lever, pressure builds up in the front brake circuit. The front brake can fail due to overheating. Adjust free travel on hand brake lever according to specifications.




- Push the hand brake lever forward and check free travel **A**.

|                                 |   |
|---------------------------------|---|
| Free travel of hand brake lever | $\geq 3 \text{ mm } (\geq 0.12 \text{ in})$ |
|---------------------------------|---|

- » If the free travel does not meet specifications:
  - Adjust the basic position of hand brake lever. (➔ p. 107)

## Adjusting basic position of hand brake lever



- Check the free travel of the hand brake lever. (☛ p. 106)
- Adjust the basic setting of the hand brake lever to your hand size by turning adjusting screw ①.

### **i** Info

Pull the brake lever forward and turn the adjusting screw. Turn the adjusting screw clockwise to increase the distance between the hand brake lever and the handlebar. Turn the adjusting screw counterclockwise to decrease the distance between the hand brake lever and the handlebar. The range of adjustment is limited. Turn the adjusting screw by hand only, and do not apply any force. Do not make any adjustments while riding!

## Checking front brake fluid level



### **Warning**

**Danger of accidents** Brake system failure.

- If the brake fluid level falls below the bottom of the viewer, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and not continue riding. (Your authorized KTM workshop will be glad to help.)




### **Warning**

**Danger of accidents** Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brakes according to the service schedule. (Your authorized KTM workshop will be glad to help.)



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in the viewer ❶.
  - » If the brake fluid level drops below the bottom of the viewer:
    - Add front brake fluid. 🛠️ (👉 p. 108)



- Park the vehicle on a horizontal surface again.
- Check the brake fluid level in the viewer ❷.
  - » If the brake fluid level drops below the bottom of the viewer:
    - Add front brake fluid. 🛠️ (👉 p. 108)

## Topping up the front brake fluid 🛠️



### Warning

**Danger of accidents** Brake system failure.

- If the brake fluid level falls below the bottom of the viewer, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and not continue riding. (Your authorized KTM workshop will be glad to help.)



## Warning

**Skin irritation** Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid gets into your eyes, rinse thoroughly with water and contact a doctor immediately.



## Warning

**Danger of accidents** Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brakes according to the service schedule. (Your authorized KTM workshop will be glad to help.)



## Warning

**Environmental hazard** Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




## Info

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid is corrosive and may damage painted surfaces!

Use only clean brake fluid from a sealed container!



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover ② with membrane ③.
- Add brake fluid to level A.

Guideline

|   |               |
|---|---------------|
| Dimension A (brake fluid level below top edge of container) | 5 mm (0.2 in) |
|---|---------------|

Brake fluid DOT 4 / DOT 5.1 (☛ p. 196)

- Position the cover with the membrane. Mount and tighten screws.

**i Info**

Clean up overflowed or spilt brake fluid immediately with water.

## Checking the front brake linings




**Warning**

**Danger of accidents** Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately. (Your authorized KTM workshop will be glad to help.)

- Remove the wheel/wheels. (☛ p. 125)



- Check the brake linings of both front brake calipers for minimum thickness **A**.

|                            |   |
|----------------------------|---|
| Minimum thickness <b>A</b> | $\geq 1 \text{ mm } (\geq 0.04 \text{ in})$ |
|----------------------------|---|

- » If the minimum thickness is less than specified:
  - Change the front brake linings. 🛠️ (📖 p. 113)
- Check the brake linings for damage and cracking.
  - » If damage or cracking is visible:
    - Change the front brake linings. 🛠️ (📖 p. 113)
- Mount the wheel/wheels. (📖 p. 126)

## Removing front brake linings 🛠️



### Warning

**Danger of accident** Brake system failure.


- Maintenance work and repairs must be carried out professionally. (Your authorized KTM workshop will be glad to help.)



### Info

The operations are the same on the left and right.

- Remove the wheel/wheels. (📖 p. 125)
- Pull the hand brake lever and release it again.
  - ✓ Locking pawl moves into its basic position, parking brake is deactivated.



- Push the brake piston back to release pressure on the brake linings.
- Remove the locking split pins ❶, withdraw the bolt, and take out the brake linings.
- Clean the brake caliper and bolts.

## Mounting front brake linings ↩



### Warning

**Danger of accidents** Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



### Warning

**Danger of accidents** Reduced braking efficiency due to use of non-approved brake linings.


- Brake linings available from accessory suppliers are often not tested and approved for use on KTM vehicles. The construction and friction factor of the brake linings and therefore the brake power can differ considerably from the original KTM brake linings. If brake linings are used that differ from the originals, there is no guarantee that they comply with the original license. The vehicle no longer corresponds to the condition at delivery, and the warranty is no longer valid.




### Info

The operations are the same on the left and right.

- Check the brake discs. (↩ p. 105)



- Insert the inside brake lining into the brake caliper and fix with bolt ❶.
- Insert the external brake lining into the brake caliper and slide the bolts in all the way.



- Mount the locking split pins ❷.
- Operate the hand brake lever repeatedly until the brake linings lie on the brake disc and there is a pressure point.
- Mount the wheel/wheels. (🔧 p. 126)

## Changing the front brake linings 🛠️



### Warning

**Skin irritation** Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid gets into your eyes, rinse thoroughly with water and contact a doctor immediately.



## Warning

**Danger of accidents** Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brakes according to the service schedule. (Your authorized KTM workshop will be glad to help.)



## Warning

**Environmental hazard** Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.





## Info

Never use DOT 5 brake fluid! This is based on silicone oil and is colored purple. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid is corrosive and may damage painted surfaces!

Use only clean brake fluid from a sealed container!



- Remove the front brake linings. 🛠️ (☞ p. 111)
- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Press the brake piston back to its basic position and make sure that no brake fluid overflows from the brake fluid reservoir.
- Mount the front brake linings. 🛠️ (☞ p. 112)
- Correct brake fluid level to ❶.

Guideline

|   |               |
|---|---------------|
| Dimension ❶ (brake fluid level below top edge of container) | 5 mm (0.2 in) |
|---|---------------|

|  |
|--|
| Brake fluid DOT 4 / DOT 5.1 (☞ p. 196) |
|--|

- Position the cover with the membrane. Mount and tighten screws.



**Info**

Clean up overflowed or spilt brake fluid immediately with water.


## Checking free travel of foot brake lever



**Warning**

**Danger of accidents** Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust free travel on foot brake lever according to specifications.



- Disconnect spring ❶.
- Move the foot brake lever backwards and forwards between the end stop and the foot brake cylinder piston bracket and check free travel ❷.

Guideline

|                                 |                            |
|---------------------------------|----------------------------|
| Free travel at foot brake lever | 3... 5 mm (0.12... 0.2 in) |
|---------------------------------|----------------------------|

- » If the free travel does not meet specifications:
  - Adjust the basic position of the foot brake lever. 🛠️ (📄 p. 116)
- Reconnect spring ❶.


## Adjusting basic position of foot brake lever 🛠️



**Warning**

**Danger of accidents** Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust free travel on foot brake lever according to specifications.



- Disconnect spring ①.
- Loosen nut ② and with push rod ③, turn it back until you have maximum free travel.
- To adjust the basic position of the foot brake lever individually, loosen nut ④ and turn screw ⑤ accordingly.



### Info

The range of adjustment is limited.

- Turn push rod ③ accordingly until you have free travel A. If necessary, adjust the basic position of the foot brake lever.

#### Guideline

|                                 |                            |
|---------------------------------|----------------------------|
| Free travel at foot brake lever | 3... 5 mm (0.12... 0.2 in) |
|---------------------------------|----------------------------|

- Hold screw ⑤ and tighten nut ④.

#### Guideline

|                         |    |                        |
|-------------------------|----|------------------------|
| Remaining nuts, chassis | M8 | 30 Nm<br>(22.1 lbf ft) |
|-------------------------|----|------------------------|

- Hold push rod ③ and tighten nut ②.

#### Guideline

|                         |    |                        |
|-------------------------|----|------------------------|
| Remaining nuts, chassis | M6 | 15 Nm<br>(11.1 lbf ft) |
|-------------------------|----|------------------------|

- Reconnect spring ①.

## Checking rear brake fluid level



### Warning

**Danger of accidents** Brake system failure.


- If the brake fluid level falls below the bottom of the viewer, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and not continue riding. (Your authorized KTM workshop will be glad to help.)



## Warning

**Danger of accidents** Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brakes according to the service schedule. (Your authorized KTM workshop will be glad to help.)



- Park the vehicle on a horizontal surface.
- Check the brake fluid level in the viewer **1**.
  - » When the brake fluid level has dropped to the bottom of the viewer **1**:
    - Add rear brake fluid. 🛠️ (📖 p. 118)

## Adding rear brake fluid 🛠️



## Warning

**Danger of accidents** Brake system failure.

- If the brake fluid level falls below the bottom of the viewer, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and not continue riding. (Your authorized KTM workshop will be glad to help.)



## Warning

**Skin irritation** Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid gets into your eyes, rinse thoroughly with water and contact a doctor immediately.



## Warning

**Danger of accidents** Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brakes according to the service schedule. (Your authorized KTM workshop will be glad to help.)



## Warning

**Environmental hazard** Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




## Info


Never use DOT 5 brake fluid! This is based on silicone oil and is colored purple. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid is corrosive and may damage painted surfaces!

Use only clean brake fluid from a sealed container!



- Remove screw ❶ with membrane ❷.



- Add brake fluid to level **A**.

|  |
|--|
| Brake fluid DOT 4 / DOT 5.1 (☞ p. 196) |
|--|

- Refit screw **1** with membrane **2**.



### Info

Clean up overflowed or spilt brake fluid immediately with water.


## Checking rear brake linings



### Warning

**Danger of accidents** Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately. (Your authorized KTM workshop will be glad to help.)



- Check the brake linings for minimum thickness **A**.

|                            |   |
|----------------------------|---|
| Minimum thickness <b>A</b> | $\geq 1 \text{ mm } (\geq 0.04 \text{ in})$ |
|----------------------------|---|

- » If the minimum thickness is less than specified:
  - Change the rear brake linings. ☞ (☞ p. 124)
- Check the brake linings for damage and cracking.
  - » If damage or cracking is visible:
    - Change the rear brake linings. ☞ (☞ p. 124)

## Removing rear brake linings




### Warning

**Danger of accident** Brake system failure.


- Maintenance work and repairs must be carried out professionally. (Your authorized KTM workshop will be glad to help.)



- Press the brake caliper by hand on to the brake disc in order to press back the brake piston.



- Loosen the screw ❶ while holding the hexagonal head ❷ of the bearing bolt. Unscrew the screw by approx. 10 turns and use the screw to press the bearing bolt out of the brake caliper. Remove screw.



## Note

**Danger of damage** Kinking of brake line.

- Position and handle the brake line without straining it. The brake line must be replaced if it is kinked.
- 
- Swing the brake caliper up, unhook it from the brake caliper support ③ and set it down.
  - Remove the brake linings ④.
  - Clean brake caliper and brake caliper support.

## Mounting rear brake linings 🛠️



### Warning

**Danger of accidents** Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.




### Warning

**Danger of accidents** Reduced braking efficiency due to use of non-approved brake linings.

- Brake linings available from accessory suppliers are often not tested and approved for use on KTM vehicles. The construction and friction factor of the brake linings and therefore the brake power can differ considerably from the original KTM brake linings. If brake linings are used that differ from the originals, there is no guarantee that they comply with the original license. The vehicle no longer corresponds to the condition at delivery, and the warranty is no longer valid.

- 
- Check the brake discs. (🔧 p. 105)




601057-10

- Check that the sliding plate ❶ is seated correctly in the brake caliper support and insert the brake linings.

**i Info**


Make sure that the decoupling plate ❶ is mounted on the piston side of the brake lining.



601058-10

- Grease the bearing bolt ❷ and insert the brake caliper with the bearing bolt into the brake caliper support ❸.

Lubricant (T625) (☛ p. 201)



601059-01

- Swing the brake caliper downward. Mount and tighten the screw.

Guideline

|                           |    |                       |                      |
|---------------------------|----|-----------------------|----------------------|
| Screw, rear brake caliper | M6 | 10 Nm<br>(7.4 lbf ft) | <b>Loctite® 243™</b> |
|---------------------------|----|-----------------------|----------------------|

- Operate the foot brake lever repeatedly until the brake linings lie on the brake disc and there is a pressure point.

## Changing rear brake linings



### Warning

**Skin irritation** Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid gets into your eyes, rinse thoroughly with water and contact a doctor immediately.



### Warning

**Danger of accidents** Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brakes according to the service schedule. (Your authorized KTM workshop will be glad to help.)



### Warning

**Environmental hazard** Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




### Info

Never use DOT 5 brake fluid! This is based on silicone oil and is colored purple. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid is corrosive and may damage painted surfaces!

Use only clean brake fluid from a sealed container!



- Remove the rear brake linings. (👉 p. 121)
- Remove screw ❶ with membrane ❷.
- Press the brake piston back to its basic position and make sure that no brake fluid overflows from the brake fluid reservoir.
- Mount the rear brake linings. (👉 p. 122)
- Add brake fluid to level A.

Brake fluid DOT 4 / DOT 5.1 (👉 p. 196)

- Refit screw ❶ with membrane ❷.

## **i** Info


Clean up overflowed or spilled brake fluid immediately with water.

## Removing wheel/wheels

### **i** Info

Proceed in the same way on the other wheels if necessary.

- Pull the hand brake lever, push the locking pawl ❷ down and release the hand brake lever. (Figure 100006-10👉 p. 20)



- Loosen the wheel nuts ❶.
- Jack up the vehicle. (🔧 p. 72)
- Remove the wheel nuts. Remove the wheel.

## **i** Info

Carefully remove the wheel, making sure it does not become jammed with the threads of the screws.

## Mounting wheel/wheels


### Note

**Material damage** Damage and destruction of components from incorrect positioning and mounting.

- Do not swap the wheels; the tire valves must always be on the outside when the wheels are positioned and mounted.

## **i** Info

Proceed in the same way on the other wheels if necessary.



- Position the wheel on the hub.



**Info**

Carefully position the wheel on the hub, being careful not to damage the threads of the screws.

- Mount the wheel nuts but do not tighten.
- Remove the vehicle from the work stand. (☛ p. 72)
- Pull the hand brake lever, push the locking pawl Ⓜ down and release the hand brake lever. (Figure 100006-10 ☛ p. 20)
- Tighten the wheel nuts crosswise.

Guideline

|           |          |                        |
|-----------|----------|------------------------|
| Wheel nut | M10x1.25 | 45 Nm<br>(33.2 lbf ft) |
|-----------|----------|------------------------|

## Checking the tire condition



**Info**

Only mount tires that have been approved and/or recommended by KTM.

Other tires could have a negative effect on vehicle handling.

The type, condition and air pressure of the tires all have an important impact on the handling characteristics of the vehicle.

The tires mounted on the front and rear wheels must have similar profiles.

Worn tires have a negative effect on vehicle handling, especially on wet surfaces.

- Examine the tire for cuts, foreign bodies and other damage.
- Check the depth of the tread.

|                     |                    |
|---------------------|--------------------|
| Minimum tread depth | ≥ 2 mm (≥ 0.08 in) |
|---------------------|--------------------|

» If the tread depth is less than the minimum value:

- Change the tire.
- Check the tire age.

## **i** Info


The tire's date of manufacture is usually part of the tire markings and is indicated by the last four digits of the **DOT** marking. The first two digits indicate the week of manufacture and the last two digits the year of manufacture. KTM recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.

- » If the tire is older than five years:
  - Change the tire.

## Checking the tire air pressure

### **i** Info

Low tire air pressure leads to abnormal wear and overheating of the tire. Correct tire air pressure ensures optimal riding comfort and maximum tire service life. Check the tire pressure on all wheels and correct it if necessary.



- Remove the dust cap.
- Check the tire air pressure when the tires are cold.

|                                   |
|-----------------------------------|
| Tire pressure gauge (83519001000) |
|-----------------------------------|

|                   |                  |
|-------------------|------------------|
| Tire air pressure | 1.0 bar (15 psi) |
|-------------------|------------------|

- » If the tire pressure does not meet specifications:
  - Correct the tire pressure.
- Mount the dust cap.

## Removing the battery




### Warning


**Risk of injury** Battery acid and battery gases cause serious cauterization.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep the battery away from sparks or open fire. Charge only in well ventilated rooms.
- In the event of skin contact, rinse with large amounts of water. If battery acid gets in the eyes, rinse with water for at least 15 minutes and contact a doctor.

- Switch off all power consumers and switch off the engine.
- Remove the rear fender. (☛ p. 142)
- Disconnect the negative (minus) cable ❶ of the battery.
- Pull back the plus pole cover and disconnect the positive (plus) cable ❷ of the battery.
- Loosen the rubber band ❸.
- Remove the battery.



## Installing the battery



- Place the battery in the battery holder.

Battery (YTX5L-BS) (☛ p. 190)

- Reconnect rubber band ❶.
- Attach the positive (plus) cable and replace the plus pole cover ❷.
- Connect the negative (minus) cable ❸ of the battery.
- Install the rear fender. (☛ p. 144)

## Recharging the battery ☛



### Warning

**Risk of injury** Battery acid and battery gases cause serious cauterization.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep the battery away from sparks or open fire. Charge only in well ventilated rooms.
- In the event of skin contact, rinse with large amounts of water. If battery acid gets in the eyes, rinse with water for at least 15 minutes and contact a doctor.



### Warning

**Environmental hazard** Battery parts and acid are harmful to the environment.

- Do not discard batteries with the household trash. Dispose of a defective battery in an environmentally compatible manner. Give the battery to your KTM dealer or to a recycling center that accepts used batteries.



## Warning

**Environmental hazard** Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.
- 



## Info

Even if there is no load on the battery, it still loses power steadily.

The charge state and the type of charge are very important for the service life of the battery.

Rapid charging with a high charging current has a negative impact on the service life.

If the charging current, charging voltage and charging time are exceeded, electrolyte escapes via the safety valves. This reduces the battery capacity.

If the vehicle is started repeatedly until the battery is depleted, the battery must be charged immediately.

If the battery is left in a discharged state for an extended period, it will drain completely and sulfate, destroying the battery.

The battery is maintenance-free, which means that the acid level does not need to be checked.

---

- Switch off all power consumers and switch off the engine.
- Remove the rear fender. (☛ p. 142)
- Disconnect the minus (negative) cable of the battery to avoid damage to the vehicle's electronics.



- Connect the battery charger to the battery. Switch on the battery charger.

Battery charger (58429074000)

You can also use the battery charger to test rest potential and start potential of the battery, and to test the alternator. With this device, you cannot overcharge the battery.



**Info**

Never remove the lid ❶.

Charge the battery to a maximum of 10% of the capacity specified on the battery housing ❷.

- Switch off the charger after charging. Disconnect the battery.

**Guideline**


The charge current, charge voltage and charge time must not be exceeded.

|   |          |
|---|----------|
| Charge the battery regularly when the vehicle is not in use | 3 months |
|---|----------|

- Install the rear fender. (👉 p. 144)

## Changing the main fuse

- Switch off all power consumers and switch off the engine.



- The main fuse ❶ is located in the starter relay ❷ in front of the battery.
- Remove protection covers ❸.
- Remove the faulty main fuse.

**i Info**  
You can recognize a blown fuse by its broken filament ❶.

**⚠ Warning**  
**Fire hazard** The electrical system can be overloaded by the use of incorrect fuses.

- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.

- Insert the new fuse.


Fuse (58011109120)

**i Tip**  
Replacement fuse ❷ should always be present in the starter relay to make sure it is available when needed.

- Replace the protection covers.

## Changing the fuses of individual power consumers

- Remove the front cover. (👉 p. 140)
- Switch off all power consumers and switch off the engine.



100090-10

- Open the cover ② of the fuse box ①.

**i Info**

The designation of the fuses is located on the inside cover of the fuse box ②.

- Remove the faulty fuse.

Guideline

|   |
|---|
| Fuse - <b>1</b> 10A - ignition, CDI controller, indicator lamps ON, N, R                                    |
| Fuse - <b>2</b> 15A - high beam, low beam, parking light, tail light, brake light, high beam indicator lamp |
| Fuse - <b>3</b> 10A - radiator fan  |
| Fuse - <b>4</b> 10A - for auxiliary devices (permanent positive)  |
| Fuse - <b>5</b> 10A - for auxiliary devices (plus switched on with ignition switch)                         |
| Fuse - <b>res.</b> 10A/15A - replacement fuses  |

**i Info**

You can recognize a blown fuse by its broken filament **A**.

**⚠ Warning**

**Fire hazard** The electrical system can be overloaded by the use of incorrect fuses.

- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.


- Insert a new fuse of the appropriate strength.

|                    |
|--------------------|
| Fuse (58011109110) |
| Fuse (58011109115) |

**i Tip**  
 The replacement fuses should always be present in the fuse box to make sure they are available when needed.

- Close the cover of the fuse box.
- Install the front cover. (☛ p. 140)

## Checking the headlight setting



- On a light-colored wall with a horizontal area in front of it, make a mark at the height of the center of the headlight.
- Make another mark a distance **B** under the first mark.

Guideline

|                   |             |
|-------------------|-------------|
| Distance <b>B</b> | 5 cm (2 in) |
|-------------------|-------------|

- Position the vehicle a distance **A** vertically in front of the wall.
- Now the rider, wearing a full set of protective clothing, sits on the vehicle in the normal sitting position (feet on the footrests).

Guideline

|                   |             |
|-------------------|-------------|
| Distance <b>A</b> | 5 m (16 ft) |
|-------------------|-------------|

- Switch on the low beam. Check the headlight setting.

The boundary between light and dark must be exactly at the lower mark when the vehicle is operational and complete with a rider.

- » If the boundary between light and dark does not meet specifications:
  - Adjust the headlight range of the headlight. (☛ p. 136)

## Adjusting the headlight range of the headlight



- Check the headlight setting. (☞ p. 135)
- Loosen screw ❶.
- Adjust the headlight range of the headlight by moving it up or down.

### Guideline


The boundary between light and dark must be exactly on the lower mark for an operational vehicle with a rider (to prepare the mark, see: Checking the headlight setting).

### **i** Info

A change in weight on the vehicle may require a correction of the headlight range.


- Tighten screw ❶.

## Removing the seat




- Pull the release hook ❶ back. Lift up the seat at the rear, pull it back and then remove from above.

## Mounting the seat



- Hook slot ① on the seat into collar sleeve ① of the fuel tank, lower the rear of the seat and slide tab ② under fuel tank ②.




- Push down the rear of the seat until release hook ③ engages.
- Make sure that the seat is correctly locked in.

## Removing the radiator spoiler


### **i** Info

The operations are the same on the left and right.

- Remove the seat (🔧 p. 136)



- Remove the screws ❶ on the fuel tank.




- Remove the screws ❷ on the radiator.
- Detach the radiator spoiler and remove it.

## Installing the radiator spoiler




### Info

The operations are the same on the left and right.



- Hook catch **1** of the radiator spoiler into holder **2** of the fuel tank and position it on the radiator.



- Mount and tighten screws **3** on the radiator.

Guideline

|                           |    |                    |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|

- Mount and tighten screws **4** on the fuel tank.

Guideline

|                    |    |                   |
|--------------------|----|-------------------|
| Screw on fuel tank | M6 | 6 Nm (4.4 lbf ft) |
|--------------------|----|-------------------|


- Mount the seat. (👉 p. 137)

## Removing the front cover



- Remove screw ❶.
- Slide the front cover up and remove it.



## Installing the front cover



- Position the front cover in slots ❶ on both sides of the front trim.
- Mount and tighten the screw.


## Removing the front trim

- Remove the front cover. (☞ p. 140)
- Remove screws ❶.
- Raise the front trim and disconnect the plug-in connectors from the head light and the emergency OFF switch with the rip cord.
- Remove the front trim.



601063-10

## Installing the front trim



- Connect the plug-in connectors of the head light and the emergency OFF switch with the rip cord and position the front trim.
- Mount all screws.
- Fully tighten screws ❶.

Guideline

|                    |    |                   |
|--------------------|----|-------------------|
| Screw on fuel tank | M6 | 6 Nm (4.4 lbf ft) |
|--------------------|----|-------------------|

- Fully tighten screws ❷.


Guideline

|                           |    |                    |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|


- Install the front cover. (☛ p. 140)

## Removing the rear fender

- Remove the seat (☛ p. 136)




- Remove screws ❶.



- Raise the rear of the air filter box lid ❷. At the same time, use your other hand to press on the carburetor connection boot to kink it at that location. This prevents the carburetor connection boot from disconnecting from the carburetor.
- Raise fender ❸ at the rear and remove it.

## Installing the rear fender




- Raise the rear of air filter box lid ❶. At the same time, use your other hand to press on the carburetor connection boot to kink it at that location. This prevents the carburetor connection boot from disconnecting from the carburetor.
- Position front fender ❷.
- Fix the air filter box lid in the fender.

---

### **i** Info

If the air filter box lid is not correctly mounted, dust and dirt can penetrate into the engine and cause damage.

---




- Mount and tighten screws ③.

Guideline

|                           |    |                    |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|


- Mount the seat. (☛ p. 137)

## Removing the engine guard



- Remove screws ① and ②. Remove the engine guard.

## Installing the engine guard



- Position the engine guard on the frame bearer. Mount and tighten screws ① and ②.

### Guideline

|                           |    |                        |
|---------------------------|----|------------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft)     |
| Remaining screws, chassis | M8 | 25 Nm<br>(18.4 lbf ft) |

## Removing the air filter

### Note

**Engine failure** Unfiltered intake air has a negative effect on the service life of the engine.

- Never ride the vehicle without an air filter since dust and dirt can get into the engine and result in increased wear.




### Warning

**Environmental hazard** Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

- 
- Remove the seat ( p. 136)




- Raise the rear of the air filter box lid ①. At the same time, use your other hand to press on the carburetor connection boot ② to kink it at that location. This prevents the carburetor connection boot from disconnecting from the carburetor.
- Unhook the air filter holder ③ and swing it to the side. Remove the air filter ④ with the air filter support.
- Remove the air filter from the air filter support.

## Installing the air filter



- Mount the clean air filter onto the air filter support.
- Grease the air filter in area **A**.

Long-life grease ( p. 201)



- Put in both parts together, position them and fix them with the air filter support **1**.

### **Info**

If the air filter is not correctly mounted, dust and dirt can penetrate into the engine and can cause damage.

- Mount the air filter box lid.

### **Info**

If the air filter box lid is not correctly mounted, dust and dirt can penetrate into the engine and cause damage.

- Mount the seat. ( p. 137)

## Cleaning air filter



### Warning

**Environmental hazard** Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



### Info

Do not clean the air filter with fuel or petroleum since these substances attack the foam.

- Remove the air filter.  ( p. 147)
- Wash the air filter thoroughly in special cleaning liquid and allow it to dry properly.

Air filter cleaner ( p. 200)



### Info


Only press the air filter to dry it, never wring it out.

- Oil the dry air filter with a high/quality filter oil.

Oil for foam air filter ( p. 202)

- Clean the air filter box.
- Check carburetor connection boot for damage and tightness.
- Install the air filter.  ( p. 149)

## Adjusting basic position of clutch lever



601065-10

- Adjust the basic setting of the clutch lever to your hand size by turning adjusting screw ❶.

### **i** Info

Turn the adjusting screw counterclockwise to increase the distance between the clutch lever and the handlebar.

Turn the adjusting screw clockwise to decrease the distance between the clutch lever and the handlebar.

The range of adjustment is limited.

Turn the adjusting screw by hand only, and do not apply any force.


Do not make any adjustments while riding!

## Checking fluid level of hydraulic clutch

### **i** Info

The fluid level rises with increasing wear of the clutch lining disc.

Do not use brake fluid.



601066-10

- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Check the fluid level.


|  |                |
|--|----------------|
| Fluid level under top level of container | 4 mm (0.16 in) |
|--|----------------|

- » If the coolant level does not meet specifications:
  - Correct the fluid level of the hydraulic clutch.

|                                 |
|---------------------------------|
| Hydraulic fluid (15) (☛ p. 198) |
|---------------------------------|

- Position the cover with the membrane. Mount and tighten screws.

## Cooling system



The water pump ❶ in the engine forces the coolant to flow.

The pressure resulting from the warming of the cooling system is regulated by a valve in the radiator cap . This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

120 °C (248 °F)

Cooling is effected by the air stream. The radiator fan provides extra cooling. The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.

## Radiator fan



The radiator fan ❶ is located on the radiator under the fuel tank.

### Working range within which radiator fan is switched on and off.

| Thermostwitch          |                |
|------------------------|----------------|
| Switch-off temperature | 80 °C (176 °F) |
| Switch-on temperature  | 85 °C (185 °F) |

## Checking the antifreeze and coolant level



### Warning

**Danger of scalding** The coolant gets very hot and is under high pressure when the vehicle is operated.

- Do not remove the radiator cap or remove radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. If you scald yourself, hold the affected area under lukewarm water immediately.



### Warning

**Danger of poisoning** Coolant is poisonous and a health hazard.

- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.

### Condition


The engine is cold.


- Park the vehicle on a horizontal surface.
- Remove the front trim. (☛ p. 141)
- Remove radiator cap ❶.
- Check the coolant antifreeze.

–25... -45 °C (-13... -49 °F)

» If the coolant antifreeze does not meet specifications:

- Correct the coolant antifreeze.





- Check the coolant level in the radiator.

|   |                 |
|---|-----------------|
| Coolant level <b>A</b> above the radiator fins. | 10 mm (0.39 in) |
|---|-----------------|

- » If the coolant level does not meet specifications:

- Correct the coolant level.

### Alternative 1

|                    |
|--------------------|
| Coolant (☛ p. 196) |
|--------------------|

### Alternative 2

|   |
|---|
| Coolant (mixed ready to use) (☛ p. 196) |
|---|

- Mount the radiator cap.
- Install the front trim. (☛ p. 142)

## Checking the coolant level



### Warning

**Danger of scalding** The coolant gets very hot and is under high pressure when the vehicle is operated.

- Do not remove the radiator cap or remove radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. If you scald yourself, hold the affected area under lukewarm water immediately.




### Warning

**Danger of poisoning** Coolant is poisonous and a health hazard.

- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.

### Condition

The engine is cold.



- Park the vehicle on a horizontal surface.
- Remove the front trim. (☞ p. 141)
- Remove the radiator cap.
- Check the coolant level in the radiator.

|   |                 |
|---|-----------------|
| Coolant level <b>A</b> above the radiator fins. | 10 mm (0.39 in) |
|---|-----------------|

- » If the coolant level does not meet specifications:
  - Correct the coolant level.

**Alternative 1**

|                    |
|--------------------|
| Coolant (☞ p. 196) |
|--------------------|

**Alternative 2**

|   |
|---|
| Coolant (mixed ready to use) (☞ p. 196) |
|---|

- Mount the radiator cap.
- Install the front trim. (☞ p. 142)

## Draining coolant ☞



**Warning**

**Danger of scalding** The coolant gets very hot and is under high pressure when the vehicle is operated.

- Do not remove the radiator cap or remove radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. If you scald yourself, hold the affected area under lukewarm water immediately.




**Warning**


**Danger of poisoning** Coolant is poisonous and a health hazard.


- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.

- Remove the front trim. (☛ p. 141)
- Place a suitable container under the vehicle.
- Remove screw ❶.



- Remove screw ❷.





- Remove the radiator cap ③. Completely drain the coolant.


## Filling coolant / bleeding cooling system ↩



### Warning

**Danger of poisoning** Coolant is poisonous and a health hazard.

- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.




- Position the vehicle as shown and secure it against rolling away. The height difference ① must be achieved.

### Guideline


|                     |                 |
|---------------------|-----------------|
| Height difference ① | 50 cm (19.7 in) |
|---------------------|-----------------|

- Pull the hand brake lever, push the locking pawl ② down and release the hand brake lever. (Figure 100006-10 ↗ p. 20)
- ✓ The front wheels are locked.



- Fill the coolant into the radiator ❶.

|         |                   |   |
|---------|-------------------|---|
| Coolant | 1.30 l (1.37 qt.) | Coolant (☛ p. 196)                      |
|         |                   | Coolant (mixed ready to use) (☛ p. 196) |




- Open the screw ❷ to bleed the cylinder head. Tighten the screw ❷ when coolant emerges from the opening.

Guideline

|                           |    |                    |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|

**i** Info


Ensure that the radiator is always filled with a sufficient amount of coolant.



- Open the screw ❸ to bleed the radiator. Tighten the screw ❸ when coolant emerges from the opening.


Guideline

|                           |    |                    |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|



- Completely fill the radiator and close the radiator cap ④.
- Place the vehicle on the ground.
- Install the front trim. (☛ p. 142)
- Make a short test ride.
- Check the coolant level. (☛ p. 154)

## Carburetor - idle



The idle setting of the carburetor has a big influence on the starting behavior, stable idling and the response to throttle opening. That means that an engine with a correctly set idle speed is easier to start than if the idle is set wrongly.



### Info


The carburetor and its components are subject to increased wear caused by engine vibration. Wear can result in malfunctioning.

If the idle speed is set significantly higher, the engine does not start. When the electric starter button is activated, the electric starter turns over the engine, but the engine does not start because there is no ignition spark.

The idle speed is adjusted with the adjustment screw ②.

The idle mixture is adjusted with the idle mixture adjustment screw ①.

## Carburetor - adjusting idle



- Screw in the idle adjusting screw ❶ until it stops and then to the prescribed basic setting.

### Guideline

|                              |           |
|------------------------------|-----------|
| Idle mixture adjusting screw |           |
| Open                         | 1.5 turns |

|   |  |
|---|--|
| Adjustment tool for mixture control screw (59029034000) |  |
|---|--|

- Run the engine until warm.

### Guideline

|              |         |
|--------------|---------|
| Warm-up time | ≥ 5 min |
|--------------|---------|

- Adjust the idle speed with the adjusting screw ❷.

### Guideline

|  |                    |
|--|--------------------|
| Choke function deactivated – The choke lever is pushed in to the stop. (☛ p. 45) |                    |
| Idle speed   | 1,500... 1,600 rpm |

### Info

If the idle speed is set significantly higher, the engine does not start. When the electric starter button is activated, the electric starter turns over the engine, but the engine does not start because there is no ignition spark.

- Turn the idle mixture control screw ❶ slowly clockwise until the idle speed begins to fall.
- Note the position and turn the idle adjusting screw slowly counterclockwise until the idle speed falls.
- Adjust to the point between these two positions with the highest idle speed.

---

**i** **Info**

If there is a large increase in the engine speed, reduce the idle speed to a normal level and repeat the above steps.

The extremely sporty rider will set the mixture about 1/4 of a turn back from this ideal value (leaner, clockwise) since the engine has a higher operating temperature in sporting use.

If the procedure described here does not lead to satisfactory results, the cause may be a wrongly dimensioned idling jet.

If you can turn the idle adjusting screw to the end without any change of engine speed, you have to fit a smaller idling jet.

The idle adjusting screw must not be opened more than two turns. If more than two turns are necessary (rich mixture), use a larger idling jet.

After changing the idling jet, start from the beginning with the adjusting steps.

---

- Adjust the idle speed with the adjusting screw ②.

**Guideline**

|  |  |
|--|--|
| Choke function deactivated – The choke lever is pushed in to the stop. (☛ p. 45) |  |
|--|--|

|            |                    |
|------------|--------------------|
| Idle speed | 1,500... 1,600 rpm |
|------------|--------------------|

---

**i** **Info**

Following extreme air temperature or altitude changes, adjust the idle speed again.

---

## Emptying the carburetor float chamber ↩



### Danger

**Fire hazard** Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.



### Warning

**Danger of poisoning** Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.



### Warning

**Environmental hazard** Improper handling of fuel is a danger to the environment.


- Do not allow fuel to get into the ground water, the ground, or the sewage system.



### Info

Carry out this work with a cold engine.

- Turn the handle ❶ of the fuel tap to **OFF**. (Figure 100013-10 ↩ p. 44)
  - ✓ No more fuel flows from the tank to the carburetor.



- Guide the hose coming down behind the engine into a suitable container.

**Info**


Water in the float chamber results in malfunctioning.

- Undo the screw ❶ (turn it counterclockwise) a few turns and drain the fuel from the float chamber.
- Tighten screw ❶.

## Checking the engine oil level

**Info**

The engine oil level can be checked on a cold or hot engine.



- Park the vehicle on a horizontal surface.

**Condition**

The engine is at operating temperature.


- Check the engine oil level.

**Info**

After switching off the engine, wait one minute before checking the level.

The engine oil reaches the middle of the viewer **A**.

- » When the engine oil does not reach the middle of the viewer **A**:
  - Add engine oil. (🔧 p. 171)



## Condition

The engine is cold.

- Check the engine oil level.

The engine oil reaches the bottom of the viewer **B**.

- » When the engine oil does not reach the bottom of the viewer **B**:
  - Add engine oil. (☞ p. 171)

## Changing engine oil and oil filter, cleaning oil screens ☞



- Drain engine oil, clean oil screens. ☞ (☞ p. 164)
- Remove the oil filter. ☞ (☞ p. 168)
- Install the oil filter. ☞ (☞ p. 170)
- Fill up with engine oil. ☞ (☞ p. 170)

## Draining engine oil, cleaning oil screens ☞



### Warning

**Danger of scalding** Engine oil and gear oil get very hot when the vehicle is driven.

- Wear suitable protective clothing and gloves. If you scald yourself, hold the affected area under lukewarm water immediately.



## Warning

**Environmental hazard** Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




## Info

Drain the engine oil only when the engine is warm.


- Park the vehicle on a horizontal surface.
- Remove the engine guard. (☛ p. 146)
- Place a suitable container under the engine.
- Remove the oil drain plug ❶.




600134-10



- Remove the plug screw ② and small oil screen with both O-rings.




- Remove the plug screw ③ and large oil screen with both O-rings.
- Completely drain the engine oil.



- Thoroughly clean parts and sealing area.
- Oil O-rings ⑤, mount them on oil screen ④ and, using a long hexagon key, insert them until the O-ring is seated in the housing ⑥ with the oil screen.
- Fit plug screw ⑦ with the seal ring and tighten it.

Guideline


|                                |         |                        |
|--------------------------------|---------|------------------------|
| Locking screw, oil sieve, long | M20x1.5 | 15 Nm<br>(11.1 lbf ft) |
|--------------------------------|---------|------------------------|




- Insert oil screen ⑧ with O-rings ⑨ into plug screw ⑩ and tighten.

Guideline

|                                 |         |                       |                            |
|---------------------------------|---------|-----------------------|----------------------------|
| Locking screw, oil sieve, short | M16x1.5 | 10 Nm<br>(7.4 lbf ft) | lubricated with engine oil |
|---------------------------------|---------|-----------------------|----------------------------|





- Fit oil drain plug 11 with the seal ring and tighten it.

Guideline

|                            |         |                        |
|----------------------------|---------|------------------------|
| Oil drain plug with magnet | M12x1.5 | 20 Nm<br>(14.8 lbf ft) |
|----------------------------|---------|------------------------|

- Install the engine guard. (☞ p. 146)

## Removing the oil filter ☞



**Warning**

**Danger of scalding** Engine oil and gear oil get very hot when the vehicle is driven.

- Wear suitable protective clothing and gloves. If you scald yourself, hold the affected area under lukewarm water immediately.




**Warning**


**Environmental hazard** Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

- Place a suitable container under the engine.



- Disconnect the ground cable **A** from the engine.
- Remove screws **1** and **2**. Take off the oil filter cover with the O-ring.




- Pull the oil filters **3** and **4** out of the engine housing.


Circlip pliers reverse (51012011000)

- Completely drain the engine oil.
- Thoroughly clean parts and sealing area.

## Installing the oil filter ↴



- Fill oil filters ③ and ④ with engine oil and insert them in the oil filter housing.



- Oil the O-rings of the oil filter covers and mount them with the oil filter covers. Mount and tighten screws ① and ②.

### Guideline

|                         |    |                   |
|-------------------------|----|-------------------|
| Screw, oil filter cover | M5 | 6 Nm (4.4 lbf ft) |
|-------------------------|----|-------------------|


- Connect ground cable ① on the engine and tighten the screw.

### Guideline

|                       |    |                    |
|-----------------------|----|--------------------|
| Screw, starter engine | M6 | 10 Nm (7.4 lbf ft) |
|-----------------------|----|--------------------|

## Filling up with engine oil ↴

- Info**  
Too little engine oil or poor-quality engine oil results in premature wear to the engine.



600132-10

- Remove the screw cap ❶ on the clutch cover and fill up with engine oil.

|            |                   |   |                                       |
|------------|-------------------|---|---------------------------------------|
| Engine oil | 2.00 l (2.11 qt.) | External temperature:<br>≥ 0 °C (≥ 32 °F) | Engine oil (SAE 10W/50)<br>(☛ p. 197) |
|            |                   | External temperature:<br>< 0 °C (< 32 °F) | Engine oil (SAE 5W/40) (☛ p. 197)     |

- Mount and tighten screw cap ❶.



## Danger

**Danger of poisoning** Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and check that it is oil-tight.

### Guideline

|  |
|--|
| Switch off the engine when the radiator fan switches on. |
|--|


- Check the engine oil level. (☛ p. 163)

## Adding engine oil



### Info

A lack of engine oil or poor-quality engine oil results in premature wear to the engine.



- Check the engine for leakage.
- Remove the filler cap ❶ on the clutch cover and fill up with engine oil.

**Condition**

External temperature:  $\geq 0$  °C ( $\geq 32$  °F)

Engine oil (SAE 10W/50) (☛ p. 197)

**Condition**

External temperature:  $< 0$  °C ( $< 32$  °F)

Engine oil (SAE 5W/40) (☛ p. 197)

**Info**

To ensure optimal engine oil performance, it is advisable to not use different engine oils.

We recommend making an oil change in this case.

- Mount and tighten filler cap ❶.

| Faults                           | Possible cause   | Action  |
|----------------------------------|--|---|
| Engine turns but does not start. | Operating error  | <ul style="list-style-type: none"> <li>– Follow the instructions on starting the engine. (☛ p. 52)</li> </ul>   |
|                                  | Vehicle was out of use for a long time and there is old fuel in the float chamber  | <ul style="list-style-type: none"> <li>– Empty the carburetor float chamber. ☛ (☛ p. 162)</li> </ul>  |
|                                  | Fuel supply interrupted  | <ul style="list-style-type: none"> <li>– Check the fuel tank breather.</li> <li>– Clean the fuel tap.</li> <li>– Check/adjust the carburetor components. ☛</li> </ul> |
|                                  | Spark plug oily or wet   | <ul style="list-style-type: none"> <li>– Clean and dry spark plug or replace if necessary.</li> </ul>   |
|                                  | Electrode distance (plug gap) of spark plug too wide   | <ul style="list-style-type: none"> <li>– Adjust the plug gap.<br/>Guideline<br/>Spark plug electrode gap<br/>0.6 mm (0.024 in)</li> </ul>                             |
|                                  | Fault in ignition system   | <ul style="list-style-type: none"> <li>– Check the ignition system. ☛</li> </ul>  |
|                                  | Socket connector of CDI control device, pulse generator or ignition coil oxidized  | <ul style="list-style-type: none"> <li>– Clean the plug-in connector and treat it with contact spray.</li> </ul>  |
|                                  | Water in carburetor or jets blocked  | <ul style="list-style-type: none"> <li>– Check/adjust the carburetor components. ☛</li> </ul>   |
|                                  | Idle speed is set too high   | <ul style="list-style-type: none"> <li>– Carburetor - adjust the idle speed. ☛ (☛ p. 160)</li> </ul>  |
|                                  | Emergency OFF switch with rip cord faulty  | <ul style="list-style-type: none"> <li>– Check the wiring harness. (visual check)</li> <li>– Check the electrical system.</li> </ul>                                  |
| Throttle lever activated         | <ul style="list-style-type: none"> <li>– Do not activate the throttle lever.</li> <li>– Follow the instructions on starting the engine. (☛ p. 52)</li> </ul> |   |

| Faults                                      | Possible cause   | Action  |
|---|--|---|
| Engine turns but does not start.            | Switch for throttle lever faulty                           | <ul style="list-style-type: none"> <li>– Check the wiring harness. (visual check)</li> <li>– Check the electrical system.</li> </ul>  |
|   | Throttle valve sensor incorrectly set or faulty            | <ul style="list-style-type: none"> <li>– Check the throttle position sensor. 🛠️</li> </ul>  |
|   | Blown fuse   | <ul style="list-style-type: none"> <li>– Change the fuses of individual power consumers. (🔧 p. 133)</li> </ul>  |
| Engine cannot be cranked (electric starter) | Operating error  | <ul style="list-style-type: none"> <li>– Follow the instructions on starting the engine. (🔧 p. 52)</li> </ul>   |
|   | Battery discharged   | <ul style="list-style-type: none"> <li>– Recharge the battery. 🛠️ (🔧 p. 130)</li> <li>– Check the charging voltage. 🛠️</li> <li>– Check the quiescent current. 🛠️</li> <li>– Check the alternator. 🛠️</li> </ul>  |
|   | Blown fuse   | <ul style="list-style-type: none"> <li>– Change the main fuse. (🔧 p. 132)</li> </ul>  |
|   | Start relay faulty   | <ul style="list-style-type: none"> <li>– Check the starter relay. 🛠️</li> </ul>   |
|   | Starter motor faulty                                       | <ul style="list-style-type: none"> <li>– Check the starter motor. 🛠️</li> </ul>   |
| Engine does not speed up                    | Carburetor running over because float needle dirty or worn | <ul style="list-style-type: none"> <li>– Check/adjust the carburetor components. 🛠️</li> </ul>  |
|   | Loose carburetor jets                                      | <ul style="list-style-type: none"> <li>– Check/adjust the carburetor components. 🛠️</li> </ul>  |
|   | Ignition system defective                                  | <ul style="list-style-type: none"> <li>– Check the spark plug connector. 🛠️</li> <li>– Check the ignition coil. 🛠️</li> <li>– Check the ignition pulse generator. 🛠️</li> <li>– Check the alternator. 🛠️</li> <li>– Check the CDI controller. 🛠️</li> </ul> |
| Engine has no idle.                         | Idling jet blocked   | <ul style="list-style-type: none"> <li>– Check/adjust the carburetor components. 🛠️</li> </ul>  |

| Faults  | Possible cause                           | Action   |
|---|--|--|
| Engine has no idle.                                 | Adjusting screws on carburetor distorted | <ul style="list-style-type: none"> <li>- Carburetor - adjust the idle speed.  (  p. 160)</li> </ul>  |
|   | Spark plug defective                     | <ul style="list-style-type: none"> <li>- Change spark plug.</li> </ul>   |
|   | Ignition system defective                | <ul style="list-style-type: none"> <li>- Check the spark plug connector. </li> <li>- Check the ignition coil. </li> <li>- Check the ignition pulse generator. </li> <li>- Check the alternator. </li> <li>- Check the CDI controller. </li> </ul> |
| Engine stalls or is backfiring into the carburetor. | Lack of fuel                             | <ul style="list-style-type: none"> <li>- Turn the handle  of the fuel tap to <b>ON</b>. (Figure 100013-10  p. 44)</li> <li>- Fill up with fuel. (  p. 65)</li> </ul>  |
|   | Intake system air leak                   | <ul style="list-style-type: none"> <li>- Check rubber sleeves and carburetor for tightness.</li> </ul>   |
|   | Loose contact or oxidized connector      | <ul style="list-style-type: none"> <li>- Check the electrical system.</li> <li>- Clean the plug-in connector and treat it with contact spray.</li> </ul>   |
| Engine overheats.                                   | Coolant level low                        | <ul style="list-style-type: none"> <li>- Check the cooling system for leakage.</li> <li>- Check the coolant level. (  p. 154)</li> </ul>  |
|   | Radiator fins excessively dirty          | <ul style="list-style-type: none"> <li>- Clean radiator fins.</li> </ul>   |
|   | Foam formation in cooling system         | <ul style="list-style-type: none"> <li>- Drain the coolant.  (  p. 155)</li> <li>- Fill coolant/bleed cooling system.  (  p. 157)</li> </ul>   |
|   | Bent radiator hose                       | <ul style="list-style-type: none"> <li>- Change the radiator hose. </li> </ul>  |
|   | Thermostat defective                     | <ul style="list-style-type: none"> <li>- Check the thermostat. </li> </ul>  |
|   | Radiator fan system faulty               | <ul style="list-style-type: none"> <li>- Check the radiator fan system. </li> </ul>   |

| Faults   | Possible cause   | Action  |
|--|--|---|
| Engine has a lack of power                         | Fuel supply interrupted  | <ul style="list-style-type: none"> <li>– Check the fuel tank breather.</li> <li>– Clean the fuel tap.</li> <li>– Check/adjust the carburetor components. 🛠️</li> </ul>  |
|  | Air filter excessively dirty   | <ul style="list-style-type: none"> <li>– Clean the air filter. 🛠️ (📖 p. 150)</li> </ul>   |
|  | Exhaust system leaky, deformed or too little glass fiber yarn filling in main silencer | <ul style="list-style-type: none"> <li>– Check exhaust system for damage.</li> </ul>  |
|  | Valve clearance too little   | <ul style="list-style-type: none"> <li>– Adjust the valve clearance. 🛠️</li> </ul>  |
|  | Ignition system defective  | <ul style="list-style-type: none"> <li>– Check the spark plug connector. 🛠️</li> <li>– Check the ignition coil. 🛠️</li> <li>– Check the ignition pulse generator. 🛠️</li> <li>– Check the alternator. 🛠️</li> <li>– Check the CDI controller. 🛠️</li> </ul> |
| High oil consumption                               | Engine vent hose bent  | <ul style="list-style-type: none"> <li>– Route the vent hose without bends or replace it if necessary.</li> </ul>   |
|  | Engine oil level too high  | <ul style="list-style-type: none"> <li>– Check the engine oil level. (📖 p. 163)</li> </ul>  |
|  | Engine oil too thin (low viscosity)  | <ul style="list-style-type: none"> <li>– Change the engine oil and oil filter, clean the oil screens. 🛠️ (📖 p. 164)</li> </ul>  |
|  | Piston or cylinder worn  | <ul style="list-style-type: none"> <li>– Check the piston/cylinder mounting clearance. 🛠️</li> </ul>  |
| Parts of the electrical system are not functional. | Fault in the electrical system   | <ul style="list-style-type: none"> <li>– Change the fuses of individual power consumers. (📖 p. 133)</li> <li>– Check the electrical system.</li> </ul>  |
| Battery discharged                                 | Battery is not charged by alternator   | <ul style="list-style-type: none"> <li>– Check the charging voltage. 🛠️</li> <li>– Check the alternator. 🛠️</li> </ul>  |

| <b>Faults</b>  | <b>Possible cause</b>                    | <b>Action</b>  |
|--|--|--|
| Battery discharged                                       | Undesired power consumer                 | – Check the quiescent current.  |
| Speedometer values deleted (time, stop watch, lap times) | The battery in the speedometer is empty. | – Change the battery in the speedometer.   |

## Cleaning the vehicle

### Note

**Material damage** Damage and destruction of components by high-pressure cleaning equipment.

- Never clean the vehicle with high-pressure cleaning equipment or a strong water-jet. The excessive pressure can penetrate electrical components, socket connects, throttle cables, and bearings, etc., and can damage or destroy these parts.



### Warning

**Environmental hazard** Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



### Info

If you clean the vehicle regularly, its value and appearance are maintained over a long period.  
Avoid direct sunshine on the vehicle during cleaning.



### Info

Do not place the vehicle onto the rear frame bracket to clean it since it could fall over.  
Never raise the vehicle on your own, even if a gear is engaged.  
Fuel can leak out of the fuel tank.

- Close off the exhaust system to prevent water from entering.
- First remove coarse dirt particles with a gentle spray of water.
- Spray very dirty areas with a normal motorcycle cleaner and then clean with a brush.

Motorcycle cleaner (🔑 p. 201)



### Info

Use warm water containing normal motorcycle cleaner and a soft sponge.

- After rinsing the vehicle with a gentle spray of water, allow it to dry thoroughly.
- Clean and dry the air filter box.
- Empty the carburetor float chamber. 🛠️ (📖 p. 162)



## Warning

**Danger of accidents** Reduced braking efficiency due to wet or dirty brakes.

- Clean or dry dirty or wet brakes by riding and braking gently.

- After cleaning, take a short ride until the engine reaches operating temperature.



## Info

The heat produced causes water at inaccessible locations in the engine and the brakes to evaporate.

- Push back the protection covers from the handlebar armatures to allow any water that may have entered there to evaporate.
- After the vehicle has cooled off, oil or grease all moving parts and bearings.
- Clean the chain. (🛠️ p. 99)
- Treat bare metal parts (except for brake discs and exhaust system) with a corrosion inhibitor.

Cleaning and polishing materials for metal, rubber and plastic (📖 p. 200)

- Treat all plastic parts and powder-coated parts with a mild cleaning and care product.

Cleaning and polishing materials for metal, rubber and plastic (📖 p. 200)

- To prevent electrical problems, treat electric contacts and switches with contact spray.

Contact spray (🛠️ p. 201)

- Oil the steering lock.

Universal oil spray (🛠️ p. 202)

## Storage



### Warning

**Danger of poisoning** Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.



### Info

If you want to store the vehicle for a longer period, take the following actions.



### Info

Before storing the vehicle, check all parts for function and wear. If service, repairs or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.

- Clean the vehicle. (🔧 p. 178)
- Change the engine oil and oil filter, clean the oil screens. 🛢️ (🔧 p. 164)
- Check the antifreeze and coolant level. (🔧 p. 153)
- Drain the fuel from the tank into a suitable container.
- Empty the carburetor float chamber. 🛢️ (🔧 p. 162)
- Check the tire air pressure. (🔧 p. 128)
- Remove the battery. (🔧 p. 129)
- Recharge the battery. 🛢️ (🔧 p. 130)

## Guideline

|  |                          |
|--|--------------------------|
| Storage temperature of battery without direct sunshine | 0... 35 °C (32... 95 °F) |
|--|--------------------------|

- Store the vehicle in a dry location that is not subject to large fluctuations in temperature.
- Cover the vehicle with a tarp or cover that is permeable to air.



## Info

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion. Avoid running the engine of a vehicle in storage for a short time only. Because the engine will not warm up sufficiently, the water vapor produced during combustion will condense, causing engine parts and the exhaust system to rust.

## Putting the vehicle into operation after storage

- Install the battery. (🔧 p. 130)
- Fill up with fuel. (🔧 p. 65)
- Checks before putting into operation (🔧 p. 51)
- Make a cautious test ride.

|                                |  |
|--------------------------------|--|
| Design                         | 1-cylinder 4-stroke engine with balancer, water-cooled                                     |
| Displacement                   | 510 cm <sup>3</sup> (31.12 cu in)  |
| Stroke                         | 72 mm (2.83 in)  |
| Bore                           | 95 mm (3.74 in)  |
| Compression ratio              | 11:1   |
| Idle speed                     | 1,500... 1,600 rpm   |
| Control                        | 4 valves controlled via rocker arm and overhead camshaft, camshaft drive via simplex chain |
| Valve diameter, intake         | 35 mm (1.38 in)  |
| Valve diameter, exhaust        | 30 mm (1.18 in)  |
| Valve clearance, cold, intake  | 0.10... 0.15 mm (0.0039... 0.0059 in)  |
| Valve clearance, cold, exhaust | 0.10... 0.15 mm (0.0039... 0.0059 in)  |
| Crankshaft bearing             | 2 cylinder roller bearing  |
| Conrod bearing                 | Needle bearing   |
| Piston pin bearing             | Bronze bush  |
| Pistons                        | Forged light alloy   |
| Piston rings                   | 1 compression ring, 1 oil scraper ring   |
| Engine lubrication             | Pressure circulation lubrication with 2 rotor pumps  |
| Primary transmission           | 31:78 straight tooth spur gears  |
| Clutch                         | Multidisc clutch in oil bath / hydraulically activated                                     |
| Transmission ratio             |  |
| 1st gear                       | 14:35  |
| 2nd gear                       | 17:33  |
| 3rd gear                       | 19:30  |
| 4th gear                       | 21:28  |

|                          |   |
|--------------------------|---|
| 5th gear                 | 23:26   |
| Generator                | 12 V, 200 W   |
| Ignition                 | Contactless controlled fully electronic ignition with digital ignition adjustment, type Kokusan |
| Spark plug               | NGK DCPR 8 E  |
| Spark plug electrode gap | 0.6 mm (0.024 in)   |
| Cooling                  | Water cooling, permanent circulation of coolant by water pump                                   |
| Starting aid             | Electric starter  |

## Capacity - engine oil

|            |                   |   |                                       |
|------------|-------------------|---|---------------------------------------|
| Engine oil | 2.00 l (2.11 qt.) | External temperature: $\geq 0\text{ }^{\circ}\text{C}$<br>( $\geq 32\text{ }^{\circ}\text{F}$ ) | Engine oil (SAE 10W/50)<br>(☛ p. 197) |
|            |                   | External temperature: $< 0\text{ }^{\circ}\text{C}$<br>( $< 32\text{ }^{\circ}\text{F}$ )       | Engine oil (SAE 5W/40)<br>(☛ p. 197)  |

## Capacity - coolant

|         |                   |   |
|---------|-------------------|---|
| Coolant | 1.30 l (1.37 qt.) | Coolant (☛ p. 196)                      |
|         |                   | Coolant (mixed ready to use) (☛ p. 196) |

# TECHNICAL DATA - ENGINE TIGHTENING TORQUES

|  |              |                    |                      |
|--|--------------|--------------------|----------------------|
| Screw, cable holder in generator cover | M4           |                    | <b>Loctite® 243™</b> |
| Locking screw for bearing              | M5           | 6 Nm (4.4 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, gear sensor                     | M5           | 6 Nm (4.4 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, ignition pulse generator        | M5           | 6 Nm (4.4 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, locking lever                   | M5           | 6 Nm (4.4 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, locking shaft lever             | M5           | 6 Nm (4.4 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, oil filter cover                | M5           | 6 Nm (4.4 lbf ft)  | –                    |
| Screw, oil pump cover                  | M5           | 6 Nm (4.4 lbf ft)  | <b>Loctite® 222</b>  |
| Screw, rocker arm shaft                | M5           | 6 Nm (4.4 lbf ft)  | –                    |
| Screw, stator bracket                  | M5           | 6 Nm (4.4 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, timing chain securing guide     | M5           | 6 Nm (4.4 lbf ft)  | <b>Loctite® 243™</b> |
| Screw on cylinder head top section     | M6x45        | 10 Nm (7.4 lbf ft) | –                    |
| Screw on cylinder head top section     | M6x50        | 10 Nm (7.4 lbf ft) | –                    |
| Screw on cylinder head top section     | M6x55 – 10.9 | 10 Nm (7.4 lbf ft) | –                    |
| Screw on cylinder head top section     | M6x75        | 10 Nm (7.4 lbf ft) | –                    |
| Screw, bearing stud, starter engine    | M6           | 10 Nm (7.4 lbf ft) | <b>Loctite® 243™</b> |
| Screw, clutch cover                    | M6           | 10 Nm (7.4 lbf ft) | –                    |
| Screw, clutch spring                   | M6           | 8 Nm (5.9 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, cylinder head                   | M6           | 10 Nm (7.4 lbf ft) | –                    |
| Screw, cylinder head top section       | M6x30        | 10 Nm (7.4 lbf ft) | –                    |
| Screw, drive wheel for balancer        | M6           | 10 Nm (7.4 lbf ft) | <b>Loctite® 243™</b> |
| Screw, engine housing                  | M6x30        | 10 Nm (7.4 lbf ft) | –                    |
| Screw, engine housing                  | M6x45        | 10 Nm (7.4 lbf ft) | –                    |
| Screw, engine housing                  | M6x60        | 10 Nm (7.4 lbf ft) | –                    |

# TECHNICAL DATA - ENGINE TIGHTENING TORQUES

|                                       |         |  |                      |
|---------------------------------------|---------|--|----------------------|
| Screw, engine housing                 | M6x65   | 10 Nm (7.4 lbf ft)   | –                    |
| Screw, engine housing                 | M6x75   | 10 Nm (7.4 lbf ft)   | –                    |
| Screw, exhaust flange                 | M6      | 10 Nm (7.4 lbf ft)   | <b>Loctite® 243™</b> |
| Screw, shift drum locating            | M6      | 10 Nm (7.4 lbf ft)   | <b>Loctite® 243™</b> |
| Screw, shift lever                    | M6      | 10 Nm (7.4 lbf ft)   | <b>Loctite® 243™</b> |
| Screw, starter engine                 | M6      | 10 Nm (7.4 lbf ft)   | –                    |
| Screw, timing chain guide rail        | M6      | 6 Nm (4.4 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, timing chain tensioning rail   | M6      | 6 Nm (4.4 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, timing-chain tensioner         | M6      | 10 Nm (7.4 lbf ft)   | –                    |
| Screw, valve cover                    | M6      | 10 Nm (7.4 lbf ft)   | –                    |
| Screw, vent hose bracket              | M6      | 10 Nm (7.4 lbf ft)   | <b>Loctite® 243™</b> |
| Screw, water pump cover               | M6      | 10 Nm (7.4 lbf ft)   | –                    |
| Nut, adjusting screw, valve clearance | M6x0.75 | 11 Nm (8.1 lbf ft)   | –                    |
| Oil jet, piston cooling               | M6x0.75 | 4 Nm (3 lbf ft)  | <b>Loctite® 243™</b> |
| Banjo bolt, oil line                  | M8      | 10 Nm (7.4 lbf ft)   | –                    |
| Jet screw, oil line                   | M8      | 10 Nm (7.4 lbf ft)   | –                    |
| Plug, crankshaft location             | M8      | 10 Nm (7.4 lbf ft)   | –                    |
| Plug, timing chain tensioner          | M8      | 10 Nm (7.4 lbf ft)   | –                    |
| Screw, camshaft gear                  | M8      | 28 Nm (20.7 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, generator cover                | M8      | 10 Nm (7.4 lbf ft)   | –                    |
| Screw, cylinder head                  | M10     | Step 1<br>40 Nm (29.5 lbf ft)<br>Step 2<br>50 Nm (36.9 lbf ft) | –                    |
| Screw, engine sprocket                | M10     | 60 Nm (44.3 lbf ft)  | <b>Loctite® 243™</b> |

# TECHNICAL DATA - ENGINE TIGHTENING TORQUES

|   |           |                       |                            |
|---|-----------|-----------------------|----------------------------|
| Ignition rotor nut                                    | M12x1     | 60 Nm (44.3 lbf ft)   | –                          |
| Spark plug  | M12x1.25  | 17 Nm (12.5 lbf ft)   | –                          |
| Bleeder flange, engine case                           | M12x1.5   |                       | <b>Loctite® 243™</b>       |
| Oil drain plug with magnet                            | M12x1.5   | 20 Nm (14.8 lbf ft)   | –                          |
| Plug, oil pressure regulator valve                    | M12x1.5   | 20 Nm (14.8 lbf ft)   | –                          |
| Locking screw, oil sieve, short                       | M16x1.5   | 10 Nm (7.4 lbf ft)    | lubricated with engine oil |
| Nut, inner clutch hub                                 | M18x1.5   | 120 Nm (88.5 lbf ft)  | <b>Loctite® 243™</b>       |
| Locking screw, oil sieve, long                        | M20x1.5   | 15 Nm (11.1 lbf ft)   | –                          |
| Nut, primary gear                                     | M20LHx1.5 | 150 Nm (110.6 lbf ft) | <b>Loctite® 243™</b>       |
| Screw-in fitting, cooling system in cylinder head top | M20x1.5   |                       | <b>Loctite® 577</b>        |

|                                  |                        |
|----------------------------------|------------------------|
| Carburetor type                  | KEIHIN FCR-MX 41       |
| Carburetor identification number | 4125L                  |
| Needle position                  | 3 th position from top |
| Idle mixture adjusting screw     |                        |
| Open                             | 1.5 turns              |
| Pump membrane stop               | 2.15 mm (0.0846 in)    |
| Main jet                         | 175                    |
| Jet needle                       | OBEKR                  |
| Idling jet                       | 42                     |
| Main air jet                     | 200                    |
| Idle air jet                     | 100                    |
| Cold start jet                   | 85                     |
| Throttle slide                   | 15                     |

|                           |   |
|---------------------------|---|
| Frame                     | Double cradle of chromium molybdenum steel tubes, powder-coated |
| Wheel suspension          |   |
| Front                     | Single wheel suspension with double transverse control arm      |
| Rear                      | Rigid axle  |
| Suspension travel         |   |
| Front                     | 275 mm (10.83 in)   |
| Rear                      | 272 mm (10.71 in)   |
| Fork offset               |   |
| Front                     | 46 mm (1.81 in)   |
| Toe                       |   |
| Front                     | 0 mm (0 in)   |
| Camber                    |   |
| Front                     | 0°  |
| Toe width                 |   |
| Front                     | 1,115 mm (43.9 in)  |
| Rear                      | 1,148 mm (45.2 in)  |
| Wheelbase                 | 1,280±10 mm (50.39±0.39 in)                                     |
| Turning radius            | 5,625 mm (221.46 in)  |
| Fording depth             | 330 mm (12.99 in)   |
| Seat height unloaded      | 820 mm (32.28 in)   |
| Ground clearance unloaded | 290 mm (11.42 in)   |
| Weight                    |   |
| Fuel tank empty           | 168 kg (370 lb.)  |
| Fuel tank full            | 176 kg (388 lb.)  |

|                                    |  |
|------------------------------------|--|
| Maximum allowable axle load        |  |
| Front                              | 160 kg (353 lb.)   |
| Rear                               | 190 kg (419 lb.)   |
| Maximum permissible overall weight | 335 kg (739 lb.)   |
| Vehicle length                     | 1,810 mm (71.26 in)  |
| Vehicle width                      | 1,148 mm (45.2 in)   |
| Vehicle height                     | 1,125 mm (44.29 in)  |
| Brake system                       |  |
| Front                              | Disc brakes, brake calipers fixed, 4 brake pistons per brake caliper |
| Rear                               | Disc brake, brake caliper floating, 1 brake piston                   |
| Brake discs - diameter             |  |
| Front                              | 180 mm (7.09 in)   |
| Rear                               | 200 mm (7.87 in)   |
| Brake discs - wear limit           |  |
| Front                              | 3.5 mm (0.138 in)  |
| Rear                               | 3.5 mm (0.138 in)  |
| Tire air pressure                  | 1.0 bar (15 psi)   |
| Rim                                |  |
| Front                              | 5x10" DWT Al 6061  |
| Rear                               | 8x9" DWT Al 6061   |
| Rear wheel gearing                 | 15:37  |
| Chain                              | 5/8 x 1/4"   |
| Rear sprockets available           | 37, 38, 39   |

|         |          |   |
|---------|----------|---|
| Battery | YTX5L-BS | Battery voltage: 12 V<br>Nominal capacity: 4 Ah<br>maintenance-free |
|---------|----------|---|

## Lighting equipment

|                    |                      |                 |
|--------------------|----------------------|-----------------|
| Headlight          | S2/socket BA20d      | 12 V<br>35/35 W |
| Parking light      | W5W/socket W2.1x9.5d | 12 V<br>5 W     |
| Indicator lights   | W1.2W/socket W1x4.6d | 12 V<br>1.2 W   |
| Turn signal        | R10W/socket BA15s    | 12 V<br>10 W    |
| Brake / tail light | LED                  |                 |
| License plate lamp | W5W/socket W2.1x9.5d | 12 V<br>5 W     |

## Tires

| Front tire   | Rear tire                                    |
|--|--|
| <b>AT21 x 7-10 25N TL</b><br>Kenda K572 ROADGO   | <b>20 x 11-9 38N TL</b><br>Kenda K572 ROADGO |
| Additional information is available in the Service section under:<br><a href="http://www.ktm.com">http://www.ktm.com</a> |  |

## Capacity - fuel

|                                  |                      |  |
|----------------------------------|----------------------|--|
| Total fuel tank capacity approx. | 13.5 l (3.57 US gal) | Super unleaded (ROZ 95 / RON 95 / PON 91) (☛ p. 199) |
| Fuel reserve approx.             | 3 l (3 qt.)          |  |

|                                 |  |
|---------------------------------|--|
| Shock absorber part number      | 03.18.7J.13  |
| Shock absorber                  | <b>WP Suspension</b> 3612 BAVP MCC   |
| Compression damping             |  |
| Comfort                         | 20 clicks  |
| Standard                        | 15 clicks  |
| Sport                           | 15 clicks  |
| Rebound damping                 |  |
| Comfort                         | 20 clicks  |
| Standard                        | 15 clicks  |
| Sport                           | 15 clicks  |
| Cross over                      | 19 mm (0.75 in)  |
|                                 | <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  <b>Info</b><br/>                     Measured at the tension-free main spring.                 </div> |
| Spring preload                  |  |
| Comfort                         | 4 mm   |
| Standard                        | 5 mm   |
| Sport                           | 8 mm   |
| Spring rate, main spring        | 24... 29 N/mm (137... 166 lb/in)   |
| Spring rate, auxiliary spring   | 40 N/mm (228 lb/in)  |
| Spring length, main spring      | 275 mm (10.83 in)  |
| Spring length, auxiliary spring | 60 mm (2.36 in)  |
| Fitted length                   | 460 mm (18.11 in)  |
| Shock absorber oil              | Shock absorber oil (SAE 2.5) (50180342S1) (☛ p. 198)   |

# TECHNICAL DATA - REAR SHOCK ABSORBER

193

|  |  |
|--|--|
| Shock absorber part number                 | 15.18.7J.13  |
| Shock absorber                             | <b>WP Suspension</b> 4618 BAVP MCC                   |
| Compression damping                        |  |
| Comfort                                    | 20 clicks  |
| Standard                                   | 15 clicks  |
| Sport                                      | 15 clicks  |
| Rebound damping                            |  |
| Comfort                                    | 20 clicks  |
| Standard                                   | 15 clicks  |
| Sport                                      | 15 clicks  |
| Spring preload                             |  |
| Comfort                                    | 0 mm   |
| Standard                                   | 3 mm   |
| Sport                                      | 3 mm   |
| Spring rate, main spring                   |  |
| Rider weight: 65... 75 kg (143... 165 lb.) | 45 N/mm (257 lb/in)                                  |
| Rider weight: 75... 85 kg (165... 187 lb.) | 48 N/mm (274 lb/in)                                  |
| Rider weight: 85... 95 kg (187... 209 lb.) | 50 N/mm (286 lb/in)                                  |
| Spring length, main spring                 | 260 mm (10.24 in)                                    |
| Fitted length                              | 435.5 mm (17.146 in)                                 |
| Shock absorber oil                         | Shock absorber oil (SAE 2.5) (50180342S1) (☛ p. 198) |

# TECHNICAL DATA - TIGHTENING TORQUES FOR CHASSIS

|                                      |        |                     |                      |
|--------------------------------------|--------|---------------------|----------------------|
| Remaining nuts, chassis              | M6     | 15 Nm (11.1 lbf ft) | –                    |
| Remaining screws, chassis            | M6     | 10 Nm (7.4 lbf ft)  | –                    |
| Screw on fuel tank                   | M6     | 6 Nm (4.4 lbf ft)   | –                    |
| Screw, clamping nut, rear axle       | M6     | 10 Nm (7.4 lbf ft)  | –                    |
| Screw, foot brake cylinder           | M6     | 7 Nm (5.2 lbf ft)   | <b>Loctite® 243™</b> |
| Screw, rear brake caliper            | M6     | 10 Nm (7.4 lbf ft)  | <b>Loctite® 243™</b> |
| Screw, shock absorber adjusting ring | M6     | 5 Nm (3.7 lbf ft)   | –                    |
| Remaining nuts, chassis              | M8     | 30 Nm (22.1 lbf ft) | –                    |
| Remaining screws, chassis            | M8     | 25 Nm (18.4 lbf ft) | –                    |
| Screw, bearing support, steering     | M8     | 25 Nm (18.4 lbf ft) | –                    |
| Screw, front brake caliper           | M8     | 20 Nm (14.8 lbf ft) | <b>Loctite® 243™</b> |
| Screw, front brake disc              | M8     | 25 Nm (18.4 lbf ft) | <b>Loctite® 243™</b> |
| Screw, handlebar clamp               | M8     | 20 Nm (14.8 lbf ft) | –                    |
| Screw, rear brake caliper            | M8     | 20 Nm (14.8 lbf ft) | <b>Loctite® 243™</b> |
| Screw, rear brake disc               | M8     | 25 Nm (18.4 lbf ft) | <b>Loctite® 243™</b> |
| Screw, rear wheel eccentric element  | M8     | 20 Nm (14.8 lbf ft) | –                    |
| Screw, steering bridge               | M8     | 20 Nm (14.8 lbf ft) | –                    |
| Screw, subframe                      | M8     | 35 Nm (25.8 lbf ft) | <b>Loctite® 243™</b> |
| Engine bracket screw                 | M10    | 60 Nm (44.3 lbf ft) | –                    |
| Engine mounting bolt                 | M10    | 60 Nm (44.3 lbf ft) | –                    |
| Nut, handlebar support               | M10    | 45 Nm (33.2 lbf ft) | –                    |
| Remaining nuts, chassis              | M10    | 50 Nm (36.9 lbf ft) | –                    |
| Remaining screws, chassis            | M10    | 45 Nm (33.2 lbf ft) | –                    |
| Screw, A-arm bottom                  | M10x70 | 45 Nm (33.2 lbf ft) | –                    |

# TECHNICAL DATA - TIGHTENING TORQUES FOR CHASSIS

|  |                |                      |   |
|--|----------------|----------------------|---|
| Screw, A-arm top                                   | M10x52         | 45 Nm (33.2 lbf ft)  | –   |
| Screw, footrest                                    | M10            | 45 Nm (33.2 lbf ft)  | –   |
| Screw, front shock absorber                        | M10            | 45 Nm (33.2 lbf ft)  | –   |
| Screw, steering column at bottom of steering lever | M10            | 25 Nm (18.4 lbf ft)  | –   |
| Nut, ball head, A-arm top                          | M10x1.25       | 35 Nm (25.8 lbf ft)  | –   |
| Nut, rear sprocket screw                           | M10x1.25       | 45 Nm (33.2 lbf ft)  | <b>Loctite® 243™</b>  |
| Nut, tie rod end                                   | M10x1.25       | 45 Nm (33.2 lbf ft)  | –   |
| Wheel nut  | M10x1.25       | 45 Nm (33.2 lbf ft)  | –   |
| Nut, front wheel hub                               | M12            | 70 Nm (51.6 lbf ft)  | –   |
| Screw, rear bottom shock absorber                  | M12            | 70 Nm (51.6 lbf ft)  | –   |
| Screw, rear top shock absorber                     | M12            | 60 Nm (44.3 lbf ft)  | –   |
| Lock nut, tie rod, inside                          | M12LHx1.25     | 20 Nm (14.8 lbf ft)  | –   |
| Lock nut, tie rod, outside                         | M12x1.25       | 20 Nm (14.8 lbf ft)  | –   |
| Nut, A-arm top                                     | M12x1.25       | 30 Nm (22.1 lbf ft)  | –   |
| Nut, ball head, A-arm bottom                       | M12x1.5        | 40 Nm (29.5 lbf ft)  | –   |
| Nut, swingarm pivot                                | M16x1.5        | 100 Nm (73.8 lbf ft) | –   |
| Nut, rear wheel hub                                | M18x1.5        | 130 Nm (95.9 lbf ft) | –   |
| Screw, steering column, bottom                     | M20x1.5        | 40 Nm (29.5 lbf ft)  | –   |
| Screw, steering column, top                        | M20x1.5        | 25 Nm (18.4 lbf ft)  | –   |
| Clamping nut, rear axle                            | 2"-10UNS-2B-LH | 25 Nm (18.4 lbf ft)  | Only applies when using:<br>Open-end wrench accessory<br>46mm (83019010461) |

## Brake fluid DOT 4 / DOT 5.1

### According to

- DOT

### Guideline

- Use only brake fluid that complies with the specified standards (see specifications on the container) and that possesses the corresponding properties. KTM recommends **Castrol** and **Motorex®** products.

### Supplier

#### Castrol

- **RESPONSE BRAKE FLUID SUPER DOT 4**

#### Motorex®

- **Brake Fluid DOT 5.1**

## Coolant

### Guideline

- Use only suitable coolant (also in countries with high temperatures). Use of low-quality antifreeze can lead to corrosion and foaming. KTM recommends **Motorex®** products.

### Mixture ratio

|  |   |
|--|---|
| Antifreeze protection: -25... -45 °C (-13... -49 °F) | 50 % corrosion inhibitor/antifreeze<br>50 % distilled water |
|--|---|

## Coolant (mixed ready to use)

|            |                 |
|------------|-----------------|
| Antifreeze | -40 °C (-40 °F) |
|------------|-----------------|

### Supplier

#### Motorex®

- **Anti Freeze**

## Engine oil (SAE 10W/50)

### According to

- JASO T903 MA (☛ p. 203)
- SAE (☛ p. 203) (SAE 10W/50)

### Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends **Motorex®** products.

Synthetic engine oil

### Supplier

#### Motorex®

- **Cross Power 4T**

## Engine oil (SAE 5W/40)

### According to

- JASO T903 MA (☛ p. 203)
- SAE (☛ p. 203) (SAE 5W/40)

### Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends **Motorex®** products.

Synthetic engine oil

### Supplier

#### Motorex®

- **Power Synt 4T**

## Hydraulic fluid (15)

### According to

- ISO VG (15)

### Guideline

- Use only hydraulic fluid that complies with the specified standards (see specifications on the container) and that possesses the corresponding properties. KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Hydraulic Fluid 75**

## Long-life grease

### According to

- NLGI

### Guideline

- Use only grease that complies with the specified standards (see specifications on the container) and that possesses the corresponding properties. KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Fett 2000**

## Shock absorber oil (SAE 2.5) (50180342S1)

### According to

- SAE (☛ p. 203) (SAE 2.5)

### Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

## **Super unleaded (ROZ 95 / RON 95 / PON 91)**

### **According to**

- DIN EN 228 (ROZ 95 / RON 95 / PON 91)

## Air filter cleaner

### Guideline

- KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Twin Air Dirt Bio Remover**

## Chain cleaner

### Guideline

- KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Chain Clean 611**

## Chain lube for road use

### Guideline

- KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Chain Lube 622 Strong**

## Cleaning and polishing materials for metal, rubber and plastic

### Guideline

- KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Protect & Shine 645**

## Contact spray

### Guideline

- KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Accu Contact**

## Long-life grease

### Guideline

- KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Fett 2000**

## Lubricant (T625)

### Guideline

- KTM recommends **Molykote®** products.

### Supplier

#### Molykote®

- **33 Medium**

## Motorcycle cleaner

### Guideline

- KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Moto Clean 900**

## Oil for foam air filter

### Guideline

- KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Twin Air Liquid Bio Power**

## Universal oil spray

### Guideline

- KTM recommends **Motorex®** products.

### Supplier

#### Motorex®

- **Joker 440 Universal**

## JASO T903 MA

Different technical development directions required a new specification for 4-stroke motorcycles – the JASO T903 MA Standard. Earlier, engine oils from the automobile industry were used for 4-stroke motorcycles because there was no separate motorcycle specification. Whereas long service intervals are demanded for automobile engines, high performance at high engine speeds are in the foreground for motorcycle engines. With most motorcycles, the gearbox and the clutch are lubricated with the same oil as the engine. The JASO MA Standard meets these special requirements.

## SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

## A

**Accessories** . . . . . 8

### Air filter

cleaning . . . . . 150  
 installing . . . . . 149  
 removing . . . . . 147

### Antifreeze

checking . . . . . 153

## B

**Basic information on changing the chassis settings** . . . . . 72

### Battery

installing . . . . . 130  
 recharging . . . . . 130  
 removing . . . . . 129

### Brake discs

checking . . . . . 105

### Brake fluid level of front brake

checking . . . . . 107

### Brake fluid of front brake

topping up . . . . . 108

### Brake fluid of rear brake

checking . . . . . 117  
 topping up . . . . . 118

### Brake linings of front brake

changing . . . . . 113  
 checking . . . . . 110

installing . . . . . 112  
 removing . . . . . 111

### Brake linings of rear brake

changing . . . . . 124  
 checking . . . . . 120  
 installing . . . . . 122  
 removing . . . . . 121

## C

### Camber

adjusting . . . . . 90  
 checking . . . . . 90

### Carburetor

adjusting idle . . . . . 160  
 emptying the float chamber . . . . . 162  
 idle . . . . . 159

### Chain

cleaning . . . . . 99

### Chain tension

adjusting . . . . . 103  
 checking . . . . . 100

### Chain wear

checking . . . . . 102

**Chassis number** . . . . . 16

**Choke** . . . . . 45

**Cleaning** . . . . . 178-179

|   |            |
|---|------------|
| <b>Clutch</b>                                       |            |
| checking fluid level . . . . .                      | 151        |
| <b>Clutch lever . . . . .</b>                       | <b>19</b>  |
| basic position, adjusting . . . . .                 | 151        |
| <b>Coolant</b>                                      |            |
| draining . . . . .                                  | 155        |
| refilling . . . . .                                 | 157        |
| <b>Coolant level</b>                                |            |
| checking . . . . .                                  | 153-154    |
| <b>Cooling system . . . . .</b>                     | <b>152</b> |
| bleeding . . . . .                                  | 157        |
| <b>E</b>  |            |
| <b>Electric starter button . . . . .</b>            | <b>26</b>  |
| <b>Emergency OFF switch with rip cord . . . . .</b> | <b>27</b>  |
| <b>Engine</b>                                       |            |
| running in . . . . .                                | 50         |
| switching off . . . . .                             | 62         |
| <b>Engine guard</b>                                 |            |
| installing . . . . .                                | 146        |
| removing . . . . .                                  | 146        |
| <b>Engine number . . . . .</b>                      | <b>17</b>  |
| <b>Engine oil</b>                                   |            |
| adding . . . . .                                    | 171        |
| changing . . . . .                                  | 164        |
| draining . . . . .                                  | 164        |
| refilling . . . . .                                 | 170        |

|  |           |
|--|-----------|
| <b>Engine oil level</b>                  |           |
| checking . . . . .                       | 163       |
| <b>Environment . . . . .</b>             | <b>10</b> |
| <b>F</b>                                 |           |
| <b>Fender, rear</b>                      |           |
| installing . . . . .                     | 144       |
| removing . . . . .                       | 142       |
| <b>Filler cap</b>                        |           |
| closing . . . . .                        | 42        |
| opening . . . . .                        | 42        |
| <b>Filling up</b>                        |           |
| fuel . . . . .                           | 65        |
| <b>Foot brake lever . . . . .</b>        | <b>47</b> |
| basic position, adjusting . . . . .      | 116       |
| free travel, checking . . . . .          | 115       |
| <b>Front cover</b>                       |           |
| installing . . . . .                     | 140       |
| removing . . . . .                       | 140       |
| <b>Front shock absorber</b>              |           |
| compression damping, adjusting . . . . . | 73        |
| cross over, adjusting . . . . .          | 75        |
| rebound damping, adjusting . . . . .     | 74        |
| spring preload, adjusting . . . . .      | 77        |
| <b>Front trim</b>                        |           |
| installing . . . . .                     | 142       |
| removing . . . . .                       | 141       |

|                                   |    |
|-----------------------------------|----|
| <b>Fuel tap</b> . . . . .         | 44 |
| <b>Fuel, oils, etc.</b> . . . . . | 8  |

|  |     |
|--|-----|
| <b>Fuse</b>  |     |
| changing fuses of individual power consumers . . . . . | 133 |
| changing the main fuse . . . . .                       | 132 |

## H

|                                     |           |
|-------------------------------------|-----------|
| <b>Hand brake lever</b> . . . . .   | <b>20</b> |
| basic position, adjusting . . . . . | 107       |
| free travel, checking . . . . .     | 106       |

|                                     |           |
|-------------------------------------|-----------|
| <b>Handlebar position</b> . . . . . | <b>93</b> |
| adjusting . . . . .                 | 94        |

|  |    |
|--|----|
| <b>Hazard warning flasher</b> . . . . .        | 26 |
| <b>Hazard warning flasher switch</b> . . . . . | 26 |

|                                      |     |
|--------------------------------------|-----|
| <b>Headlight setting</b>             |     |
| checking . . . . .                   | 135 |
| headlight range, adjusting . . . . . | 136 |

|                                   |    |
|-----------------------------------|----|
| <b>Horn button</b> . . . . .      | 25 |
| <b>Hot start button</b> . . . . . | 45 |

## I

|  |    |
|--|----|
| <b>Ignition switch</b> . . . . .         | 25 |
| <b>Indicator lamp overview</b> . . . . . | 27 |

## K

|                              |    |
|------------------------------|----|
| <b>Key number</b> . . . . .  | 17 |
| <b>Kill switch</b> . . . . . | 24 |

## L

|                               |    |
|-------------------------------|----|
| <b>Light switch</b> . . . . . | 23 |
|-------------------------------|----|

## M

|                    |     |
|--------------------|-----|
| <b>Main fuse</b>   |     |
| changing . . . . . | 132 |

|                              |   |
|------------------------------|---|
| <b>Maintenance</b> . . . . . | 8 |
|------------------------------|---|

## O

|                      |     |
|----------------------|-----|
| <b>Oil filter</b>    |     |
| changing . . . . .   | 164 |
| installing . . . . . | 170 |
| removing . . . . .   | 168 |

|                    |     |
|--------------------|-----|
| <b>Oil screens</b> |     |
| cleaning . . . . . | 164 |

|                                 |    |
|---------------------------------|----|
| <b>Owner's manual</b> . . . . . | 11 |
|---------------------------------|----|

## P

|                          |    |
|--------------------------|----|
| <b>Parking</b> . . . . . | 64 |
|--------------------------|----|

|                                |           |
|--------------------------------|-----------|
| <b>Parking brake</b> . . . . . | <b>22</b> |
| front . . . . .                | 20        |
| rear . . . . .                 | 22        |

|                               |    |
|-------------------------------|----|
| <b>Play in throttle cable</b> |    |
| adjusting . . . . .           | 97 |
| checking . . . . .            | 96 |

|                               |     |
|-------------------------------|-----|
| <b>Putting into operation</b> |     |
| advice on first use . . . . . | 48  |
| after storage . . . . .       | 181 |

checks before putting into operation . . . . . 51

## R

**Radiator fan** . . . . . 152

### Radiator spoiler

installing . . . . . 138

removing . . . . . 137

### Rear shock absorber

compression damping, adjusting . . . . . 79

installing . . . . . 85

rebound damping, adjusting . . . . . 80

removing . . . . . 83

spring preload, adjusting . . . . . 81

### Rear sprocket / engine sprocket

checking for wear . . . . . 101

### Rear wheel eccentric element

greasing . . . . . 105

**Rider training** . . . . . 10

### Riding

bends . . . . . 57

brakes . . . . . 55

downhill . . . . . 58

engine, switching off . . . . . 62

general information . . . . . 56

perpendicular to the slope . . . . . 60

riding through water . . . . . 62

starting up . . . . . 54

stopping, parking . . . . . 64

turning on slopes . . . . . 60

uphill . . . . . 59

## S

### Seat

mounting . . . . . 137

removing . . . . . 136

**Service schedule** . . . . . 67-71

### Shift lever

basic position, adjusting . . . . . 98

basic setting, checking . . . . . 97

### Shifting

forward gears . . . . . 54

### Shock absorber

front shock absorber part number . . . . . 18

rear shock absorber part number . . . . . 18

**Spare parts** . . . . . 8

### Speedometer

adjusting . . . . . 31

function description . . . . . 28

setting kilometers or miles . . . . . 29

setting the clock . . . . . 30

**Starting** . . . . . 52

### Steering

locking . . . . . 43

unlocking . . . . . 43

**Stopping** . . . . . 64

**Storage** . . . . . 180

## T

### Technical data

carburetor . . . . . 187  
 chassis . . . . . 188-191  
 chassis tightening torques . . . . . 194-195  
 engine . . . . . 182-183  
 engine tightening torques . . . . . 184-186  
 front shock absorber . . . . . 192  
 rear shock absorber . . . . . 193

**Throttle lever** . . . . . 23

### Tire air pressure

checking . . . . . 128

### Tire condition

checking . . . . . 127

### Toe

adjusting . . . . . 88  
 checking . . . . . 85

**Transport** . . . . . 9

**Troubleshooting** . . . . . 173-177

**Turn signal switch** . . . . . 24

**Type label** . . . . . 16

## U

**Use definition** . . . . . 8

## V

### Vehicle

cleaning . . . . . 178  
 jacking up . . . . . 72  
 removing from work stand . . . . . 72

## W

### Wheel/wheels

installing . . . . . 126  
 removing . . . . . 125

**Work rules** . . . . . 9



3211487en



06/2009 Photo: Mitterbauer



**KTM-Sportmotorcycle AG**  
5230 Mattighofen/Austria  
<http://www.ktm.com>