



WP Xplor Preload Adjuster Set



PRELOAD ADJUSTER SET XPLOR 48

79401905000

ZG10001

- 1) Screw off the standard screw cap.
- 2) Fix the spanner (SW 22) on the nut of the hydro stop.
- 3) Mount the preload adjuster cap on the piston rod and screw the cap on block (5Nm).
- 4) Put the WP special tool (T14087) on the cap and counter it with the spanner (25Nm).

